

Aurora AK-200 Electric Kettle User Manual

Thank you for choosing the Aurora AK-200 variable temperature electric kettle. Read this manual completely before first use and keep it for future reference. This manual covers setup, daily operation, descaling, troubleshooting and the technical specifications of the appliance.

Important Safety Instructions

Use the kettle only with the supplied power base. Do not immerse the kettle, base or cord in water. Keep the appliance out of reach of children while hot. Do not operate the kettle when it is empty, and unplug it before cleaning. Use only on a dry, flat and heat resistant surface.

Getting Started

Before first use, fill the kettle to the MAX line, boil the water and discard it twice to remove any manufacturing residue. Place the power base on a flat surface and wind excess cord into the storage recess under the base. The kettle switches off automatically when the selected temperature is reached.

Selecting the Water Temperature

Press the TEMP button to select the water temperature. Five presets are available: 60, 70, 80, 90 and 100 degrees Celsius. Green tea is best at 80 degrees, coffee at 90 degrees, and black tea at a full boil of 100 degrees. The HOLD button keeps the selected temperature for 30 minutes.

Descaling and Maintenance

Descale the kettle every 4 to 6 weeks in hard water areas. Fill the kettle with a mixture of half water and half white vinegar, boil once, then let it stand for 30 minutes before rinsing thoroughly three times. Never use abrasive cleaners on the stainless steel body. Wipe the outside with a soft damp cloth only.

Troubleshooting

If the kettle does not turn on, check that the power base is plugged in and that the kettle sits fully seated on the base. If the kettle switches off before boiling, it most likely needs descaling. If the boil-dry protection has triggered, let the kettle cool for 10 minutes before using it again.

Technical Specifications

The Aurora AK-200 has a capacity of 1.7 liters and a 2200 watt concealed heating element. It operates on 220 to 240 volts at 50 to 60 hertz. The body is brushed stainless steel with a BPA-free water window, and the kettle weighs 1.2 kilograms without the base.

Warranty

The Aurora AK-200 is covered by a 2 year limited warranty from the date of purchase. The warranty covers manufacturing defects but not damage caused by limescale, misuse or unauthorized repair. Register your kettle at aurora.example/register within 30 days to activate the warranty.