# 实验三 快速傅立叶变换(FFT)算法应用实验

### 一、实验目的

- 1. 了解 DSP 的定时器。
- 2. 了解 DSP 片内 AD 的控制方法。
- 3. 了解 DSP 片内 DA (选做) 。
- 4. 掌握 FFT 的应用。

# 二、实验设备

计算机

ICETEK-F28335-AF 实验箱 (带 ICETEK 仿真器)

示波器

### 三、实验原理

#### 1. 片内自带模数转换模块特性

12 位模数转换模块 ADC;

快速转换功能,时钟周期为 25MHz,最小采样带宽为 12.5MSPS;

16 个模拟输入通道(AINO-AIN15)。

内置双采样-保持器

模拟输入电压范围: 0-3v, 切记输入 ad 的信号不要超过这个范围, 否则会烧坏芯片。

#### 2. 模数模块介绍

ADC 模块有 16 个通道,可配置为两个独立的 8 通道模块以方便为事件管理器 A 和 B 服务。两个独立的 8 通道模块可以级连组成 16 通道模块。虽然有多个输入通道和两个序列器,但在 ADC 内部只有一个转换器,同一时刻只有 1 路 AD 进行转换数据。

#### 3. 模数转换的程序控制

模数转换相对于计算机来说是一个较为缓慢的过程。一般采用中断方式启动转换或保存结果,这样在 CPU 忙于其他工作时可以少占用处理时间。设计转换程序应首先考虑处理过程如何与模数转换的时间相匹配,根据实际需要选择适当的触发转换的手段,也要能及时地保存结果。

#### 4. FFT 的原理和参数生成公式

$$x(k) = \sum_{r=0}^{\frac{N}{2}-1} x_1(r) W_{\frac{N}{2}}^{rk} + W_N^k \sum_{r=0}^{\frac{N}{2}-1} x_2(r) W_{\frac{N}{2}}^{rk} = X_1(k) + W_N^k X_2(k)$$

公式(1)FFT 运算公式

FFT 并不是一种新的变换,它是离散傅立叶变换(DFT)的一种快速算法。由于我们在计算 DFT 时一次复数乘法需用四次实数乘法和二次实数加法;一次复数加法则需二次实数加法。每运算一个 X(k) 需要 4N 次复数乘法及 2N+2 (N-1)=2 (2N-1) 次实数加法。所以整个 DFT 运算总共需要  $4N^2$  次实数乘法和  $N^2(2N-1)=2N(2N-1)$  次实数加法。如此一来,计算时乘法次数和加法次数都是和  $N^2$  成正比的,当 N 很大时,运算量是可观的,因而需要改进对 DFT 的算法减少运算速度。

根据傅立叶变换的对称性和周期性,我们可以将 DFT 运算中有些项合并。

我们先设序列长度为  $N=2^L$ , L 为整数。将  $N=2^L$  的序列 x(n)(n=0,1,....., N-1),按 N 的奇偶分成两组,也就是说我们将一个 N 点的 DFT 分解成两个 N/2 点的 DFT,他们又从新组合成一个如下式所表达的 N 点 DFT:

一般来说,输入被假定为连续的。当输入为纯粹的实数的时候,我们就可以利用左右

$$x(k) = \sum_{r=0}^{\frac{N}{2}-1} x_1(r) W_{\frac{N}{2}}^{rk} + W_N^k \sum_{r=0}^{\frac{N}{2}-1} x_2(r) W_{\frac{N}{2}}^{rk} = X_1(k) + W_N^k X_2(k)$$

对

称的特性更好的计算 DFT。

我们称这样的 RFFT 优化算法是包装算法: 首先 2N 点实数的连续输入称为"进包"。 其次 N 点的 FFT 被连续被运行。最后作为结果产生的 N 点的合成输出是"打开"成为最初的与 DFT 相符合的 2N 点输入。

使用这战略,我们可以划分 FFT 的大小,它有一半花费在包装输入 O(N)的操作和打开输出上。这样的 RFFT 算法和一般的 FFT 算法同样迅速,计算速度几乎都达到了两次 DFT 的连续输入。下列一部分将描述更多的在 TMS320C54x 上算法和运行的细节。

### 四、实验内容

1. 基本内容: (完成 8 分,不能完成视情况依内容给定时器 2 分、AD 转换 2 分、FFT 变换 2 分,综合 2 分)

采集正弦、方波和三角波信号,并对其进行 FFT 变换,需要良好的人机交互界面。

完成此项基本内容,需要首先分别完成如下内容:(1)定时器调试正常,定时时间正确;(2) AD 采集正常,数据正确;(3) FFT 变换正确。最后将几项内容综合在一起,完成对信号的 FFT 变换。

2. 拓展内容

拓展内容为研究内容,如:采样周期变化对 FFT 结果的影响;加窗类型对 FFT 结果的影响;你在实验过程中发现的需要研究的问题等。

#### 五、实验程序流程图

实验流程需要根据自己的实验画出。

### 六. 实验步骤

- (1) 准备硬件:按照实验一准备实验箱的硬件连接。
- (2) 调试定时器程序。
- (3) 熟悉实验箱里信号源的设置

向内侧按波形频率选择旋钮,相应波形的指示灯点亮。

上下调节波形频率选择旋钮,相应频率范围的指示灯点亮。

调节幅值调整旋钮,可调整输出波形的幅值,通过示波器可观察波形的各项参数。



(4) 将信号源输出连接至 AD 输入,编写 AD 程序,调试 AD 程序() ①取出 1 根实验箱附带的信号线(如下图,两端均为双声道语音插头)。



- ②用 1 根信号线连接实验箱左侧信号源的波形输出 A 端口和 "A/D 输入"模块的 "ADC-Ch.A"插座注意插头要插牢、到底。这样,信号源波形输出 A 的输出波形即可送到 AD 输入通道 0。
  - (5) 编写 FFT 程序,调试 FFT 程序可以先用仿真调试,再加硬件。
  - (6) 检查结果

#### 七、例程

### 1. 定时器例程

```
void main(void)
{
// Step 1. Initialize System Control:
// PLL, WatchDog, enable Peripheral Clocks
// This example function is found in the DSP2833x_SysCtrl.c file.
  InitSysCtrl();
// Step 2. Initalize GPIO:
// This example function is found in the DSP2833x_Gpio.c file and
// illustrates how to set the GPIO to it's default state.
// InitGpio(); // Skipped for this example
  InitXintf16Gpio(); //zq
// Step 3. Clear all interrupts and initialize PIE vector table:
// Disable CPU interrupts
  DINT;
// Initialize the PIE control registers to their default state.
// The default state is all PIE interrupts disabled and flags
// are cleared.
// This function is found in the DSP2833x_PieCtrl.c file.
  InitPieCtrl();
// Disable CPU interrupts and clear all CPU interrupt flags:
  IER = 0 \times 0000;
  IFR = 0x0000;
// Initialize the PIE vector table with pointers to the shell Interrupt
// Service Routines (ISR).
// This will populate the entire table, even if the interrupt
// is not used in this example. This is useful for debug purposes.
// The shell ISR routines are found in DSP2833x DefaultIsr.c.
// This function is found in DSP2833x_PieVect.c.
  InitPieVectTable();
// Interrupts that are used in this example are re-mapped to
// ISR functions found within this file.
  EALLOW; // This is needed to write to EALLOW protected registers
  PieVectTable.TINT0 = &cpu_timer0_isr;
  //PieVectTable.XINT13 = &cpu_timer1_isr;
  //PieVectTable.TINT2 = &cpu_timer2_isr;
         // This is needed to disable write to EALLOW protected registers
```

```
// Step 4. Initialize the Device Peripheral. This function can be
          found in DSP2833x CpuTimers.c
  InitCpuTimers(); // For this example, only initialize the Cpu Timers
#if (CPU_FRQ_150MHZ)
// Configure CPU-Timer 0, 1, and 2 to interrupt every second:
// 150MHz CPU Freq, 1 second Period (in uSeconds)
  ConfigCpuTimer(&CpuTimer0, 150, 1000000);
  //ConfigCpuTimer(&CpuTimer1, 150, 1000000);
  //ConfigCpuTimer(&CpuTimer2, 150, 1000000);
#endif
#if (CPU FRQ 100MHZ)
// Configure CPU-Timer 0, 1, and 2 to interrupt every second:
// 100MHz CPU Freq, 1 second Period (in uSeconds)
  ConfigCpuTimer(&CpuTimer0, 100, 1000000);
  //ConfigCpuTimer(&CpuTimer1, 100, 1000000);
  //ConfigCpuTimer(&CpuTimer2, 100, 1000000);
#endif
// To ensure precise timing, use write-only instructions to write to the entire
register. Therefore, if any
// of the configuration bits are changed in ConfigCpuTimer and InitCpuTimers
(in DSP2833x_CpuTimers.h), the
// below settings must also be updated.
  //CpuTimerORegs.TCR.all = 0x4001; // Use write-only instruction to set TSS
bit = 0
  //CpuTimer1Regs.TCR.all = 0x4001; // Use write-only instruction to set TSS
  //CpuTimer2Regs.TCR.all = 0x4001; // Use write-only instruction to set TSS
bit = 0
// Step 5. User specific code, enable interrupts:
//CpuTimer0Regs.PRD.all=0xffff;
CpuTimer0Regs.TPR.all=0;
CpuTimer0Regs.TIM.all=0;
CpuTimer0Regs.TPRH.all=0;
CpuTimer0Regs.TCR.bit.TSS=1;
CpuTimer0Regs.TCR.bit.SOFT=1;
CpuTimer0Regs.TCR.bit.FREE=1;
CpuTimer0Regs.TCR.bit.TRB=1;
CpuTimer0Regs.TCR.bit.TIE=1;
```

```
CpuTimer0.InterruptCount=0;
startCpuTimer0();
// Enable CPU int1 which is connected to CPU-Timer 0, CPU int13
// which is connected to CPU-Timer 1, and CPU int 14, which is connected
// to CPU-Timer 2:
  IER |= M INT1;
  //IER |= M_INT13;
  //IER |= M INT14;
// Enable TINTO in the PIE: Group 1 interrupt 7
  PieCtrlRegs.PIEIER1.bit.INTx7 = 1;
// Enable global Interrupts and higher priority real-time debug events:
  EINT; // Enable Global interrupt INTM
  ERTM; // Enable Global realtime interrupt DBGM
// Step 6. IDLE loop. Just sit and loop forever (optional):
for(;;)
 {
   }
}
interrupt void cpu_timer0_isr(void)
{
  CpuTimer0.InterruptCount++;
  // Acknowledge this interrupt to receive more interrupts from group 1
  PieCtrlRegs.PIEACK.all = PIEACK_GROUP1;
  CpuTimer0Regs.TCR.bit.TIF=1;
  CpuTimer0Regs.TCR.bit.TRB=1;
  if(ncount==0)
  { LED=uLBD;
     uLBD++;uLBD%=16;
  }
  ncount++;ncount%=194;
   }
   2. AD 例程
#include "DSP2833x_Device.h" // DSP2833x Headerfile Include File
```

```
#include "DSP2833x_Examples.h" // DSP2833x Examples Include File
// Determine when the shift to right justify the data takes place
// Only one of these should be defined as 1.
// The other two should be defined as 0.
#define POST_SHIFT 0 // Shift results after the entire sample table is full
#define INLINE SHIFT 1 // Shift results as the data is taken from the results
regsiter
#define NO SHIFT 0 // Do not shift the results
// ADC start parameters
#if (CPU FRQ 150MHZ) // Default - 150 MHz SYSCLKOUT
 #define ADC_MODCLK 0x3 // HSPCLK = SYSCLKOUT/2*ADC_MODCLK2 = 150/(2*3) =
25.0 MHz
#endif
#if (CPU FRQ 100MHZ)
 #define ADC_MODCLK 0x2 // HSPCLK = SYSCLKOUT/2*ADC_MODCLK2 = 100/(2*2) =
25.0 MHz
#endif
#define ADC_CKPS 0x0 // ADC module clock = HSPCLK/1 = 25.5MHz/(1) =
25.0 MHz
#define ADC_SHCLK 0x1 // S/H width in ADC module periods
2 ADC cycle
#define AVG
                 1000 // Average sample limit
#define ZOFFSET 0x00 // Average Zero offset
#define BUF_SIZE 1024 // Sample buffer size
// Global variable for this example
Uint16 SampleTable[BUF_SIZE];
Uint16 SampleTable1[BUF SIZE];
Uint16 AD0[64];
main()
  Uint16 i;
  Uint16 j,k;
  Uint16 array_index;
  Uint16 array_index1;
// Step 1. Initialize System Control:
// PLL, WatchDog, enable Peripheral Clocks
// This example function is found in the DSP2833x_SysCtrl.c file.
  InitSysCtrl();
```

```
// Specific clock setting for this example:
  EALLOW;
  SysCtrlRegs.HISPCP.all = ADC_MODCLK; // HSPCLK = SYSCLKOUT/ADC_MODCLK
// Step 2. Initialize GPIO:
// This example function is found in the DSP2833x Gpio.c file and
// illustrates how to set the GPIO to it's default state.
// InitGpio(); // Skipped for this example
// Enable the pin GPIO34 as output
  EALLOW;
  GpioCtrlRegs.GPBMUX1.bit.GPIO34 = 0;  // GPIO pin
  GpioCtrlRegs.GPBDIR.bit.GPIO34 = 1;  // Output pin
  EDIS;
// Step 3. Clear all interrupts and initialize PIE vector table:
// Disable CPU interrupts
  DINT;
// Initialize the PIE control registers to their default state.
// The default state is all PIE interrupts disabled and flags
// are cleared.
// This function is found in the DSP2833x PieCtrl.c file.
  InitPieCtrl();
// Disable CPU interrupts and clear all CPU interrupt flags:
  IER = 0 \times 0000;
  IFR = 0 \times 0000;
// Initialize the PIE vector table with pointers to the shell Interrupt
// Service Routines (ISR).
// This will populate the entire table, even if the interrupt
// is not used in this example. This is useful for debug purposes.
// The shell ISR routines are found in DSP2833x DefaultIsr.c.
// This function is found in DSP2833x PieVect.c.
  InitPieVectTable();
// Step 4. Initialize all the Device Peripherals:
// This function is found in DSP2833x_InitPeripherals.c
// InitPeripherals(); // Not required for this example
  InitAdc();
                    // For this example, init the ADC
// Specific ADC setup for this example:
  AdcRegs.ADCTRL1.bit.ACQ PS = ADC SHCLK; // Sequential mode: Sample rate
```

```
1/[(2+ACQ_PS)*ADC clock in ns]
                                           = 1/(3*40ns) = 8.3MHz (for 150 MHz
SYSCLKOUT)
                      //
                                            = 1/(3*80ns) = 4.17MHz (for 100 MHz
SYSCLKOUT)
                      // If Simultaneous mode enabled: Sample rate =
1/[(3+ACQ PS)*ADC clock in ns]
  AdcRegs.ADCTRL3.bit.ADCCLKPS = ADC_CKPS;
  AdcRegs.ADCTRL1.bit.SEQ CASC = 1;
                                        // 1 Cascaded mode
  //AdcRegs.ADCCHSELSEQ1.bit.CONV00 = 0xf;
  //AdcRegs.ADCCHSELSEQ1.bit.CONV01 = 0x0;
  AdcRegs.ADCCHSELSEQ1.bit.CONV02 = 0x2;
  AdcRegs.ADCCHSELSEQ1.bit.CONV03 = 0x3;
  AdcRegs.ADCTRL1.bit.CONT RUN = 1;
                                         // Setup continuous run
  AdcRegs.ADCTRL1.bit.SEQ OVRD = 1;  // Enable Sequencer override feature
// AdcRegs.ADCCHSELSEQ1.all = 0x320f;
                                          // Initialize all ADC channel
selects to A2,A3
// AdcRegs.ADCCHSELSEQ2.all = 0x0;
 // AdcRegs.ADCCHSELSEQ3.all = 0x0;
  //AdcRegs.ADCCHSELSEQ4.all = 0x0;
  AdcRegs.ADCMAXCONV.bit.MAX_CONV1 = 0x1; // convert and store in 8 results
registers
// Step 5. User specific code, enable interrupts:
// Clear SampleTable
  for (i=0; i<BUF SIZE; i++)</pre>
    SampleTable[i] = 0;
    SampleTable1[i] = 0;
  }
  for(i=0;i<64;i++)</pre>
   AD0[i]=0;
// Start SEQ1
  AdcRegs.ADCTRL2.all = 0x2000;
  for(;;)
    array_index = 0;
    array_index1 = 0;
```

```
for (i=0; i<(BUF_SIZE); i++)</pre>
    {
      // Wait for int1
      while (AdcRegs.ADCST.bit.INT_SEQ1== 0){}
      GpioDataRegs.GPBSET.bit.GPIO34 = 1; // Set GPIO34 for monitoring
-optional
      AdcRegs.ADCST.bit.INT_SEQ1_CLR = 1;
      SampleTable[array_index++] = ( (AdcRegs.ADCRESULT2)>>4);
      SampleTable1[array_index1++]= ( (AdcRegs.ADCRESULT3)>>4);
      for(j=0;j<100;j++)</pre>
       k++;
    }
   for (i=0; i<BUF SIZE; i++)</pre>
     SampleTable[i] = ((SampleTable[i]) >>4);
      SampleTable1[i] = ((SampleTable1[i]) >>4);
   }
   GpioDataRegs.GPBCLEAR.bit.GPIO34 = 1; // Break point
 }
}
3. FFT例程
#include"math.h"
#define PI 3.1415926
#define SAMPLENUMBER 128
void InitForFFT();
void MakeWave();
//void FFT(float dataR[SAMPLENUMBER],float dataI[SAMPLENUMBER]);
int INPUT[SAMPLENUMBER], DATA[SAMPLENUMBER];
float fwaver[SAMPLENUMBER], fwaveI[SAMPLENUMBER], w[SAMPLENUMBER];
float sin_tab[SAMPLENUMBER], cos_tab[SAMPLENUMBER];
void FFT(float dataR[SAMPLENUMBER],float dataI[SAMPLENUMBER])
{
    int x0,x1,x2,x3,x4,x5,x6,xx;
    int i,j,k,b,p,L;
```


```
float TR,TI,temp;
   /***** following code invert sequence ********/
   for ( i=0;i<SAMPLENUMBER;i++ )</pre>
   {
       x0=x1=x2=x3=x4=x5=x6=0;
       x0=i&0x01; x1=(i/2)&0x01; x2=(i/4)&0x01; x3=(i/8)&0x01; x4=(i/16)&0x01;
x5=(i/32)\&0x01; x6=(i/64)\&0x01;
       xx=x0*64+x1*32+x2*16+x3*8+x4*4+x5*2+x6;
       dataI[xx]=dataR[i];
   }
   for ( i=0;i<SAMPLENUMBER;i++ )</pre>
   {
       dataR[i]=dataI[i]; dataI[i]=0;
   }
   /***** following code FFT ***********/
   for ( L=1;L<=7;L++ )</pre>
   { /* for(1) */
       b=1; i=L-1;
       while ( i>0 )
           b=b*2; i--;
       } /* b= 2^(L-1) */
       for ( j=0;j<=b-1;j++ ) /* for (2) */</pre>
       {
           p=1; i=7-L;
           while ( i>0 ) /* p=pow(2,7-L)*j; */
               p=p*2; i--;
           }
           p=p*j;
           for ( k=j;k<128;k=k+2*b ) /* for (3) */</pre>
               TR=dataR[k]; TI=dataI[k]; temp=dataR[k+b];
   dataR[k]=dataR[k]+dataR[k+b]*cos_tab[p]+dataI[k+b]*sin_tab[p];
   dataI[k]=dataI[k]-dataR[k+b]*sin_tab[p]+dataI[k+b]*cos_tab[p];
               dataR[k+b]=TR-dataR[k+b]*cos_tab[p]-dataI[k+b]*sin_tab[p];
               dataI[k+b]=TI+temp*sin_tab[p]-dataI[k+b]*cos_tab[p];
           } /* END for (3) */
       } /* END for (2) */
   } /* END for (1) */
```

```
for ( i=0;i<SAMPLENUMBER/2;i++ )</pre>
    {
        w[i]=sqrt(dataR[i]*dataR[i]+dataI[i]*dataI[i]);
} /* END FFT */
main()
{
    int i;
    InitForFFT();
   MakeWave();
    for ( i=0;i<SAMPLENUMBER;i++ )</pre>
        fWaveR[i]=INPUT[i];
        fWaveI[i]=0.0f;
        w[i]=0.0f;
    }
    FFT(fWaveR,fWaveI);
    for ( i=0;i<SAMPLENUMBER;i++ )</pre>
        DATA[i]=w[i];
   while ( 1 ); // break point
}
void InitForFFT()
{
    int i;
    for ( i=0;i<SAMPLENUMBER;i++ )</pre>
        sin_tab[i]=sin(PI*2*i/SAMPLENUMBER);
        cos_tab[i]=cos(PI*2*i/SAMPLENUMBER);
    }
}
void MakeWave()
{
    int i;
    for ( i=0;i<SAMPLENUMBER;i++ )</pre>
```

```
{
    INPUT[i]=sin(PI*2*i/SAMPLENUMBER*3)*1024;
}
```

# 八、观察窗口

1. 选择菜单 Tools->Graph->Single Time 做如下设置,然后单击"OK"按钮:



- 2. 通过设置,可打开图形窗口观察模数转换和 FFT 转换的结果。
- 7. 运行程序观察结果

点击菜单 Run->Resume,运行程序,或者直接点击 by 按钮;

-按 停止运行,观察窗口中的图形显示;

注:有时候 CCS 显示会出现问题,例如停止程序后,图形观察窗口显示空白或者混乱的波形:可以点击一下按钮 (Reset the Graph),复位图形观察窗口。然后再次运行程序,停止程序。

适当改变信号源,再次运行,停止后观察图形窗口中的显示。