Chapter 5

Time-Domain Analysis of Control Systems (2)

5-2 First-Order Systems

1. Mathematical model

$$T\frac{dc}{dt} + c(t) = r(t)$$

where T is time constant. Many physical systems can be described by first-order system, such as an RC circuit, thermal system, or the like. A simplified block diagram:

$$\begin{array}{ccc}
R(s) & \xrightarrow{T} & C(s) & C(s) & C(s) & \frac{C(s)}{R(s)} & = \frac{1}{Ts+1}
\end{array}$$

Example. Electrical first-order system

$$RC\frac{du_c}{dt} + u_c = u_i$$

$$u_r$$

$$C - u_c$$

Taking the *Laplace* transform of the equation with zero initial condition yields

$$\frac{U_c(s)}{U_r(s)} = \frac{1}{RCs + 1} = \frac{1}{Ts + 1}$$

where the time constant T=RC.

Example. A simplified mathematical model of a missile in linear motion can be described by a first-order system:

$$m\frac{dv}{dt} = f(t) - kv$$

where f(t) is the force, v is the velocity, kv denotes the force of air resistance which is proportional to the velocity, and m, the mass.

Taking the *Laplace* transform of the equation with zero initial condition yields

$$V(s) = \frac{1}{ms + k} F(s) = \frac{1}{k} \frac{1}{(m/k)s + 1} F(s)$$

2. Unit-Step Response of First-order Systems

$$R(s) \longrightarrow \boxed{\frac{1}{Ts+1}} \longrightarrow C(s)$$

The input signal:
$$R(s) = \frac{1}{s}$$

Hence, the output

$$C(s) = \frac{1}{s(Ts+1)} = \frac{1}{s} - \frac{T}{Ts+1} = \frac{1}{s} - \frac{1}{s+1/T}$$


from which, we obtain the time response

$$c(t) = 1 - e^{-t/T}, t \ge 0$$

Step response
$$c(t) = 1 - e^{-t/T}$$
,

$$c(t) = 1 - e^{-t/T},$$

$$\left. \frac{dc}{dt} \right|_{t=0} = \frac{1}{T}$$



3. Unit-Ramp response of First-order Systems

$$R(s) \longrightarrow \boxed{\frac{1}{Ts+1}} \longrightarrow C(s)$$

If the input is the unit ramp $r(t) = t \cdot 1(t)$

then
$$R(s) = \frac{1}{s^2}$$

Expanding C(s) into partial fractions gives

$$C(s) = \frac{1}{s^2} - \frac{T}{s} + \frac{T}{s+1/T}$$

Thus, the time-domain response is


$$c(t) = t - T + Te^{-\frac{t}{T}}, t \ge 0$$

The error signal e(t) is then

$$e(t) = r(t) - c(t) = T(1 - e^{-\frac{t}{T}}), t \ge 0$$

$$\Rightarrow e(\infty) = T$$

The error in following the unit-ramp input is equal to T for sufficiently large t. The smaller the time constant T, the smaller the steady-state error is.



Notice that for first-order systems, the steadystate errors are different when input signals are unit-step function and unit-ramp function, respectively. For unit-step function,

$$\lim_{t\to\infty} e(t) = \lim_{t\to\infty} [r(t) - c(t)] = \lim_{t\to\infty} e^{-t/T} = 0$$

while for unit-ramp function,

$$\lim_{t \to \infty} e(t) = \lim_{t \to \infty} [r(t) - c(t)] = \lim_{t \to \infty} T(1 - e^{-\frac{t}{T}}) = T$$

4. Unit-Impulse response of First-order Systems

$$R(s)$$
 $\xrightarrow{1}$ $C(s)$

If the input is a unit-impulse, then R(s) = 1

Therefore,


$$C(s) = \frac{1}{Ts + 1}$$

Taking the inverse Laplace transform gives


$$c(t) = \frac{1}{T}e^{-t/T}, t \ge 0$$

Unit-Impulse response

Since we have assumed zero initial conditions, the output must change instantaneously from 0 at $t=0^-$ to 1/T at $t=0^+$.



Example. Determine the unit-step response of the following closed-loop system:



Solution: The output C(s) is:

$$C(s) = \frac{K}{s(Ts+1+K)} = \frac{K/T}{s[s+(1+K)/T]} = \frac{a}{s} + \frac{b}{s+(1+K)/T}$$


Evaluating the partial-fraction coefficients yields

$$a = \frac{K}{1+K}, \quad b = -\frac{K}{1+K}$$

Hence, the time response

$$c(t) = \frac{K}{1+K} \left(1 - e^{-[(1+K)/T]t}\right), t \ge 0$$

$$c(t) = \frac{K}{1+K} (1-e^{-[(1+K)/T]t}), \quad t \ge 0$$



5. An important property of LTI systems

The responses of first-order systems to the three inputs are given below:

$$egin{align} c_t &= t - T + Te^{-rac{t}{T}}, t \geq 0 \ & c_{1(t)} &= 1 - e^{-t/T}, t \geq 0 \ & c_\delta &= rac{1}{T}e^{-t/T}, t \geq 0 \ \end{pmatrix}$$

which have the following properties:

$$\begin{aligned} \frac{dc_t}{dt} &= c_{\mathbf{l}(t)} \\ \frac{dc_{\mathbf{l}(t)}}{dt} &= c_{\delta} \end{aligned}$$

In complex domain:

$$C_{t}(s) = \frac{1}{Ts+1} \frac{1}{s^{2}} \Rightarrow sC_{t}(s) = s \frac{1}{Ts+1} \frac{1}{s^{2}} = \frac{1}{Ts+1} \frac{1}{s} = C_{1(t)}(s)$$

$$C_{1(t)}(s) = \frac{1}{Ts+1} \frac{1}{s} \Rightarrow sC_{1(t)}(s) = s \frac{1}{Ts+1} \frac{1}{s} = \frac{1}{Ts+1} = C_{\delta}(s)$$

Conclusion: For unit ramp, step and impulse inputs, the response to the derivative of an *input* signal can be obtained by differentiating the response of the system to the original signal.

Such a conclusion can be readily extended to any LTI systems. In fact, let

$$\frac{1}{s^2} \longrightarrow G(s) \longrightarrow C(s)$$

Then

$$C(s) = G(s) \frac{1}{s^2}$$


Obviously,

$$sC(s) = sG(s)\frac{1}{s^2} = G(s)\left(s\frac{1}{s^2}\right) = G(s)\frac{1}{s}$$

The left hand side is the derivative of the *output* and the right hand side is the response to the derivative of the *input*.

Summary of first-order systems

1. Standard first-order system:




2. The main feature of first-order systems: Only one parameter: T, which determines everything:

$$c_{1(t)} = 1 - e^{-t/T}, t \ge 0$$

$$c_t = t - T + Te^{-\frac{t}{T}}, t \ge 0$$

$$c_{\delta} = \frac{1}{T}e^{-t/T}, t \ge 0$$

S-plane:




- T is the unique measure of the speed of unit step response: $t_s=3T$ (5%) or $t_s=4T$ (2%).
- Only one pole, s=-1/T, whose distance to the imaginary axis determines the speed of response.

5-3. Second-order systems

Many physical control systems can be described by or approximated to a second-order differential equation.

1. Examples of second-order systems: Servo control system:



The system consists of a proportional control and load elements (inertia and viscous friction elements). Control objective: output position C tracks the desired position R.

The transfer function with respect to the torque T, the moment of inertia J and viscous friction referred to the motor shaft B is

$$\frac{C(s)}{T(s)} = \frac{1}{s(Js+B)}$$


Therefore, the closed-loop transfer function

$$\frac{C(s)}{R(s)} = \frac{K/J}{s^2 + (B/J)s + K/J}$$

The **standard form** of second order systems is

$$\frac{C(s)}{R(s)} = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2}$$


where ω_n is undamped natural frequency and ζ , the damping ratio.



The characteristic equation

$$s^2 + 2\zeta\omega_n s + \omega_n^2 = 0$$

RLC circuit: A second-order system example.




$$\frac{Y(s)}{U(s)} = \frac{1}{LCs^2 + RCs + 1} = \frac{1/LC}{s^2 + (R/L)s + 1/LC}$$

$$\omega_n = \sqrt{\frac{1}{LC}}$$

$$2\zeta\omega_n = \frac{R}{L} = 2\left(\frac{1}{2}R\sqrt{\frac{C}{L}}\right)\sqrt{\frac{1}{LC}}$$

Mass-Spring-Damper System: A second-order system example.



k: Spring constant

f: Damping coefficient

$$m\ddot{y} + f\dot{y} + ky = u$$

$$\frac{Y(s)}{U(s)} = \frac{1}{m s^2 + f s + k} = \frac{1}{k} \left(\frac{k / m}{s^2 + (f / m) s + k / m} \right)$$

2. Step response of second-order systems

(1) Underdamped case $(0 < \zeta < 1)$: From

$$s^2 + 2\zeta\omega_n s + \omega_n^2 = 0$$


The two poles can be expressed as

$$s_{1,2} = -\zeta \omega_n \pm j\omega_n \sqrt{1-\zeta^2} = -\zeta \omega_n \pm j\omega_d$$

where

$$\omega_d = \omega_n \sqrt{1 - \zeta^2}$$

 $\boldsymbol{\omega_d}$ is called damped frequency.



The step response


The step response
$$C(s) = \frac{\omega_n^2}{s(s^2 + 2\zeta\omega_n s + \omega_n^2)} = \frac{1}{s} - \frac{s + 2\zeta\omega_n}{s^2 + 2\zeta\omega_n s + \omega_n^2}$$

$$= \frac{1}{s} - \frac{s + \zeta\omega_n}{(s + \zeta\omega_n)^2 + \omega_d^2} - \frac{\zeta}{\sqrt{1 - \zeta^2}} \frac{\omega_d}{(s + \zeta\omega_n)^2 + \omega_d^2}$$

Hence,

$$\begin{split} c(t) &= 1 - e^{-\zeta \omega_n t} \cos \omega_d t - e^{-\zeta \omega_n t} \frac{\zeta}{\sqrt{1 - \zeta^2}} \sin \omega_d t \\ &= 1 - \frac{e^{-\zeta \omega_n t}}{\sqrt{1 - \zeta^2}} \Big[\sqrt{1 - \zeta^2} \cos \omega_d t + \zeta \sin \omega_d t \Big] \\ &= 1 - \frac{e^{-\zeta \omega_n t}}{\sqrt{1 - \zeta^2}} \sin \left(\omega_d t + \beta \right), t \geq 0 \end{split}$$
 where $\cos \beta = \zeta$ or $\tan \beta = \sqrt{1 - \zeta^2} / \zeta$.


$$c(t) = 1 - \frac{e^{-\zeta \omega_n t}}{\sqrt{1 - \zeta^2}} \sin(\omega_d t + \beta), t \ge 0$$



The response oscillatorily decays to one $(0 < \zeta < 1)$

In particular, if the damping ratio $\zeta=0$, the response becomes **undamped** and oscillations continue indefinitely:

$$c(t) = 1 - \cos \omega_n t, \quad t \ge 0$$



This is why we call ω_n as undamped natural frequency, which is in fact cannot be observed experimentally; what we are able to observe is damped frequency

$$\omega_d = \omega_n \sqrt{1 - \zeta^2}$$


which is always lower than ω_n when $0 < \zeta < 1$. If ζ is increased beyond unity, that is, $\zeta > 1$, the response becomes **overdamped** and will not oscillate.

(2) Critical damped case $(\zeta=1)$: The unit-step response

$$C(s) = \frac{\omega_n^2}{s(s + \omega_n)^2} = \frac{1}{s} - \frac{1}{s + \omega_n} - \frac{\omega_n}{(s + \omega_n)^2}$$

Taking the inverse Laplace transform of both sides of the above equation yields

$$c(t) = 1 - e^{-\omega_n t} (1 + \omega_n t), \quad t \ge 0$$



(3) Overdamped Case ($\zeta > 1$):

• Unit-step response: The characteristic equation has two negative real poles:


$$s^{2} + 2\zeta\omega_{n}s + \omega_{n}^{2} = (s + s_{1})(s + s_{2}) = \left(s + \frac{1}{T_{1}}\right)\left(s + \frac{1}{T_{2}}\right)$$

where

$$\begin{cases} T_1 = \frac{1}{\underbrace{\zeta\omega_n - \omega_n \sqrt{\zeta^2 - 1}}} \coloneqq \frac{1}{s_2} \\ T_2 = \underbrace{\frac{1}{\zeta\omega_n + \omega_n \sqrt{\zeta^2 - 1}}} \coloneqq \frac{1}{s_1} \\ \underbrace{\frac{-s_1}{\zeta\omega_n + \omega_n \sqrt{\zeta^2 - 1}}} \coloneqq \frac{1}{s_1} \\ \underbrace{-\frac{1}{T_2}}_{-\frac{1}{T_1}} \xrightarrow{-\frac{1}{T_1}} \end{cases}$$

Therefore,

$$T_1 > T_2$$
 $(s_2 < s_1), \ \omega_n^2 = \frac{1}{T_1 T_2}$



1.5

Hence,


$$C(s) = \frac{\frac{1}{T_1 T_2}}{\left(s + \frac{1}{T_1}\right) \left(s + \frac{1}{T_2}\right)} \frac{1}{s} = \frac{1}{s(T_1 s + 1)(T_2 s + 1)}$$

$$= \frac{1}{s} + \frac{1}{\frac{T_2}{T_1} - 1} \times \frac{1}{\left(s + \frac{1}{T_1}\right)} + \frac{1}{\frac{T_1}{T_2} - 1} \times \frac{1}{\left(s + \frac{1}{T_2}\right)}$$

The unit-step response is

$$c(t) = 1 + \frac{1}{\frac{T_2}{T_1} - 1} e^{-\frac{1}{T_1}t} + \frac{1}{\frac{T_1}{T_2} - 1} e^{-\frac{1}{T_2}t}$$


$$= 1 + \frac{\omega_n}{2\sqrt{\zeta^2 - 1}} \left(\frac{e^{-s_1t}}{s_1} - \frac{e^{-s_2t}}{s_2}\right), t \ge 0$$



• Reduction to a first-order system. From

$$C(s) = \frac{\frac{1}{T_1 T_2}}{\left(s + \frac{1}{T_1}\right) \left(s + \frac{1}{T_2}\right)} R(s) \qquad \frac{-s_1 - s_2}{\times} \xrightarrow{\times} \xrightarrow{\times}$$

it can be seen that for overdamped case, the secondorder system can be expressed as two first-order systems connected in cascade:



$$\begin{array}{c|c} R(s) & \hline & 1 \\ \hline T_1s+1 & \hline & T_2s+1 & \hline \end{array}$$


In particular, if $-1/T_1$ is located very much closer to the $j\omega$ axis than $-1/T_2$, (which means $1/T_1 << 1/T_2$), then for an approximate solution we may neglect $-1/T_2$ and the second-order system can be reduced to a first-order system:

$$R(s) \xrightarrow{T_1 s + 1} C(s)$$
or
$$\frac{C(s)}{R(s)} = \frac{s_2}{s + s_2} = \frac{\zeta \omega_n - \omega_n \sqrt{\zeta^2 - 1}}{s + \zeta \omega_n - \omega_n \sqrt{\zeta^2 - 1}} \xrightarrow{-s_1 - s_2} j\omega$$


$$c(t) = 1 - e^{-(\zeta - \sqrt{\zeta^2 - 1})\omega_n t}, \quad t \ge 0$$

Second-order system

$$\Phi(s) = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2}$$




Qualitative analysis of unit-step response of the cond-




 $0.4 \le \zeta \le 0.8$, the system gets close to the final value more rapidly than a critically damped

or overdamped systems. Small values of ζ (ζ < 0.4) yield excessive overshoot in the transient response, and a system with a large value of ζ (ζ > 0.8) responds sluggishly.



In particular, when $\zeta \approx 0.707$, the system exhibits fastest response with a nice overshoot (=4%).




- (2)Among the systems without oscillation $(\zeta \geq 1)$, the critical damped system exhibits the fastest response.
- (3)An overdamped system is always sluggish.

3. Definitions of Transient Response Specifications

- In many practical cases, the desired performance characteristics are specified in terms of time-domain quantities.
- Usually, the performance characteristics of a control system are specified in terms of the transient response to a **unit-step input** since it is easy to generate and is sufficiently drastic.

(1) Peak time t_n and maximum percent overshoot M_n


 t_p is the time required for the response to reach the **first** peak of the overshoot.



$$M_p = \frac{c(t_p) - c(\infty)}{c(\infty)} \times 100\%$$


(3) Settling time t_s

The settling time is defined as the time required for the step response to reach and stay within a specified percentage of its final value. A frequently used figure is 5% or 2% tolerance band.



(4) Steady-state error e_{ss}

$$e_{ss} := \lim_{t \to \infty} (r(t) - c(t)) = \lim_{t \to \infty} (1 - c(t))$$



Steady-state error

4. Transient Response Specifications for secondorder systems

(1) Peak time t_p (0< ζ <1):


$$c(t) = 1 - \frac{e^{-\zeta\omega_n t}}{\sqrt{1 - \zeta^2}} \sin(\omega_d t + \beta)$$

$$\frac{dc(t)}{dt} = \frac{\omega_n}{\sqrt{1-\zeta^2}} e^{-\zeta\omega_n t} \sin \omega_d t = 0 \Rightarrow \omega_d t = 0, \pi, 2\pi, \dots$$

$$t_p = \frac{\pi}{\omega_d} = \frac{\pi}{\omega_n \sqrt{1 - \zeta^2}}$$

(2) Maximum Percent Overshoot $(0 < \zeta < 1)$:

$$t_p = \frac{\pi}{\omega_d} = \frac{\pi}{\omega_n \sqrt{1 - \zeta^2}} \Rightarrow c(t_p) = 1 + e^{-\frac{\pi \zeta}{\sqrt{1 - \zeta^2}}}$$




Hence,


$$M_p = e^{\frac{-\pi\zeta}{\sqrt{1-\zeta^2}}} \times 100\%$$

The relationship between ζ and M_p is given below. Note that if ζ is between 0.4 and 0.7, then M_p is between 25% and 4%.

 $M_p = e^{-\pi\zeta/\sqrt{1-\zeta^2}} \times 100\%$




In particular, when $\zeta=1/\sqrt{2}=0.707$, which corresponds to $\beta=45^{\circ}$, $M_p=4\%!$ Such a ζ is called **optimal damping ratio**.



(3) Settling time
$$(0 < \zeta < 1)$$
: $c(t) = 1 - \frac{e^{-\zeta \omega_n t}}{\sqrt{1 - \zeta^2}} \sin(\omega_d t + \beta)$

$$1 \pm \frac{e^{-\zeta \omega_n t}}{\sqrt{1 - \zeta^2}} = \text{envelope curves}$$

whose time constant is $T=1/\zeta\omega_n$.



Therefore,

$$t_s \approx 4T = 4/\zeta \omega_n$$
, (2% criterion)


$$t_s \approx 3T = 3/\zeta \omega_n,$$
 (5% criterion)

(4) Settling time t_s for $(\zeta \ge 1)$:

From

$$C(s) = \frac{\frac{1}{T_1 T_2}}{\left(s + \frac{1}{T_1}\right) \left(s + \frac{1}{T_2}\right)} \frac{1}{s}$$


$$= \frac{1}{s(T_1 s + 1)(T_2 s + 1)}$$



the system can be considered as two first-order subsystems connected in cascade. Since no oscillation arises, only settling time t_s is concerned.

When $\zeta \geq 1$, the settling time t_s can be obtained by looking up the following table (for 5% tolerance

band):



For example:

1)
$$T_1 = T_2 \Leftrightarrow \zeta = 1$$
$$t_s = 4.75T_1$$

2)
$$T_1 / T_2 = 1.5 \Rightarrow \zeta = 1.02$$

 $t_s = 4T_1$

3)
$$T_1/T_2 = 4 \Rightarrow \zeta = 1.25$$

$$t_s \approx 3.3T_1$$

4)
$$T_1/T_2 > 4 \Rightarrow \zeta > 1.25$$

 $t_s \approx 3T_1$





Table: t_s/T_1 versus T_1/T_2

Comments on settling time


• t_s is inversely proportional to the product of ζ and ω_n . Since ζ is usually given by designer from the requirement of M_p , t_s is mainly determined by ω_n .

Example. The step responses for ζ =0.2 with ω_n =1 and ω_n =10, respectively, are shown below.




For a given ζ , the response is faster for larger ω_n . Note that the overshoot is independent of ω_n .

On the other hand, with fixed ω_n , t_s reaches a minimum value around $\zeta = 0.76$ (for the 2\% criterion) or $\zeta =$ 0.68 (for the 5%criterion) and then increases almost linearly for large values of ζ , where $T=1/\zeta\omega_n$ Note that $\zeta=0.707$ implies that $\beta=45^{\circ}$. Also, discontinuities arise.



Example. The unit-step response of a second-order system is shown below, where $\lim_{t\to\infty} c(t) = 3$. Determine its transfer function.



Solution: The transfer function must have the following form:

$$\Phi(s) = \frac{K\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2}$$

with K=3. From the response, it is clear that $t_p=1$ s and $M_p=(1/3)100\%=33.3\%$. Hence, by utilizing the

formulas

$$M_p = e^{-\pi\zeta/\sqrt{1-\zeta^2}} \times 100\%$$

and

$$t_p = \frac{\pi}{\omega_n \sqrt{1 - \zeta^2}}$$


one can obtain that

$$\zeta = 0.33$$

and

$$\omega_n = 3.33 \, \text{rad/s}$$

Example. Consider the following system:



where T=0.1s, and K is the open-loop gain. To determine K such that no overshoot and $t_s=1s$.

Solution: By the requirements, ζ should satisfy $\zeta \ge 1$. Therefore, the closed-loop characteristic equation can be expanded as

$$d(s) = s^{2} + \frac{1}{T}s + \frac{K}{T} = \left(s + \frac{1}{T_{1}}\right)\left(s + \frac{1}{T_{2}}\right) = s^{2} + \left(\frac{1}{T_{1}} + \frac{1}{T_{2}}\right)s + \frac{1}{T_{1}T_{2}} = 0$$


Equating the coefficients for the same power of s yields:

 $\begin{vmatrix}
\frac{K}{T} = \frac{1}{T} \\
\frac{1}{T} = \frac{1}{T}
\end{vmatrix}$

To make the response a required that ζ be close we obtain that when

we have

$$\frac{t_s}{T_1} = 4$$



In that case, $\zeta=1.02$, which is very much close to 1 and therefore, possesses a fast transient response. Since $t_s=1$ s, we have

Therefore, $T_1 = \frac{1}{4}t_s = 0.25 \text{ s}$

$$\frac{T_1}{T_2} = 1.5 \Rightarrow T_2 = \frac{T_1}{1.5} = \frac{0.25}{1.5} = 0.167 \text{ s}$$

To determine K, notice that

$$\begin{cases} \frac{K}{T} = \frac{1}{T_1 T_2} \\ \frac{1}{T} = \frac{1}{T_1} + \frac{1}{T_2} \end{cases}$$

Therefore,

$$K = \frac{T}{T_1 T_2} \Big|_{T=0.1} = \frac{0.1}{0.25 \times 0.167_2} = 2.4s^{-1}$$

Finally, we must check that

$$\frac{1}{T_1} + \frac{1}{T_2} = \frac{1}{T} = \frac{1}{0.1} = 10$$


should be satisfied. Otherwise, K should be redesigned. Fortunately, in this example, from

$$\frac{1}{T_1} = 4, \quad \frac{1}{T_2} = 6$$

such a condition is satisfied.

5. Servo system with velocity feedback

The derivative of the output signal can be used to improve system performance:



Note that without the derivative feedback $(K_h=0)$, system may exhibit excessive overshoot. Indeed, the closed-loop transfer function in that case is

$$\frac{\Theta_m(s)}{\Theta_r(s)} = \frac{K/J}{s^2 + (B/J)s + K/J} = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2}$$

where

$$\omega_n = \sqrt{K/J}$$

$$\zeta = \frac{B}{2\sqrt{JK}}$$


However, taking the derivative feedback into account, the closed-loop transfer function becomes

$$\frac{\Theta_m(s)}{\Theta_r(s)} = \frac{\omega_n^2}{s^2 + 2(\zeta + K_h \omega_n / 2)\omega_n s + \omega_n^2}$$


The improved damping ratio is:

$$\zeta_t = \zeta + \frac{1}{2} K_h \omega_n$$

For a servo control system, in obtaining the derivative of the output position signal, it is desirable to use a tachometer generator instead of physically differentiating the output signal (noise effect, p.175).



Servo-Tek Tachometer Generators provide a convenient means of converting rotational speed into an isolated analog voltage signal suitable for control applications.



Mathematical model:

$$u(t) = K_h \dot{\theta}(t)$$


6. Impulse response of second-order systems

By the property of LTI systems, differentiating the corresponding unit-step response of the second-order system (or directly taking the inverse Laplace transform) yields

$$c(t) = \frac{\omega_n}{\sqrt{1-\zeta^2}} e^{-\zeta\omega_n t} \sin(\omega_d t), t \ge 0, \quad 0 \le \zeta < 1$$

$$c(t) = \omega_n^2 t e^{-\omega_n t}, \quad t \ge 0, \quad \zeta = 1$$

$$c(t) = \frac{\omega_n}{2\sqrt{\zeta^2 - 1}} e^{-(\zeta - \sqrt{\zeta^2 - 1})\omega_n t} - \frac{\omega_n}{2\sqrt{\zeta^2 - 1}} e^{-(\zeta + \sqrt{\zeta^2 - 1})\omega_n t}, t \ge 0, \quad \zeta > 1$$




For ζ <1, c(t) oscillates and takes both positive and negative values.

5-4 Higher-Order Systems

In this section, we shall present a transient response analysis of higher-order systems in general forms. We shall show that the response of higher-order systems is the sum of the responses of first-order and second-order systems.

1. Transient response of higher-order systems



Consider the closed loop transfer function

$$\frac{C(s)}{R(s)} = \frac{G(s)}{1 + G(s)H(s)}$$

$$\frac{C(s)}{R(s)} = \frac{b_0 s^m + b_1 s^{m-1} + \dots + b_m}{s^n + a_1 s^{n-1} + \dots + a_n} = \frac{b_0 \prod_{i=1}^m (s + z_i)}{\prod_{k=1}^n (s + p_k)}, m \le n$$

Assumption 1: $m \le n$.

Almost any physical control system satisfies this condition. A transfer function satisfies Assumption 1 is called a **proper transfer function**. If m < n, the system is called **strictly proper**. We only deal with proper or strictly proper systems.

Assumption 2: All the closed-loop poles lie in the left-half s-plane.

Assumption 3: All the poles are *distinct*.

Unit-step response: Let the input signal be a unitstep function. Then the output is

$$C(s) = \frac{b_0 \prod_{i=1}^{m} (s + z_i)}{\prod_{k=1}^{n} (s + p_k)} \cdot \frac{1}{s} = \frac{a}{s} + \sum_{k=1}^{n} \frac{a_k}{s + p_k}$$

where a and a_k are the residues of the poles at s=0 and $s=-p_k$, respectively:

$$a = \lim_{s \to 0} \frac{b_0 \prod_{i=1}^{m} (s + z_i)}{\prod_{k=1}^{n} (s + p_k)} = \frac{b_0 \prod_{i=1}^{m} (z_i)}{\prod_{k=1}^{n} (p_k)} = \Phi(0)$$

$$a_k = \lim_{s \to -p_k} \frac{b_0 \prod_{i=1}^m (s+z_i)}{\prod_{\substack{i=1 \\ i \neq k}}^n (s+p_i)} \frac{1}{s} = \frac{b_0 \prod_{i=1}^m (-p_k+z_i)}{\prod_{\substack{i=1 \\ i \neq k}}^n (-p_k+p_i)} \frac{1}{-p_k}$$

We consider the general case that C(s) consists of real poles and pairs of complex-conjugate poles. Then,

$$C(s) = \frac{a}{s} + \sum_{j=1}^{q} \frac{a_j}{s + p_j} + \sum_{k=1}^{r} \frac{b_k(s + \zeta_k \omega_k) + c_k \omega_k \sqrt{1 - \zeta_k^2}}{s^2 + 2\zeta_k \omega_k s + \omega_k^2}$$

where n=q+2r. For example,

$$C(s) = \frac{-s^3 + 3s + 4}{(s+1)(s^2 + 2s + 2)} \frac{1}{s} = \frac{2}{s} - \frac{2}{s+1} - \frac{s+1}{s^2 + 2s + 2}$$

Therefore, for the general case, the unit-step response can be written as

$$c(t) = a + \sum_{i=1}^{q} a_i e^{-p_i t} + \sum_{k=1}^{N} b_k e^{-\zeta_k \omega_k t} \cos \omega_k \sqrt{1 - \zeta_k^2} t$$

$$+ \sum_{k=1}^{N} c_k e^{-\zeta_k \omega_k t} \sin \omega_k \sqrt{1 - \zeta_k^2} t$$

$$= a + \sum_{i=1}^{q} a_i e^{-p_i t} + \sum_{k=1}^{N} d_k e^{-\zeta_k \omega_k t} \sin(\omega_k \sqrt{1 - \zeta_k^2} t + \theta_k)$$

Some useful concepts: Residues and dipoles:

- Under the **Assumption 1**, a pair of closely located closed-loop pole and zero is called a **dipole** and can be neglected (p.181).
- On the other hand, if a closed-loop pole is located very far from the imaginary axis, the transient associated with the pole lasts a short time and therefore may be neglected.

Example. A system's transfer function is

$$\Phi(s) = \frac{(s+1.01)}{(s+1)(s+2)}$$

By partial fraction expansion,

$$\Phi(s) = \frac{(s+1.01)}{(s+1)(s+2)} = \frac{0.01}{(s+1)} + \frac{1-0.01}{(s+2)}$$

Taking the inverse Laplace transform yields

$$c(t) = 0.01e^{-t} + (1 - 0.01)e^{-2t}, \quad t \ge 0$$

Obviously, the contribution of the term $0.01e^{-t}$ to the response is small and therefore, can be neglected.

Example. A system's transfer function is

$$\Phi(s) = \frac{1/5}{(s+1)(\frac{1}{5}s+1)} \approx \frac{1}{(s+1)}$$

2. Dominant poles

Example. Consider the following third-order closed-loop system:

$$\Phi(s) = \frac{\omega_n^2}{(s^2 + 2\zeta\omega_n s + \omega_n^2)(\gamma s + 1)}$$

$$-\omega_n \zeta$$


If the real parts satisfy $1/\gamma \ge 5\omega_n \zeta$ $(1/\gamma \ge 4\omega_n \zeta)$, then the third-order system can be approximated by a second-order system

$$\Phi(s) \approx \frac{\omega_n^2}{(s^2 + 2\zeta\omega_n s + \omega_n^2)}$$

whose two poles are called **dominant poles**.

In general, if the ratios of real parts exceed 5 (or 4) and there are no zeros nearby, then the closed-loop poles nearest the $j\omega$ axis will dominate in the transient response and are called **dominant poles**.

Example. The locations of closed-loop poles and zero of a higher order system are shown below. Determine its dominant poles.



The pair of zero-pole nearest the $j\omega$ axis is a dipole and therefore can be neglected. By the rule of determining the dominant poles introduced above, the system can be approximated by a second-order system with a pair of complex-conjugate dominant poles.

3. Stability analysis in complex plane

(1). Concept of stability

Definition: A signal x(t) is said to be bounded if there is a positive real number M such that

$$|x(t)| \leq M$$

for all $t \in [0, \infty)$.

Definition: A system is said to be bounded-input-bounded-output (BIBO) stable if for each bounded input the corresponding output is bounded.

(2). Stability criterion

Theorem: An LTI system with **closed-loop** transfer function G(s) is said to be stable *if and only if* G(s) is proper and all its poles lie in the left-half s-plane $(\Leftrightarrow have\ negative\ real\ parts)$.

Example. Consider the following three systems:


$$\Phi(s) = \frac{1}{(s+1)};$$

$$\Phi(s) = \frac{1}{(s-1)};$$

$$\Phi(s) = \frac{1}{(s^2+1)}.$$

Investigate their unit-step responses.


Example. An inverted pendulum mounted on a motor-drive cart is shown below. The objective is to keep the rod in a vertical position.



The system is unstable.


$$\frac{\Theta(s)}{U(s)}$$

 $=\frac{lm}{\left[(M+m)mgl-(MI+mMl^2+mI)s^2\right]}$





(3). Relative Stability

If dominant poles lie closed to $j\omega$ axis, the transient may exhibit excessive oscillation or very slow. Therefore, to guarantee fast, yet well



For example, if the two dominant poles are located in the region with $\beta=45^{\circ}$ as shown in the following figure. Then, $\zeta=0.707$. The system possesses a satisfactory transient response.





Another relative stability region