
# **Automatic Control**

The structure of feedback control systems

Relevant tf of feedback control systems

Automatic Control – M. Canale

#### Series connection of transfer functions



$$Y(s) = Y_{2}(s) = H_{2}(s)U_{2}(s) = H_{2}(s)Y_{1}(s) =$$

$$= H_{2}(s)H_{1}(s)U_{1}(s) = H_{2}(s)H_{1}(s)U(s) = H(s)U(s)$$


$$U(s) = H_{2}(s)H_{1}(s)$$

$$U(s) = H_{2}(s)H_{1}(s)$$


# **Transfer function connection and block algebra**

Automatic Control – M. Canale

#### Parallel connection of transfer functions



#### Feedback connection of transfer functions




Automatic Control – M. Canale

AC\_L10 5

AC L10 7

#### The general structure of a control system

We start from the scheme of principle of a feedback control system previously introduced (see AC\_L01 p. 9)




... the next step is to describe the dynamic behavior of each block

The structure of a feedback control system

Automatic Control – M. Canale


# The general structure of a control system



Automatic Control – M. Canale

AC L10 8

#### The general structure of a control system




- $G_p(s) \rightarrow$  plant transfer function
- $C(s) \rightarrow$  controller tf
- A → actuator gain
- $G_s \rightarrow$  Sensor gain,  $G_v \rightarrow$  Conditioning filter gain

Automatic Control – M. Canale


AC\_L10 9

## The general structure of a control system



- d'<sub>a</sub>: input disturbance
- $d'_{\nu}$ : output disturbance,  $G_{d}(s) \rightarrow$  tf between  $d'_{\nu}$  and y
- $d_s$ : sensor noise

#### The general structure of a control system




- r: reference signal  $\rightarrow$  desired behavior of the controlled output
- y: (controlled) output
- $e = r y \rightarrow \text{tracking error}$
- *u*: control input (command signal)

Automatic Control – M. Canale


AC L10 10

#### A simplified structure



- $d_a = d'_a / A$  actuator disturbance
- $G_d(s) = 1 \rightarrow d'_v = d_v$
- $d_t = d_s G_y$

#### A simplified structure




- $G(s) = G_p(s) A$
- $T_d = G_y G_s$

Automatic Control – M. Canale

AC\_L10 1

## The loop function L(s)





• The **loop function** is defined as

$$L(s) = G(s) C(s)$$

L(s) is made up by the product of all the tf in the loop

#### A simplified structure






Automatic Control – M. Canale

AC L10 14

## The sensitivity function S(s)



• The **sensitivity function** is defined as

$$S(s) = \frac{1}{1 + L(s)}$$

## The sensitivity function S(s)

$$S(s) = \frac{1}{1 + L(s)}$$

- The **sensitivity function** represents:
  - the transfer function between r and e

$$S(s) = \frac{e(s)}{r(s)}$$


• the transfer function between  $d_{\nu}$  and y

$$S(s) = \frac{y(s)}{d_{y}(s)}$$

Automatic Control – M. Canale

AC\_L10 17

## The complementary sensitivity function T(s)



• The complementary sensitivity function is defined as


$$T(s) = \frac{L(s)}{1 + L(s)}$$

Note that:


$$S(s)+T(s)=\frac{1}{1+L(s)}+\frac{L(s)}{1+L(s)}=1$$

#### The sensitivity function S(s)

- The term sensitivity function is due to the fact that it describes the ability of the control action in reducing the "sensitivity" of the controlled system to the output disturbance w.r.t. the uncontrolled case
  - Uncontrolled system (i.e. open loop)



Controlled system (i.e. closed loop)



Automatic Control – M. Canale

AC L10 18

#### The complementary sensitivity function T(s)

$$T(s) = \frac{L(s)}{1 + L(s)}$$


- The complementary sensitivity function represents:
  - the transfer function between r and y

$$T(s) = \frac{y(s)}{r(s)}$$

• the transfer function between  $d_t$  and y (except for the sign)

$$T(s) = -\frac{y(s)}{d_t(s)}$$

## The control sensitivity function R(s)




The control sensitivity function is defined as

$$R(s) = \frac{C(s)}{1 + L(s)}$$

Automatic Control – M. Canale

AC\_L10 21

# The function Q(s)



• We define also the function:  $Q(s) = \frac{G(s)}{1 + L(s)}$ 

which represents the transfer function between  $d_a$  and y

$$Q(s) = \frac{y(s)}{d_s(s)}$$

Function Q(s) is also known as the **actuator disturbance** sensitivity function

The control sensitivity function R(s)

$$R(s) = \frac{C(s)}{1 + L(s)}$$

- The control sensitivity function represents:
  - the transfer function between r and u

$$R(s) = \frac{u(s)}{r(s)}$$

• the transfer function between  $d_t$  and u (except for the sign)

$$R(s) = -\frac{u(s)}{d_t(s)}$$

Automatic Control – M. Canale

AC L10 22