Behavior Test Tool User Guide

Version 1.0

Copyright ° 2014 Intel Corporation. All rights reserved. No portions of this document may be reproduced without the written permission of Intel Corporation.

Intel is a trademark of Intel Corporation in the U.S. and/or other countries. Linux is a registered trademark of Linus Torvalds.

Tizen® is a registered trademark of The Linux Foundation.

ARM is a registered trademark of ARM Holdings Plc.

*Other names and brands may be claimed as the property of others.

Any software source code reprinted in this document is furnished under a software license and may only be used or copied in accordance with the terms of that license.

Contents

1	Introduction	3
2	Overview	3
3	Install Crosswalk	3
	Deploy tinyweb	
	Installation Behavior Test Tool	
	Preparing To Test	
7	Executing Tests	7
	Viewing the Report	

1 Introduction

This document provides comprehensive information about Behavior Test Tool, including the following: Overview, Installation and Deployment, Test Execution and Report.

2 Overview

Behavior Test Tool is a device behavior checker that uses jQuery. It is a major component of the Tizen Compliance Tests tool set.

Behavior Test Tool has these features:

- A list of behaviors you can test, with information about test cases
- Test cases for checking and evaluating the behavior of a device
- Automatically generated test reports you can view and save for further analysis

3 Install Crosswalk

- 1. Install crosswalk on Tizen
 - Download crosswalk from here

https://download.01.org/crosswalk/releases/tizen-ivi/canary/crosswalk-<version>.i686.rpm

https://download.01.org/crosswalk/releases/tizen-ivi/canary/tizen-extensions-crosswalk-<version>.i686.rpm

Deploy crosswalk to TIZEN device

\$ sdb push crosswalk-<version>.i686.rpm /opt/home/developer

\$ sdb push tizen-extensions-crosswalk-<version>.i686.rpm /opt/home/developer

\$ rpm -ivh crosswalk-<version>.i686.rpm --ignorearch

\$ rpm -ivh tizen-extensions-crosswalk-<version>.i686.rpm -ignorearch

- 2. Install crosswalk on Tizen device
 - Download crosswalk from here

https://download.01.org/crosswalk/releases/android-x86/canary/crosswalk-<version>-x86.zip

Deploy crosswalk to Android device

\$ unzip crosswalk-<version>-x86.zip <path>/
\$ adb install <path>/crosswalk-<version>-x86/apks/XWalkRuntimeLib.apk

4 Deploy tinyweb

1. Deploy tinyweb on Tizen

Make binaries for tinyweb from source code in Github

\$ git clone git@github.com:testkit/tinyweb.git \$ cd tinyweb && make

Deploy binaries to TIZEN device

\$ sdb push tinyweb /opt/home/developer/
\$ sdb shell "chmod a+x /opt/home/developer/tinyweb"
\$ sdb push cgi-getcookie /opt/home/developer/
\$ sdb shell "chmod a+x /opt/home/developer/cgi-getcookie"
\$ sdb push cgi-getfield /opt/home/developer/
\$ sdb shell "chmod a+x /opt/home/developer/cgi-getfield"
\$ sdb push server.pem /opt/home/developer/
\$ sdb shell "chmod 666 /opt/home/developer/server.pem"
\$ sdb shell "ln -s /usr/lib/libssl.so.1.0.0 /opt/home/developer/libssl.so"
\$ sdb shell "ln -s /usr/lib/libcrypto.so.1.0.0 /opt/home/developer/libcrypto.so"

Launch tinyweb

\$ DPATH=`sdb shell "printenv PATH"`
\$ timeout 5 sdb shell "env LD_LIBRARY_PATH=/opt/home/developer
PATH=\$DPATH:/opt/home/developer tinyweb -ssl_certificate
/opt/home/developer/server.pem - document_root /opt/usr/media/tct/listening_ports 80,8080,8081,8082,8083,8443s; sleep 3s"

2. Deploy tinyweb on Android

Make binaries for tinyweb from source code in Github

\$ git clone git@github.com:testkit/tinyweb.git \$ cd tinyweb/android/native/jni/ && /path/to/android-ndk-dir/ndk-build

- Copy <u>tinyweb/android/native/libs/</u> to folder <u>testkit-stub/android/assets/system/libs/</u>
- Import project tinyweb to Android developer Tool by location <u>tinyweb /android</u>
- Build the project and install APK to android device
 - \$ adb install /path/to/tinyweb/bin/tinywebservice.apk
- Launch tinyweb by clicking the tinyweb app icon in launcher

5 Installation Behavior Test Tool

1. Pack Behavior Test Tool

Please see *Web_Test_Suite_Packaging_Guide*, Chapter 3 "*Pack Web Test Suite Packages*", to choose a suitable mode package.

Note: For Android device, only embedded mode APK package is supported.

2. Install Behavior Test Tool

On Tizen:

\$ sdb push tct-behavior-tests-x.x.x-x.xpk.zip /opt/usr/media/tct/

\$ sdb shell

\$ cd /opt/usr/media/tct/

\$ unzip tct-behavior-tests-x.x.x-x.xpk.zip

\$ /opt/usr/media/tct/opt/tct-behavior-tests/inst.sh

On Android:

\$ unzip tct-behavior-tests-x.x.x-x.apk.zip

\$./opt/tct-behavior-tests/inst.sh

6 Preparing To Test

The home page in which all Behavior Test Tool test cases are listed is shown below:




Figure 5-1. Behavior Test Tool Home Page

The header bar shows the Behavior Test Tool title and version.

The test list in the center shows components and the tests for them. When you perform a test, the result status also appears in this area.

The footer bar has buttons for working with the test results:

- Export: Save the test result XML file to the file system. This is default full path that includes both location and file name: /opt/usr/media/Documents/tct-behavior-tests.result.xml.
- Reset: Reset the test results.
- Exit: Quit.

7 Executing Tests

1. Click the Info button to view the test case description, and perform the test according to it.




Figure 6-1. Behavior Test Tool Test Case Info Page

2. Compare the test result with the expected result, then click **Pass** or **Fail** to update the test result on the Home page.

8 Viewing the Report

To generate the result XML at the specific location, click Export. You can view the summary information, including the case title and result.