DietPi SSH access on Windows machine:

1. download putty.exe or install putty Application on windows
   http://www.putty.org/
   https://www.chiark.greenend.org.uk/~sgtatham/putty/latest.html

2. find out the Board IP address :
   From GUI : dietpi.local and check under system settings the IP address or from router find out the IPaddress.



ROON shows the IP address located on same network

3. Open puttye.exe /putty application on windows and login with board IP address. Type the board IP address on putty and open.
   (For example shows IP address 192.168.0.72 , you have to enter your board IP address)





Login as :root

Password : dietpi

On successful login reach to the root@DietPi~#

Now you can type the basic commands as suggested by Support lsusb , lsusb -t , aplay -l , cat /proc/asound/card1/stream0 , ……. fdisk -l , mount …….



Example:

lsusb , lsusb -t on USBridge (Here 0424:2412 id on bus 004 shows USBridge detection)



,lsusb ,lsusb -t , aplay -l command results of USBridge with iFi-nano USB DAC



cat /proc/asound/card1/stream0 command results of USBridge with iFi-nano USB DAC DSD_U32_BE shows the native DSD support on USB dac.



** On Mac OS terminal available by default

On terminal , to access ssh

ssh root@192.168.0.72

password : dietpi