KATANA Player (Dietpi OS)

You have selected Dietpi OS, see below info about it:

https://dietpi.com/phpbb/viewtopic.php?f=8&t=2317&p=8869#p8869

OS download link: http://dietpi.com/downloads/images/DietPi_RPi-ARMv7-Stretch_AlloGUI.7z

Product information and manuals are available http://Allo.com

Please follow these startup steps.

- 1) Connect all RCA cable and accessories to Katana player.
 - -RCA cables to Amplifier (For XLR additional wiring Required)
 - ethernet to router
 - before powering on, check manual for correct sequence.

Power on Unit

Verify Ethernet LEDs status.

2) Find out the IP address of Katana Player from Router or IP scanner or on ROON controller Running on Windows.

Default host name dietpi.

On ROON - list Dietpi, IP address, kernel version, Audio Device as KatanaDAC *by default, KATANA DAC configured on Allo Web GUI.

3) Open web-browser on locally connected PC to configure the Audio Device. dietpi.local or IP address of the player

Allo Web GUI Login E-Mail address: admin@allo.com password : allo




4) Configure Audio Device: System settings ensure ALLO-KATANA DAC configured as Sound card.

SOUNDCARD SELECTION	
SoundCard:	
SoundCard.	allo-katana-dac-audio
	rpi-bcm2835-ultrahq
	rpi-bcm2835-ultrahq-3.5mm
CPU GOVERNOR	allo-boss-dac-pcm512x-audio
	allo-digione
CPU Governor :	allo-katana-dac-audio
	allo-piano-dac-pcm512x-audio
	allo-piano-dac-plus-pcm512x-audio
	usb-dac
	none




5) ROON BRIDGE status check Active.




6) Open ROON server- controller Application


Roon server list the KatanaDAC endpoint available on the same network.



Enable the KatanDAC, Select the AUDIO device, Play the Music



DoP settings.



7) Wi-Fi Enable possible ony through Terminal / SSH login

SSH login on windows refer:

https://github.com/sparkysbc/sparky linux images/blob/master/Dietpi ssh access.pdf

Wi-Fi settings refer

https://github.com/sparkysbc/sparky linux images/blob/master/Dietpi wifi.pdf

SSH terminal command outputs

```
F1: Help x
F2: System information x
Card: Allo Katana
View: F3: [Playback] F4: Capture F5: All
                                                   F6: Select sound card
x Item: Master [dB gain: -7.97, -7.97]
                                                   Esc: Exit
                  laak
                  x
                    ×
                  x
                  tqqu
                         Apodizing Fa
                                     Bypass
                                               lqqk
                                               x00x
                  x00x
                  mqqj
                                               mqqj
                 73<>73
                        DSP Program Deemphasis
                                                DoP
```

Alsamixer settings.

```
oot@DietPi-RPI:~#
root@DietPi-RPI:~#
root@DietPi-RPI:~# aplay -1
**** List of PLAYBACK Hardware Devices ****
card 0: Katana [Allo Katana], device 0: bcm2835-i2s-allo-katana-codec allo-katana-codec-0 []
 Subdevices: 0/1
 Subdevice #0: subdevice #0
root@DietPi-RPI:~# alsamixer
root@DietPi-RPI:~# cat /proc/asound/Katana/pcm0p/sub0/hw params
access: RW_INTERLEAVED
format: S32 LE
subformat: STD
channels: 2
rate: 44100 (44100/1)
period_size: 882
buffer_size: 1764
root@DietPi-RPI:~# cat /proc/asound/Katana/pcm0p/sub0/hw_params
access: RW_INTERLEAVED
format: S32 LE
subformat: STD
channels: 2
period size: 7056
buffer_size: 14112
root@DietPi-RPI:~#
```