## miniBOSS player user manual (RPIzero + miniBOSS)

The Following is the detailed procedural steps to configure volumio on RPIzero + miniBOSS. Preloaded with Volumio OS on microSD card

- **Step 1**: Plug the RCA cables from the miniBoss to your amp make sure volume is on. Plug the power supply to the micro USB connector on the right of the piZero.
- **Step 2**: Wait for about 5 minutes.
- **Step 3**: Using your laptop/tablet or phone, find the Volumio connection in your wifi connections.
- **Step 4**: Connect to Volumio using the password: volumio2
- **Step 5**: After connecting successfully you will be automatically directed to volumio page else Connect to the unit by typing this default IP in your browser: 192.168.211.1 or use <a href="http://volumio.local">http://volumio.local</a>
- **Step 6**: Follow the easy Volumio set up: Select I2S device: BOSS, then configure your network (connect to a wireless) and finally the unit will restart.
- **Step 7**: Listen for the Volumio start up chime, it can take a few minutes.
- Step 8: look for the unit in your router and use the IP to access or <a href="http://volumio.local">http://volumio.local</a>
- Step 9: Set up and enjoy the music!!

Latest Images Download and Flash:

Step 1: Download The latest Volumio - RPI image from the Volumio official website.

<a href="http://updates.volumio.org/pi/volumio/2.389/volumio-2.389-2018-03-26-pi.img.zip">http://updates.volumio.org/pi/volumio/2.389/volumio-2.389-2018-03-26-pi.img.zip</a>

**Step 2**: Load the Downloaded image into an SD card of size preferably 8Gb or more.

Volumio Quick Guide refer: https://volumio.github.io/docs/User Manual/Quick Start Guide.html