

HS4/4S Function

Note: serial call Api calls must be, that is, when the end of an Api, can call an Api, Otherwise it will appear the Api function failure.




Note: the three functions of parallel relationship, there is no order

HS4/4S Function A On-line measurement




A-1: commandMeasureWithUint: andUser: Authentication:Weight: StableWeight: DisposeErrorBlock:

HS4/4S Function B Get offline data



B-1: commandTransferMemorryWithUser:memoryData:DisposeProgress:MemorryData:FinishTransmission:DisposeErrorBlock:

HS4/4S Function C Disconnect Device



C-1: commandDisconnectDevice