
BP7 Function

Note: Api call must be serial call, that is, after the end of a Api, you can call the next Api, otherwise it will appear Api function failure.




Note: the 3 fuctions are parallel relationship, there is no order.

BP7 Function A - Online Measurement Fuction

Note: 1. Api call must be serial call, that is, after the end of a Api, you can call the next Api, otherwise it will appear Api function failure.

2. In the BP7 measurement process, only to receive the stop measurement function (A-3), other Api failure.




A-1: commandStartGetAngleWithUser: clientID:

A-2: commandStartMeasure: xiaoboWithHeart:

A-3: stopBPMeassureErrorBlock: errorBlock:

BP7 Function B - Upload Offline Data


Note: BP7 (B-1) must be called before using the offline measurement function of the Api, otherwise the offline data time may be wrong.



B-1: commandFounction: errorBlock:

B-2: commandBatchUpload: pregress:

BP7 Function C –Querying and Setting Function



C-1: commandFounction: errorBlock:

C-2: commandEnergy: errorBlock:

 $C-3: \ command Set Blue Connect: \ respond:$

C-4: commandSetOffline: errorBlock: