ndt status

what is running, and who has the lab

HOW YOU CALL IT

`ndt status`	what is on the machine right now
`ndt status --check`	compare it against the baseline this lab was brought up with

WHAT ITS EXIT CODE MEANS

0	every compared field matches
1	one of them does not
3	there was no baseline to compare against

THE SHARP EDGE — **with no baseline on disk the whole report is rc 3, not rc 0**