




Time to start the practical lab!

- ▶ Communicate with the board using a serial console
- ▶ Configure, build and install the bootloader stages:
 - *TF-A* and *U-Boot* on STM32MP1 and Beagleplay
 - *U-Boot SPL* and *U-Boot* on BeagleBoneBlack and QEMU
- ▶ Learn *U-Boot* commands
- ▶ Set up *TFTP* communication with the host