



ASoC component controls



- ▶ Controls allow to export configuration knobs of the component to userspace.
- ▶ ASoC provides many helpers to define them instead of filling `struct snd_kcontrol_new`



include/sound/control.h

```
struct snd_kcontrol_new {
    snd_ctl_elem_iface_t iface;      /* interface identifier */
    unsigned int device;             /* device/client number */
    unsigned int subdevice;          /* subdevice (substream) number */
    const char *name;                /* ASCII name of item */
    unsigned int index;              /* index of item */
    unsigned int access;              /* access rights */
    unsigned int count;              /* count of same elements */
    snd_kcontrol_info_t *info;
    snd_kcontrol_get_t *get;
    snd_kcontrol_put_t *put;
    union {
        snd_kcontrol_tlv_rw_t *c;
        const unsigned int *p;
    } tlv;
    unsigned long private_value;
};
```



kcontrol helpers

include/sound/soc.h

```
#define SOC_SINGLE(xname, reg, shift, max, invert)
{
    .iface = SNDRV_CTL_ELEM_IFACE_MIXER, .name = xname,
    .info = snd_soc_info_volsw, .get = snd_soc_get_volsw,
    .put = snd_soc_put_volsw,
    .private_value = SOC_SINGLE_VALUE(reg, shift, max, invert, 0) }

#define SOC_SINGLE_RANGE(xname, xreg, xshift, xmin, xmax, xinvert)
{
    .iface = SNDRV_CTL_ELEM_IFACE_MIXER, .name = (xname),
    .info = snd_soc_info_volsw_range, .get = snd_soc_get_volsw_range,
    .put = snd_soc_put_volsw_range,
    .private_value = (unsigned long)&(struct soc_mixer_control)
        { .reg = xreg, .rreg = xreg, .shift = xshift,
          .rshift = xshift, .min = xmin, .max = xmax,
          .invert = xinvert } }

#define SOC_SINGLE_TLV(xname, reg, shift, max, invert, tlv_array)
{
    .iface = SNDRV_CTL_ELEM_IFACE_MIXER, .name = xname,
    .access = SNDRV_CTL_ELEM_ACCESS_TLV_READ |
        SNDRV_CTL_ELEM_ACCESS_READWRITE,
    .tlv.p = (tlv_array),
    .info = snd_soc_info_volsw, .get = snd_soc_get_volsw,
    .put = snd_soc_put_volsw,
    .private_value = SOC_SINGLE_VALUE(reg, shift, max, invert, 0) }
```



kcontrol examples

sound/soc/codecs/pcm3168a.h

```
#define PCM3168A_DAC_PWR_MST_FMT    0x41
#define PCM3168A_DAC_PSMODA_SHIFT  7
```

sound/soc/codecs/pcm3168a.c

```
SOC_SINGLE("DAC Power-Save Switch", PCM3168A_DAC_PWR_MST_FMT,
           PCM3168A_DAC_PSMODA_SHIFT, 1, 1),
```

- ▶ This exposes a simple on/off switch named “DAC Power-Save Switch” for bit 7 in register 0x41.



kcontrol examples

sound/soc/codecs/pcm3168a.h

```
#define PCM3168A_ADC_MUTE 0x55
```

sound/soc/codecs/pcm3168a.c

```
SOC_DOUBLE("ADC1 Mute Switch", PCM3168A_ADC_MUTE, 0, 1, 1, 0),
```

- ▶ This exposes a Left/Right switch named “ADC1 Mute Switch” for bit 0 (left) and 1 (right) in register 0x55.



kcontrol examples

sound/soc/codecs/sgtl5000.h

```
#define SGTL5000_DAP_MAIN_CHAN 0x0120
```

sound/soc/codecs/sgtl5000.c

```
/* tlv for DAP channels, 0% - 100% - 200% */  
static const DECLARE_TLV_DB_SCALE(dap_volume, 0, 1, 0);  
[...]  
SOC_SINGLE_TLV("DAP Main channel", SGTL5000_DAP_MAIN_CHAN,  
0, 0xffff, 0, dap_volume),
```

- ▶ This a single volume control named “DAP Main channel”. It is controlled by register 0x120 and can take values up to 0xffff.

include/uapi/sound/tlv.h

```
#define SNDRV_CTL_TLVD_DECLARE_DB_SCALE(name, min, step, mute)
```



kcontrol examples

sound/soc/codecs/pcm3168a.h

```
#define PCM3168A_DAC_VOL_MASTER 0x47
```

sound/soc/codecs/pcm3168a.c

```
/* -100db to 0db, register values 0-54 cause mute */
static const DECLARE_TLV_DB_SCALE(pcm3168a_dac_tlv, -10050, 50, 1);
[...]
SOC_SINGLE_RANGE_TLV("Master Playback Volume",
                     PCM3168A_DAC_VOL_MASTER, 0, 54, 255, 0,
                     pcm3168a_dac_tlv),
```

- ▶ This is a single volume control named “Master Playback Volume”. It is controlled by register 0x47 and can take values 54 to 255. The datasheet states that 0 to 54 is mute.



kcontrol examples

sound/soc/codecs/pcm3168a.h

```
#define PCM3168A_DAC_VOL_CHAN_START 0x48
```

sound/soc/codecs/pcm3168a.c

```
/* -100db to 0db, register values 0-54 cause mute */
static const DECLARE_TLV_DB_SCALE(pcm3168a_dac_tlv, -10050, 50, 1);
[...]
SOC_DOUBLE_R_RANGE_TLV("DAC1 Playback Volume",
                        PCM3168A_DAC_VOL_CHAN_START,
                        PCM3168A_DAC_VOL_CHAN_START + 1,
                        0, 54, 255, 0, pcm3168a_dac_tlv),
```

- ▶ This a Left/Right volume control named “DAC1 Playback Volume”. Left is controlled by register 0x48, right channel is in register 0x49 and both can take values 54 to 255. The datasheet states that 0 to 54 is mute.



kcontrol examples

sound/soc/codecs/pcm3168a.h

```
#define PCM3168A_DAC_ATT_DEMP_ZF      0x46
#define PCM3168A_DAC_DEMP_SHIFT      4
```

sound/soc/codecs/pcm3168a.c

```
static const char *const pcm3168a_demp[] = {
    "Disabled", "48khz", "44.1khz", "32khz" };

static SOC_ENUM_SINGLE_DECL(pcm3168a_dac_demp, PCM3168A_DAC_ATT_DEMP_ZF,
    PCM3168A_DAC_DEMP_SHIFT, pcm3168a_demp);

[...]
```

```
    SOC_ENUM("DAC De-Emphasis", pcm3168a_dac_demp),
```

- ▶ This creates a control named “DAC De-Emphasis”. Allowing to choose between four different values. This is controlled in register 0x46, bits 4 and 5.



kcontrol examples

sound/soc/codecs/sgtl5000.h

```
#define SGT5000_DAP_AVC_THRESHOLD 0x0126
```

sound/soc/codecs/sgtl5000.c

```
static int avc_get_threshold(struct snd_kcontrol *kcontrol,  
                             struct snd_ctl_elem_value *ucontrol)  
  
[...]  
static const DECLARE_TLV_DB_MINMAX(avc_threshold, 0, 9600);  
[...]  
SOC_SINGLE_EXT_TLV("AVC Threshold Volume", SGT5000_DAP_AVC_THRESHOLD,  
                    0, 96, 0, avc_get_threshold, avc_put_threshold,  
                    avc_threshold),
```

- ▶ This a single volume control named “AVC Threshold Volume”.



kcontrol names

- ▶ Naming actually matters, userspace tools use them to populate the user interface properly!
- ▶ Controls named similarly will be grouped together:
 - “Playback” and “Capture” controls may be exposed separately in the UI
 - “Mute Switch” and “Volume” for a similarly named controls can be shown as a single control
- ▶ Master Playback Switch
- ▶ Master Playback Volume
- ▶ Headphone Mic Boost Volume
- ▶ Capture Volume

10