# [Guide] airport\_pcie-hm\_plist\_edits.pdf

## Requirements

1. 10.8.5 or newer (This technique does not work in 10.8.4 or earlier)

#### **Tools**

- 1. IORegistryExplorer, IOJones
- 2. Property list editor Xcode, Property List Editor, Plist Editor, or TextEdit
- 3. Kext installer KextBeast, Kext Utility, DPCIManager

#### I. Broadcom

- 1. Backup S/L/E/IO80211Family.kext
- 2. Copy S/L/E/IO80211Family.kext to Desktop
- 3. Property List Editor/Open/Desktop/IO80211Family.kext/Contents/Plugins/AirPortBrcm4360.kext/Contents/Info.plist
- 4. Open IOKitPersonalities
- 5. Open Broadcom 802.11 PCI
- 6. Open IONameMatch
- 7. find: <string>pci14e4,4353</string> Native
- 8. add: <string>pci14e4,4357</string> For BCM943225 HMB
- or add: <string>pci14e4,43b1</string> For BCM94352 HMB
- 9. Save
- 10. Run kext installer

Note: 8. add means:

- 1. Copy Item 2
- 2. Paste Item 2 on IONameMatch
- 3. Edit the new item 0, from 4353 to 4357

## See **Example** screenshots below

#### II. Atheros

- 1. Backup S/L/E/IO80211Family.kext
- 2. Copy S/L/E/IO80211Family.kext to Desktop
- 3. Property List Editor/Open/Desktop/IO80211Family.kext/Contents/Plugins/AirPortAtheros40.kext/Contents/Info.plist
- 4. Open IOKitPersonalities
- 5. Open Atheros Wireless LAN PCI
- 6. Open IONameMatch
- 7. find: <string>pci168c,2a</string> Native
- 8. add: <string>pci168c,2b</string> For AR9285
- or add: <string>pci168c,2e</string> For AR9287
- 9. Save
- 10. Run kext installer

Note: 8. add means:

- 1. Copy Item 2
- 2. Paste Item 2 on IONameMatch
- 3. Edit the new item 0, from 2a to 2b


See **Example** screenshots below

## **Configuration/Troubleshooting**


See [Guide] airport\_pcie-hm\_details.pdf

## **Example**


Property List Editor/Open/S/L/E/IO80211Family.kext/Contents/Plugins/AirPortBrcm4360.kext/Contents/Info.plist



Step 6 (before edit)



# Step 8 (after edit)



[Guide] airport\_pcie-hm\_plist\_edits\_v1.0