[Guide] airport_pcie-hm_plist_edits.pdf



Requirements

1. 10.8.5 or newer (This technique does not work in 10.8.4 or earlier)

Tools

- 1. IORegistryExplorer, IOJones
- 2. Property list editor Xcode, Property List Editor, Plist Editor, or TextEdit
- 3. Kext installer KextBeast, Kext Utility, DPCIManager

I. Broadcom WiFi

A. Determine WiFi Card Device_ID

- 1. Download, install and run DPCIManager 1.5 Open Beta
- 2. Find Vendor-ID 14E4 (Broadcom) or 168E (Atheros) in DPCIManager/PCI
- 3. Note Device_ID and verify with supported Device_IDs above.
- 4. Vendor/Device ID is 14E4/4357; BCM943225

B. Edit Info.plist

- 1. Backup S/L/E/IO80211Family.kext
- 2. Copy S/L/E/IO80211Family.kext to Desktop
- 3. Property List Editor/Open/Desktop/IO80211Family.kext/Contents/Plugins/AirPortBrcm4360.kext/Contents/Info.plist
- 4. Open IOKitPersonalities
- 5. Open Broadcom 802.11 PCI
- 6. Open IONameMatch
- 7. find: <string>pci14e4,43a0</string> Native
- 8. add: <string>pci14e4,4353</string> For BCM943224 HMS
- 9. add: <string>pci14e4,4357</string> For BCM943225 HMB
- or add: <string>pci14e4,43b1</string> For BCM94352 HMB
- 10. Save
- 11. Run kext installer

Note: 8. add means:

- 1. Copy Item 2
- 2. Paste Item 2 on IONameMatch

3. Edit the new item 0, from 43a0 to 4353

See **Example** screenshots below

II. Broadcom BT

A. Determine WiFi Card/Bluetooth ProductID/VendorID

- 1. System Information/Hardware/USB
- 2. Select ".. Bluetooth..."/BCM207020A
- 3. Note: ProductID/Convert hex to decimal/Ex. 0x217d = decimal 8573
- 4. Note: VendorID/Convert hex to decimal/Ex. 0x0a5c = decimal 2652 (Broadcom)

B. Edit Info.plist

- 1. Backup S/L/E/IOBluetoothFamily.kext
- 2. Copy S/L/E/IOBluetoothFamily.kext to Desktop
- 3, Property List Editor/Open/Desktop/IOBluetoothFamily/Contents/Plugins/BroadcomBluetoothHostControllerUSBTransport/Contents/Info.plist
- 4. Open IOKitPersonalities
- 5. Open BroadcomUSBBluetoothHCIController MediaLink BT4.0 Adapter

III. Atheros WiFi

A. Determine WiFi Card Device_ID

- 1. Download, install and run DPCIManager 1.5 Open Beta
- 2. Find Vendor-ID 168E (Atheros) in DPCIManager/PCI
- 3. Note Device_ID and verify with supported Device_IDs above.
- 4. Vendor/Device ID is 168E/2B; AR9285

B. Edit Info.plist

- 1. Backup S/L/E/IO80211Family.kext
- 2. Copy S/L/E/IO80211Family.kext to Desktop
- 3. Property List Editor/Open/Desktop/IO80211Family.kext/Contents/Plugins/AirPortAtheros40.kext/Contents/Info.plist
- 4. Open IOKitPersonalities
- 5. Open Atheros Wireless LAN PCI
- 6. Open IONameMatch
- 7. find: <string>pci168c,2a</string> Native
- 8. add: <string>pci168c,2b</string> For AR9285
- or add: <string>pci168c,2e</string> For AR9287
- 9. Save
- 10. Run kext installer

Note: 8. add means:

- 1. Copy Item 2
- 2. Paste Item 2 on IONameMatch
- 3. Edit the new item 0, from 2a to 2b

See **Example** screenshots below

III. Atheros BT


- 1. Atheros BT is not supported natively, search IOath3kfrmwr
- 2. Native Broadcom BT support: GMYLE Micro USB Bluetooth 4.0 Dongle Dual Mode Wireless Adapter | GMYLE

Configuration/Troubleshooting


See [Guide] airport_pcie-hm_details.pdf

Example


Property List Editor/Open/S/L/E/IO80211Family.kext/Contents/Plugins/AirPortBrcm4360.kext/Contents/Info.plist



Step 6 (before edit)



Step 8 (after edit)



[Guide] airport_pcie-hm_plist_edits_v1.0