0.1 Space Vector Pulse Width Modulation

Space Vector PWM has several advantages over Sine PWM

- Higher voltage utilization: SVPWM can utilize up to 15% more DC bus voltage compared to SPWM. This means for the same DC supply voltage, an inverter with SVPWM can provide a higher output voltage.
- Better harmonic performance: SVPWM results in lower total harmonic distortion (THD) compared to SPWM. This leads to a better quality of the output voltage and current waveforms, which is particularly important in applications like drives where harmonics can cause heating and torque pulsations.
- Reduced switching losses: SVPWM requires fewer switching operations for the inverter switches compared to SPWM. This results in lower switching losses, leading to higher efficiency and reduced heating of the inverter switches.
- Improved dynamic response: The space vector representation used in SVPWM allows for a more precise control of the output voltage vector, leading to an improved dynamic response. This is particularly beneficial in applications like motor drives where a fast dynamic response is required.
- Vector control capability: SVPWM allows for vector control of the output voltage, which is not possible with SPWM. This enables more complex control strategies, such as field-oriented control (FOC), which can provide better performance in applications like motor drives.
- Flexibility: SVPWM allows for flexible control of the output voltage magnitude and frequency, as well as the phase relationship

between the output voltage and current. This flexibility makes it suitable for a wide range of applications.

0.1.1 Generation of Space Vector PWM with C2000 microcontroller

To generate space vector PWM wave for the switches C2000 series microcontroller offers a hardware level module called ePWM or enhanced PWM module. It enables to generate PWM waves with high flexibility.

To generate symmetrical waveform, the ePWM's internal timer is configured in up-down count mode.

PWM Frequency Calculation

Variable Definitions

Symbol	Description
F_{PWM} and T_{PWM}	Frequency of PWM and Time period of PWM
T_{TBCLK}	Time base clock
TBPRD	ePWM Time period
EPWMCLK	ePWM clock derived from a 200 MHz system clock
HSPCLKDIV	High speed clock divider
CLKDIV	Clock prescaler

The period of the PWM signal can be calculated using the formula:

$$T_{\mathrm{PWM}} = 2 \times TBPRD \times T_{\mathrm{TBCLK}}$$

where TBPRD is the time base period.

0.2 PWM Frequency (F_{PWM})

The frequency of the PWM signal is defined as the inverse of the PWM period:

$$F_{\rm PWM} = \frac{1}{T_{\rm PWM}}$$

0.3 Time Base Clock (T_{TBCLK})

The time base clock is given by:

$$T_{\mathrm{TBCLK}} = \frac{\mathrm{EPWMCLK}}{\mathrm{HSPCLKDIV} \times \mathrm{CLKDIV}}$$

- EPWMCLK is the clock frequency dedicated to the PWM module.
- HSPCLKDIV and CLKDIV are the dividers for the high-speed PWM clock.

According to the FSAM20SH60A datasheet, a 15 kHz carrier wave is recommended for optimal performance. The dividers HSPCLKDIV and CLKDIV are both set to 1. Given that the EPWMCLK is derived from the system clock (SYSCLK) which operates at 200 MHz, the time base clock can be calculated as follows:

$$T_{\text{TBCLK}} = \frac{200 \times 10^6}{1 \times 1} = 200 \times 10^6 \text{ Hz}$$

Figure 0.1 below shows the ePWM block in Simulink, which is used to simulate the PWM control scheme.



Figure 0.1: ePWM block in Simulink

Chapter 1

Conclusion