

ECE 471C-Wireless Communications Lab

PreLab1.1

Zhaojing Fu

Hi guys, this is a guidance for lab1.1. There are some LabVIEW files that are distributed to you.

digital_comm, control_type_defs – these two are some subVIs needed for simulation, probably something wrong with them if there are errors showing missing VIs;

awgn_simple_sim – this is the simulator you will use to test the 2 VIs you write and get the BER data;

student_error_detect, student_source – these are templates you need to fill, with inputs and outputs already defined, you will need to figure out the intervening process to realize the functionality.

Some quick notes:

It is highly recommended that you enable the help context by clicking the topright corner "?" icon in the block diagram to help you identify different parts.

After finishing the 2 VIs, namely source.vi and error_detect.vi, you can open the simulator provided, right click in the block diagram and select "select a VI" to call the VIs you have written. But it is always better to check the function of your own VIs first before playing around with the whole link in the simulator.

Please do read the lab manual, there are some detailed instructions and requirements mentioned.