

FOR SOUND ENGINEERS AND DJS

Setting up the Casting window

This guide walks you through the Casting window step by step — whether you're a speaker with a microphone, or a DJ playing music from your Mac. No previous experience needed.

1. Log in

Go to **app.adience.no/cast**. Enter the venue's **Stream ID** and **cast password** (found under Media on My page), and press Unlock.

2. Choose the right source

Under "Source", pick where the sound is actually coming from.

- **Speaker with a microphone:** pick your microphone from the list (e.g. your audio interface).
- **DJ playing music from your Mac:** you'll need a small free app called VB-Cable. It pretends to be a microphone, but instead captures everything played on your Mac. Set your Mac's audio output to VB-Cable, then select "VB-Cable" as the source here.

3. Hear myself

This toggle decides whether you hear yourself in your headphones while broadcasting.

- **Real microphone:** leave it ON.
- **VB-Cable/music:** turn it OFF. Leave it on with VB-Cable and you'll get a howling feedback loop — the sound plays right back into itself.

4. Mono or stereo

- **Microphone (voice):** choose Mono.
- **Music (Spotify etc.):** choose Stereo to keep the full musical width.

5. EQ preset

- **Voice** — for speech and commentary.
- **Music** — for music.
- **Plain** — unaltered sound, no adjustment.

6. Check the level

The meter below shows how strong the signal is.

- **Barely moving:** too weak — turn it up.
- **Stuck in the red:** too strong — turn it down.
- **Moves steadily without hitting the ceiling:** perfect.

7. Start and stop broadcasting

Press **Start sending** when you're ready. The status shows SHOWTIME when you're actually live. Press **Stop sending** when you're done — no cleanup needed.



Use a wired connection if you can! Wi-Fi in a room full of phones can make the sound choppy — a cable gives the smoothest broadcast.

8. Common problems

- **Howling/feedback:** turn off "Hear myself".
- **No sound at all:** check you've actually picked the right source — some devices in the list are empty and carry nothing.
- **Stuttering/choppy:** check your network connection, wired if possible.