K5BMC EI DO's & DON'Ts

DO's

- Provide a protective cap for optical connector when it is not used.
- Switch OFF the power, before replacing the card.
- Clean the connecter surface while opening or removing an optical cable.
- Ensure proper polarity before connecting a power cable.
- Ensure all terminations are fully tightened.
- Ensure that Maintenance Console is kept always in ON condition.
- Ensure the insertion of cards in the correct slots.
- Grip the front panel with both hands while replacing the cards.
- Keep the El room free from dust.
- Maintain the rated power supply at the K5BMC power modules.
- Make sure that no cable/ wire/ patch cord is connected to the card before replacing the card.
- Check SPD periodically for health indication status.

DON'Ts

- **ODE :** Don't attempt troubleshooting, if you do not have proper K5BMC training.
- Don't bend an optical fibre with a radius of less than rated value.
- Don't remove the IC card while the system is operating.
- Don't remove any protective cover.
- Don't replace the power supply unit while the main power switch is turn ON.
- Don't touch or alter the Dip switch position in the logic module.
- Don't touch the contacts of the IC card while handling.
- Don't touch the internal wiring of the rack of card or power cable.
- Don't touch the tip of an optical connector.
- Don't turn ON/ OFF the power switch without following proper sequence.
- Don't use removable media/ USB/ DVD/ CD in Operator/ Maintenance Console.
- Don't use Radio equipment/ mobile phone when El Rack door is in open condition.