


Lec 3 - Linear Time Invariant (LTI) Systems

- > System: Something that has an input & an output.
- > linear: $f(ax+by) = af(x)+bf(y)$ from Lec 2.
- > Time invariant: $y(t) = f(x(t)) \Rightarrow y(t-\tau) = f(x(t-\tau))$.
- > We model complex circuits as LTI systems because the analysis tools we have (linear algebra, Fourier Transforms etc.) only work for LTI systems.
- > In circuits the inputs to the system are sources and outputs are voltages and/or currents somewhere. A circuit is LTI if it has linear elements (resistors, inductors, capacitors, dep. sources) & their values are fixed in time.

Ex:



- > Given an LTI system we want to study how to find $y(t)$ for a particular $x(t)$. There are different analysis techniques for different classes of inputs & they are all closely related.
- > Classes of inputs $x(t)$
 - Impulse function (Dirac Delta fn.) $\delta(t)$
 - ↳ Impulse Response.
 - Step function
 - ↳ Step Response.
 - Sinusoidal functions ($\sin x, \cos x$)
 - ↳ Frequency Response (Fourier Transform)
 - Decaying/Growing Sinusoidal functions ($e^x \sin x, e^x \cos x$) & other general functions.
 - ↳ Complex Frequency Response (Laplace Transform).

(11)

Impulse Response


- Dirac Delta function

$$\delta(t) = \begin{cases} 0 & t \neq 0 \\ \text{undefined} & t = 0 \end{cases}$$

Such that $\int_{-\infty}^{\infty} \delta(t) dt = 1$

It can be constructed from a pulse function of area = 1
as the width $\rightarrow 0$ in the limit.

$$\delta(t) = \lim_{\Delta \rightarrow 0} \left(\frac{1}{\Delta} \cdot P_\Delta(t) \right) \text{ where } P_\Delta(t) = \begin{cases} 0 & t < 0 \\ 1 & 0 \leq t \leq \Delta \\ 0 & t > \Delta \end{cases}$$




> Why is $\delta(t)$ useful? \rightarrow Sifting Property!

Sifting Property

"Sifting" → Extracting → $\delta(t)$ extracts the value of a function at time t .


$$\int_{-\infty}^{\infty} f(t') \delta(t' - t) dt' = f(t).$$



The integral only fires when $t' = t$ because of $\delta(t' - t)$.

> Another way to look at this is as if $\delta(t)$ is "building" the function.


$$f(t) = \int_{-\infty}^{\infty} f(\tau) \delta(t - \tau) d\tau$$



Each δ is scaled by $f(\tau)$ & then added up to make the function.

> Both the "sifting" & "building" viewpoints are equivalent
x useful in different ways.

LTI Systems (Impulse Response)



Impulse Response: Response $y(t)$ of a system when the input is an impulse ($x(t) = \delta(t)$).

$$y(t) = H(x(t))$$

$$\Rightarrow h(t) = H(\delta(t)) \rightarrow \text{impulse response.}$$

Time invariance \Rightarrow ~~$h(t-\tau) = H(\delta(t-\tau))$~~

$$\text{Since } x(t) = \int_{-\infty}^{\infty} x(\tau) \delta(t-\tau) d\tau$$

$$\Rightarrow y(t) = H \left(\int_{-\infty}^{\infty} x(\tau) \delta(t-\tau) d\tau \right)$$

Linearity \Rightarrow H can be taken inside the integral.


$$\Rightarrow y(t) = \int_{-\infty}^{\infty} x(\tau) H(\delta(t-\tau)) d\tau$$

$\begin{cases} H \text{ only acts on} \\ t - \tau \text{ is a constant.} \end{cases}$

$$y(t) = \int_{-\infty}^{\infty} x(\tau) h(t-\tau) d\tau$$

\rightarrow Convolution.

What is convolution saying.



- > For a $\delta(t)$ input I have some response $\rightarrow h(t)$.
- > I can break up my input $x(t)$ in scaled & shifted deltas, find the response to each of them & then add them back up to get the response $y(t)$

$$y(t) = \int_{-\infty}^{\infty} u(\tau) h(t - \tau) d\tau$$

$\uparrow \quad \uparrow$
 $\text{add} \quad \text{Scaled} \quad \text{Shifted}$


$$y(t) = u(t) * h(t)$$

- > For an LTI system the impulse response fully characterizes the system. From $h(t)$ you can find the response to any arbitrary input.

Step Response

- Step Function


$$u(t) = \begin{cases} 0 & t < 0 \\ \text{undefined} & t = 0 \\ 1 & t > 0 \end{cases}$$



Note: $u(t) = \int_{-\infty}^t \delta(t) dt \Rightarrow \delta(t) = \frac{du(t)}{dt}$

- > Step response also fully characterizes a system. In
- circuits it is useful in analyzing "switched" systems.

Example (LPF)



$$\text{kVL} \Rightarrow -V_s + iR + V_o = 0$$

$$\Rightarrow i = \frac{V_s - V_o}{R} = C \frac{dV_o}{dt}$$

$$\Rightarrow \boxed{\frac{dV_o}{dt} + \frac{V_o}{RC} = \frac{V_s}{RC}} \rightarrow \text{ODE of order 1.}$$

Solution is $V_o(t) = Ae^{kt} + B \rightarrow \text{Ansatz}$

$$\Rightarrow Ak e^{kt} + \frac{A}{RC} e^{kt} + \frac{B}{RC} = \frac{u(t)}{RC} \xrightarrow{\substack{V_s(t) = 1V \text{ for } t > 0 \\ \text{Eq. } \textcircled{A}}} \textcircled{A}$$

Assume $V_o(t=0) = 0 \Rightarrow$ uncharged capacitor.


$$\Rightarrow V_o(t=0) = A + B = 0 \Rightarrow A = -B.$$

> For $t > 0$, $u(t) = 1 \Rightarrow B = 1$ Since Eq. \textcircled{A} must be true for all t .

> Also $Ak + \frac{A}{RC} = 0$ for the same reason.

$$\Rightarrow k = -\frac{1}{RC}$$

$$\Rightarrow V_o(t) = 1 - e^{\frac{-t}{RC}} \quad \begin{matrix} \text{Time} \\ \text{constant} \\ \tau \end{matrix}$$



Procedure for solving in time-domain

- 1) Use KVL, KCL (nodal or mesh analysis).
- 2) Find ODE for desired output.
- 3) Solve using Ansatz.

> Solving ODEs in time domain is painful, especially when sinusoidal inputs are used & the circuits are more complex. So we prefer to work in the complex frequency domain \rightarrow Laplace Transform.