1. **Manual Pulser Section:**
    - Features a debounced push-button mechanism. When pressed and released, it generates a single clean logic transition.
    - It must provide two independent output terminals: a **Rising Edge / Positive-Going Pulse output** (which stays LOW and transitions HIGH on button press, or provides a clean positive clock edge) and a **Falling Edge / Negative-Going Pulse output** (which stays HIGH and transitions LOW when pressed, or provides a clean negative clock edge) to facilitate testing of edge-triggered sequential ICs (like Flip-Flops and Counters).
2. **Automatic Clock Section:**
    - Features a continuous square-wave oscillator whose frequency/speed is adjustable via a rotary knob (potentiometer control).
    - Like the manual section, it must provide simultaneous, synchronized continuous square wave outputs for both **Rising-Edge** and **Falling-Edge** tracking across adjustable frequencies (ranging from low Hz for visual LED observation up to higher kHz ranges)."