BSR mode Programs

7	6	5	y	3	2	1	0
1	X	×	Х	22.	\$	0	1

7th bit = 0 for BSR mode un defined 6th but, 5th but and 4th but = make o 3rd | 2nd | 1st 0 - Rese 0 0 - PC4 - PC3 O I - PC,

are Write BSR control word subsoutine to set bits PC, and PCs and reset them after loms. Use diagram given below for Port address.

1 Identify port address
2 Identify the content of control regaster
3 then program for given statement.

