Conex_Magellan: Programming Barcodes for DS4308

Configuration name in Utility :	Conex_Magellan
Last Modified :	26-jul-17
Windows Filename :	Config
Plug-in Name :	File_DS4308_Conex_Magellan_2017.07.26.scncfg
Report Type :	DS4308-COMMON SR MODELS-010
	Only parameters changed from defaults shown

Barcodes 1 of 2

Conex_Magellan: Programming Barcodes for DS4308

Configuration name in Utility :	Conex_Magellan
Last Modified :	26-jul-17
Windows Filename :	Config
Plug-in Name :	File_DS4308_Conex_Magellan_2017.07.26.scncfg
Report Type :	DS4308-COMMON SR MODELS-010
	Only parameters changed from defaults shown



Barcodes 2 of 2

Conex_Magellan: Programming Barcodes for DS4308

Configuration name in Utility :	Conex_Magellan
Last Modified :	26-jul-17
Windows Filename :	Config
Plug-in Name :	File_DS4308_Conex_Magellan_2017.07.26.scncfg
Report Type :	DS4308-COMMON SR MODELS-010
	Only parameters changed from defaults shown





Set Factory Defaults

Cable Connection Settings

USB

USB Device Type	IBM Table Top USB

Single RS232C

RS232 Host Types	Standard Host
Stop Bits	Two Stop Bits
Hardware Handshaking	RTS/CTS Option 1

Modify Data - Advanced Data Formatting

Erase All Rules

Begin New Rule

QR Code

1. Send ASCII Key <P>

2. Send All that remains

Save Rule

Begin New Rule

Code 39

1. Send ASCII Key <*>

2. Send ASCII Key <*>

Conex_Magellan: Programming Barcodes for DS4308

Configuration name in Utility : Conex_Magellan
Last Modified : 26-jul-17
Windows Filename : Config
Plug-in Name : File_DS4308_Conex_Magellan_2017.07.26.scncfg
Report Type : DS4308-COMMON SR MODELS-010
Only parameters changed from defaults shown





3. Send All that remains

Save Rule

Begin New Rule

Code 93

1. Send ASCII Key <&>

2. Send All that remains

Save Rule

Begin New Rule

PDF417

1. Send ASCII Key <P>

2. Send All that remains

Save Rule

Begin New Rule

Interleaved 2 of 5

1. Send ASCII Key <i>

2. Send All that remains

Save Rule

Begin New Rule

Code 128

1. Send ASCII Key <#>

2. Send All that remains

Conex_Magellan: Programming Barcodes for DS4308

Configuration name in Utility :	Conex_Magellan
Last Modified :	26-jul-17
Windows Filename :	Config
Plug-in Name :	File_DS4308_Conex_Magellan_2017.07.26.scncfg
Report Type :	DS4308-COMMON SR MODELS-010
	Only parameters changed from defaults shown





Save Rule

Begin New Rule

EAN-8

1. Send ASCII Key <F>

2. Send ASCII Key <F>

3. Send All that remains

Save Rule

Begin New Rule

EAN-13

1. Send ASCII Key <F>

2. Send All that remains

Save Rule

Begin New Rule

UPC–E

1. Send ASCII Key <E>

2. Send All that remains

Save Rule

Begin New Rule

UPC–A

1. Send ASCII Key <A>

2. Send All that remains

Conex_Magellan: Programming Barcodes for DS4308

Configuration name in Utility :	Conex_Magellan
Last Modified :	26-jul-17
Windows Filename :	Config
Plug-in Name :	File_DS4308_Conex_Magellan_2017.07.26.scncfg
Report Type :	DS4308-COMMON SR MODELS-010
	Only parameters changed from defaults shown





Save Rule

General Parameter Settings

Configuration File	Conex_Magellan

Notes:

DS4308 Conexion magellan

Firmware:

CAACES00-002-R03

Supported Scanner Models for Plug-in :

DS4308-HD00007ZCAP

DS4308-HD00007ZCWW

DS4308-HD00007ZZAP

DS4308-HD00007ZZWW

DS4308-SR00006ZZAP

DS4308-SR00006ZZWW

DS4308-SR00007PCAP

DS4308-SR00007PCWW

DS4308-SR00007PZAP

DS4308-SR00007PZWW

DS4308-SR00007PZY

DS4308-SR00007ZZAP

DS4308-SR00007ZZWW

DS4308-SR00007ZZY