

ELASTOMERIC BEARING – INSTALLATION METHODOLOGY

Proper installation ensures long service life, load transfer and optimal performance.

1 Preparation of Bearing Seat



Clean the bearing seat surface from dust, debris, oil and loose particles. Ensure the surface is level and properly aligned.

2 Placement of Elastomeric Bearing



Place the elastomeric bearing in the exact position as per drawing and alignment marks.

3 Fixing with Anchor Bolts (If Required)



Install anchor bolts and tighten with specified torque as per design requirements.

4 Casting of Grout



Fill the gaps with non-shrink grout to ensure full bearing support and proper load transfer.

5 Final Installation



After curing, check alignment, level and proper seating of the bearing. Installation is complete.



Well Installed Bearings
= Safe & Durable Bridge

ELASTOMERIC BEARING – MAINTENANCE METHODOLOGY

Regular inspection and simple maintenance keep the bearings performing for decades.

1 Visual Inspection



- Check for cracks, cuts, bulging or deformations.
- Check for water ingress, corrosion or loose parts.

2 Cleaning



Remove dust, dirt, debris, foreign material and corrosion from bearing surfaces and surrounding area.

3 Check Alignment & Movement



Ensure proper alignment, no rotation, and free movement as per design (allowable displacement).

4 Re-Tightening of Bolts (If Required)



Check and re-tighten anchor bolts to the specified torque values.

5 Grout & Paint Repair



Repair any damaged grout and apply protective coating (approved epoxy/paint) as per specification.

6 Documentation



MAINTENANCE CHECKLIST

- ☒ Visual Check
- ☒ Cleaning
- ☒ Alignment
- ☒ Bolts Tightness
- ☒ Grout / Paint
- ☒ Remarks

Record inspection details, remarks and corrective actions in the maintenance logbook.



Longer Service Life



Better Performance



Safety & Reliability



Stronger Infrastructure

Designed by **TAUSIFKHAN PATHAN**
Mobile No. : 8657323278