USB INSIGHT HUB - INTERFACE - ASSEMBLY TOP GND 3V3 SDA SCL Display 1 Display 2 Display 3 SW5 IO ærio Bot RT Rx Tx GNL SW2 SW3 SW4 CH3 CH1 CH2 ESP32 PR06 GND 3V3 SDA SCL Display 1 Display 3 Display 2 103 102 3V3 IO ærio IND 🖺 Bot RT Rx Tx GND ESP32 PR06 ver. C0-1 dat. 27/11/24

