## Binding the Receiver to the Transmitter:

- 1. Hold down the white button on back of transmitter.
- 2. Turn on the remote control.
- 3. Once the remote is beeping, release the button.
- 4. Push and hold the failsafe (F/S) button on the receiver.
- 5. Connect the USB cable.
- 6. Release button once LED is flashing red/ green.
- 7. Disconnect the USB cable.
- 8. Turn off the remote control.

Your Receiver is Now Bound to the Transmitter.

## Setting the Failsafe:

- 1. With the remote control turned off, connect the USB cable.
- 2. Press and release the F/S button on the receiver.
- 3. The red/green LEDs should now be flashing.
- 4. Disconnect the USB cable.
- 5. Turn on the remote control.
- 6. Plug in the USB.
- 7. LED should now display solid green.

Your Remote Control Setup is Completed.