




ERONT BACK
Letsmake
This Mins!





#1:USB (6N)
+1,1 prd
+1,1 prd
-4,2 mc 161+
011.

Then
CAREFULLY
Outerest.



Councition ity 1+ This


Point After This, it

15 hard to fix


Diodesare
Next. Neyme


Small and go

Here symbol Gostpint.




Next up: 68Ω Resistors
And 1.6k & Resistor
68Ω=1166=111





Testled




Corgrent Justice

Last 0805! Cerpneitor time

goeshere. Notpolarized. Time for Chip! Do+->Pin#1

All PONEL, Optional: Header Pins



Needed: Firmune Programming commands:

\$: sudo avrdude -c

avrispmkii -P usb -p

attiny45 -U

flash:w:vusbtiny.hex

Set fuses with:

Sudo avrdude -c avrispmkii

-P usb -p attiny45 -U

Ifuse:w:0xe1:m -U


hfuse:w:0x5d:m -U

efuse:w:0xff:m

That Should be it-! It should LSUSB/ enmemters:

046d:c52b Logitech, Inc. Unifying 1781:0c9f Multiple Vendors USBtiny 413c:8187 Dell Computer Corp. DW375 0a5c:5800 Broadcom Corp. BCM5880





excellent Quality Boards. FAST, USA!