


Ist Block (all climension one in mm).

Date
Expt. No Page No
9 10 10 10 1
Practical No. 01
The state of the s
Aim' To make a wooden block (T-fitting)
The state of the s
- Tools Required!
1 Saul
2. Engineering Scale.
3. Mallet
4. Inon. jack plane.
s. Tru - Squape,
s. Try - Square, 6. Rasp.
7. Mortise Chisel.
Thurse crasu.
- material Required! A wooden block.
requires. In wooder ower
- Seguence at Marchanet
Sequence of Openations!
Gutting a dividing into two parts.
Filing.
checking flatness and Squaneness.
marking & meanswring.
sawing.
Sawing. Chipping.
TITIS DIDO.
· Filting the blocks.
Teacher's Signature:



	Date
Expt	No. Page No
step	Procedure! Brocedure! Broced
	. Cut the piece into two parts according to the measurement and cheek the dimensions with Engineering scale and cheek for its edges using try square.
stęp:	Take first wooden block of dimension 13 oxygrus, and mark its size to convent it into T shape.
step4	cut the piece into T-shape using saw According to the dimensions measured.
step 5	Take Another piece and marik the measurement on it
step 6	Remove the unwanted portion using mortise chisel 8 mallet and make a rectangular hole. and binish its inner side using Rosp.
Step	Fil the Ist block into I nd block and make sure size would be accumate.

Teacher's Signature:

Da	ate
Expt. No. — Page N	lo.
Annual Control of the	
- Result! T- fit is mode as per the Required dimensons.	e
- Prevautions!	
· Cane is taken to see that the models are not crossed, which is by Pencil or Chalk.	viking indicated
· Apply Pressure in forward direction	
Don't rub steel rule (scale) on wooden piece.	the
· Files one to be cleaned properly a	fкл
with II'd one with a high pressurit may broken.	o adjust ur l
Teacher's Signature	2