

1 Posting Functions in the Tool and Resource Management

If the tool and resource management is active, the buttons *Maintenances*, *Enter resource comment* and *Change resource status* are available in the area of the resources logged on.

1.1. Operation logon with resources

An operation is logged on by clicking the “log OP on” button. In addition to the selected OP, a list also shows the assigned production resources and tools.

The following requirements have to be met to have the required resources displayed in the list of production resources and tools as well.

The option “display material/PRT list when logging OP on” has to be enabled in the workplace/machine configuration.

The assigned resource has to be configured with the “explicit logon” or “required resource” option within the resource stock.

Posting procedure

A workplace has to be selected before the operation is logged on. Thus, the workplace is already defined, when the dialog is opened.

Starting of the “log operation on” function

The “log operation on” button is to be clicked. The user is navigated through the posting dialog as soon as the function has been started. Subject to the workplace configuration, the “log operation on” dialog is now started either including batch posting or without.

Select operation

Selection from the existing list or manual entry.

Batch

AIP automatically generates the batch. Input is not required/possible.

Status

Select the status from the list or enter it manually.

Batch/resource

The batch or resource number to be logged on can be entered here. This production resource and tool is logged on by clicking the “report batch” button.

Resources, which have already been logged on, are highlighted in green in the list, resources, which have not yet been logged on, are displayed in blue.

Provided that all required production resources and tools are logged on, the OP can be started using the “log operation on” button.

Posting of required resources



The functionality described below is only available as of service pack 15. Existing systems, which have been implemented before service pack 15, can only use this functionality if the function is implemented as part of a service.

The application provides a button behind the input field and the prompt *Select resource* is shown if the following conditions are fulfilled:

- A required resource is selected in the list.
- No actual resource has been logged on for this required resource yet.

The button can be used to call a selection dialog. The selection dialog displays all resources, which are assigned to the required resource and available. A resource is available if the following conditions are fulfilled:

- The resource is currently not logged on to another workplace.
- The resource has a status that is configured as "released".

For each resource, the selection dialog displays the following:

- Resource type of the resource
- Resource number of the resource
- Name of resource
- Assigned resource family
- Current storage location of the resource

Input of staff badge number

The staff badge number of the person entering the values must be entered.

Confirmation of “log operation on”

The operation is logged on by clicking the “log operation on” button. Once the operation has been logged on successfully, it is displayed within the list of the main AIP dialog.

When the operation is logged on, the workplace, which this operation is logged on to, is entered in the “workplace” field of the backlog of orders dialog. Thus, the workplace (that might deviate from this one), which this operation has so far been planned on, is overwritten. Consequently, the OP is actually re-planned.

1.2. Interrupt/log OP off

General information

All resources that are active for an operation will also be logged off if this operation is interrupted or logged off.

The procedure is the same as for “logging an operation off” or “interrupting an operation”. The “interrupt/log operation off” button triggers this process.

1.3. Change of resources

You can perform a resource change for a logged on resource with running operations, if the logged on resource is configured with the option *Explicit logon* in the *Resource stock*. The resource change is also possible with resources assigned to a required resource because these resources must be configured with the option *Explicit logon*.

Use the button *Change of resources* to change resources logged on to a running OP.

Posting procedure

The workplace and operation have to be selected, for which resources are to be changed.

Starting of the function

The “change of resources” button from the “operations” section has to be clicked.

Resource

The resource to be posted has to be entered here.

If a resource is entered in the "resource" field, which is not logged on and thus is not included in the list of active resources, it will be logged on by clicking the “log resource on” button.

If a resource is entered in the "resource" field, which is currently logged on and thus is included in the list of active resources, it will be logged off by clicking the “log resource on” button.

Posting of required resources



The functionality described below is only available as of service pack 15. Existing systems, which have been implemented before service pack 15, can only use this functionality if the function is implemented as part of a service.

The application provides a button behind the input field and the prompt *Select resource* is shown if the following conditions are fulfilled:

- A required resource is selected in the list.

- No actual resource has been logged on for this required resource yet.

The button can be used to call a selection dialog. The selection dialog displays all resources, which are assigned to the required resource and available. For further information, refer to section "Operation logon with resources".

Staff badge number

The entered person must be authorized to perform the posting.

Confirmation of the dialog

The resource is logged off, when the "log resource on" button is clicked, provided that this resource is included in the list. Consequently, posting of times and quantities is stopped for this resource.

If the resource is not included in the list it will be logged on. This starts posting of times and quantities for this resource.

1.4. Enter resource comment

General information

The "enter resource comment" dialog allows for a comment to be entered for a resource and, as a result, to document a measure that has been taken.

Posting procedure

Starting the function

The "enter resource comment" button from the "workplaces" section is to be clicked.

Select resource

The resource type or resource family has to be entered to select the resource, for which you would like to enter a comment.



After clicking/touching the refresh button, the table shows all resources that are assigned to the entered resource type or resource family.

Select the required resource and click "Next".

Resource type

Specification of the resource type using the list or by manual input. Used for pre-selection.

Resource family

Specification of the resource family using the list or by manual input. Used for pre-selection.

Resource

Specification of the resource using the list or by manual input. The resource, for which already entered comments are to be displayed or for which a comment has to be entered.

Enter comment

The list shows the comments, which have already been entered for the selected resource, in chronological order (descending).

To enter a new comment, select an entry from the catalog and enter a comment or change the text suggested by the catalog.

Catalog

Entries in the "catalog" field (= measure) are made manually or using the list. The corresponding ID must exist in HYDRA. Entries of catalogs of measures are configured on the basis of the resource family at the client.

Comment

By default this field is assigned to the comment of the measure and may be overwritten.

Staff badge number

The entered person must be authorized to enter a comment. The authorization is activated in the HR master.

Confirmation of input

The dialog is posted in HYDRA by clicking the "confirm comment" button. Then the dialog remains open and the comment, which has just been entered, is displayed in the list.

The dialog can be left by clicking the "cancel" button. Comments that have just been entered are saved.

Please note

For technical reasons, comments that are longer than the visible comment field cannot be displayed in full even if changes are made as a part of customizing services (scrolling is not possible within the column).

1.5. Maintenance

The "maintenances" dialog shows active and upcoming maintenances and allows for finished maintenances to be reset.

Posting procedure

Starting the function

The "maintenances" button from the "operations" section is to be clicked.

Select resource

The resource type or resource family has to be entered to select a resource, for which you would like to display or reset the maintenance.



After clicking/touching the refresh button, the table shows all resources that are assigned to the entered resource type or resource family.

Select the required resource and click "Next".

Resource type

Specification of the resource type using the list or by manual input. Used for pre-selection.

Resource family

Specification of the resource family using the list or by manual input. Used for pre-selection.

Resource

Specification of the resource using the list or by manual input. Resource, for which the maintenance is to be displayed or entered.

Select maintenance

The maintenance list shows all maintenances of the selected resource:

Maintenance

Designation of maintenance

Type

ID defining the maintenance type:

T – Cycle-based maintenance

B – Maintenance by hours of operation

Z – Time-based maintenance

Next maintenance

Subject to the maintenance type, this field shows

T – cycles after which the maintenance becomes due.

B – hours after which the maintenance becomes due.

Z – date on which the maintenance becomes due.

Current value

Subject to the maintenance type, this field shows

T – cycles currently posted onto the resource.

B – hours currently posted onto the resource.

Z – current date

Last maintenance

Date when the maintenance was reset

Select the required maintenance you would like to reset and click “Next”.

The function may be stopped by clicking “cancel”.

Reset maintenance**Comment**

A user-defined text, which is displayed in the resource history, may be entered in the “comment” field (optional).

Staff badge number

According to the HR master, the specified person must be authorized to reset the maintenance.

Confirmation of the “reset maintenance” dialog

The maintenance is reset by confirming the dialog. The next maintenance is calculated subject to the calculation base (by default: actual value; can be changed by customizing).

In case it is a unique/non-recurring maintenance, it will no longer be displayed in the maintenance list.

1.6. Change resource status

General information

The status of a resource can be changed by clicking the “change status” dialog.

Posting procedure

Starting the function

The “change resource status” button from the “operations” section has to be clicked.

Select resource

Enter the resource type or resource family to select a resource for which you would like to change the resource status or storage location.



After clicking/touching the refresh button, the table shows all resources that are assigned to the entered resource type or resource family.

Select the required resource and click “Next”.

Resource type

Specification of the resource type using the list or by manual input. Used for pre-selection.

Resource family

Specification of the resource family using the list or by manual input. Used for pre-selection.

Resource

Specification of the resource using the list or by manual input. Resource, for which the resource status or storage location is to be changed.

Select status

The list shows all resource statuses configured for the resource family of the resource. Choose the resource status you would like to set.

If you only want to change the resource status, just confirm the dialog by clicking the “change status” button.

If the storage location is to be changed as well, click “Next”.

New status

The (new) status needs to be entered (mandatory input). The status may either be entered manually or chosen from the selection list. The status must exist in HYDRA. Statuses are configured on the basis of resource types/resource families at the client.

Comment

A user-defined text, which is displayed in the resource history, may be entered in the “comment” field (optional).

Staff badge number

According to the HR master, the specified person must be authorized to set a resource status.

Confirmation of the “change status” dialog

By confirming the respective dialog, the resource status of the selected resource is changed.

Select storage location

Choose the storage location from the list to which the resource is to be reposted. Provided that you have already entered a comment in the last process step, this one is displayed here and may still be changed, if necessary.

Current storage location

After entering a resource, the current storage location of the selected resource is displayed in the “current storage location” field. This field has only been designed for display purposes and indicates which storage location the selected resource is posted on.

New storage location

A new storage location may be entered in the storage location field (optional). Consequently, the current storage location of the resource is reposted. The storage location may either be entered manually or chosen from the selection list. The storage location must exist in HYDRA. Storage locations are configured at the client.

Comment

A user-defined text, which is displayed in the resource history, may be entered in the “comment” field (optional).

Staff badge number

According to the HR master, the specified person must be authorized to set a resource status.

Confirmation of the “change status” dialog

By confirming the dialog, the resource status of the selected resource is changed and reposted to the new storage location.



In case of active resources, it is only possible to switch to a status that is assigned to the "entry" = "F" option, since in any other case, the resources can no longer be posted (e.g. log the resource off when the OP is logged off).