

1 Posting of Quantities

1.1 General

Manually collected quantities

Manual quantities are always posted onto the registered operation and, subject to the respective configurations in HYDRA, to the person carrying out the posting as well. The below table shows whether or when manually collected quantities are posted onto the operation and/or the reporting person.

Posting	Posting to operation	Posting to reporting person
Interrupt OP	Yes	No *) **)
Log OP off	Yes	No *) **)
Partial confirmation/upload	Yes	Yes **)
Log person off	Yes	Yes

*) compare the "Notes on personal posting of quantities"

**) The person who performs the posting needs to enter his/her personal badge number in the posting dialog.

Please note for entering the quantity when personnel is logged off:

If several operations are logged on simultaneously, the quantities will be posted onto all operations.

Recommendation:

The relevant quantities based on operations should be recorded as partial upload for each operation, before the person logs off (without entering a quantity).

Automatically collected quantities

All OPs and employees logged on to the machine are assigned automatic quantities. Automatic quantities result, for example from counter collection.

The quantities to be posted are computed according to the partitioning/cavity that is respectively defined for the operation and operations or staff are posted.

Notes on the personal posting of quantities

The personal posting of quantities depends on the workplace on which an operation was produced. In general: automatically collected quantities are always posted onto all persons who are logged on.

Individual workplace (EAP)

If quantities are neither recorded automatically nor with respect to staff (i.e. no quantity is entered when a person logs off), no quantities will be taken over to the person. Consequently, the quantity fields within the personal posting dialog (posting of record type "B") are empty (0).

Exceptions:

- a) The *"quantity posting to staff"* configuration option within the machine/workplace configuration allows for the manually recorded quantity to be posted onto the person who has so far been logged on for the longest time, when an OP is interrupted or logged off.
- b) Using the option of the HYDRA basic parameter settings "post manual quantities as automatic quantities" allows for manually recorded quantities to be posted like automatically collected quantities, i.e. they are posted onto all OPs and persons logged on.

Group workplace (GWP/GAP)

At group workplaces, the quantity is always taken over to the person when the OP is interrupted or finished, as a unique assignment between person and operation has been established.

1.2 Special features

The following configuration options may influence the above-mentioned quantity posting:

Post manual quantities as automatic quantities

Cross-system configuration in the basic parameter settings of HYDRA.

Quantity posting to staff

Configuration based on workplaces.

Merged operations

If several operations are grouped into a merged operation, quantities are distributed onto the individual operations according to different configurations.

Split operations

Further information on how to post split operations or their split master can be found [here](#).