

# 1 Download of inspection specifications / master data

The processing of all other segments in the integration scenario with PP-PDC and / or HYINFO interface extension are described in their respective interface documentations (HKMPP-PDC.pdf or HKMPP-INF.pdf). In this chapter the QM-IDI processing is described only.

## Inspection batch / operations in “Z2QAIVC000X000” structure

| Field name: | T    | L  | D | Description                                                                                      | Use in HYDRA                                                                                     |
|-------------|------|----|---|--------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|
| SATZART     | CHAR | 3  |   | Record type for header record                                                                    | Not used                                                                                         |
| PRUEFLOS    | NUMC | 12 |   | Number of the inspection batch                                                                   | Number of the inspection batch                                                                   |
| PLNFL       | CHAR | 6  |   | Operation sequence in task list                                                                  | In accordance with configuration (*1)                                                            |
| VORNR       | CHAR | 4  |   | Operation number                                                                                 | In accordance with configuration (*1)<br>Display in HYDRA client (*2)                            |
| WERK        | CHAR | 4  |   | Plant of the inspection batch                                                                    | Plant of the inspection batch                                                                    |
| ART         | CHAR | 8  |   | Inspection type                                                                                  | Inspection type                                                                                  |
| HERKUNFT    | CHAR | 2  |   | Origin of the inspection batch                                                                   | Origin of the inspection batch                                                                   |
| ENTSTEHDAT  | DATE | 8  |   | Creation date of the inspection batch                                                            | Creation date of the inspection batch                                                            |
| ERSTELLER   | CHAR | 12 |   | User who created the data record                                                                 | User who created the data record                                                                 |
| AENDERER    | CHAR | 12 |   | User who changed the data record                                                                 | User who changed the data record                                                                 |
| AENDERDAT   | DATE | 8  |   | Change date of the data record                                                                   | Change date of the data record                                                                   |
| KZVESUBSYS  | CHAR | 1  |   | Ind.: make usage decision in subsystem                                                           | “X” Usage decision will be made in HYDRA<br>“ ” Usage decision will be made in SAP               |
| VKATART     | CHAR | 1  |   | Catalog type for usage decision                                                                  | Catalog type for usage decision                                                                  |
| VWERKS      | CHAR | 4  |   | Plant of selected set for usage dec.                                                             | Plant of selected set for usage dec.                                                             |
| VAUSWAHLMG  | CHAR | 8  |   | Selected set for usage decision                                                                  | Selected set for usage decision                                                                  |
| PPVEKATART  | CHAR | 1  |   | Catalog type for inspection point valuation                                                      | Catalog type for inspection point valuation                                                      |
| PPVEWERK    | CHAR | 4  |   | Plant of the selected set for the inspection point valuation                                     | Plant of the selected set for the inspection point valuation                                     |
| PPVEMENGE   | CHAR | 8  |   | Selected set for the inspection point valuation                                                  | Selected set for the inspection point valuation                                                  |
| PPVECODGRA  | CHAR | 4  |   | Code group proposal when inspection point is accepted (acceptance of all characteristics)        | Code group proposal when inspection point is accepted (acceptance of all characteristics)        |
| PPVECODEA   | CHAR | 4  |   | Code proposal when inspection point is accepted                                                  | Code proposal when inspection point is accepted                                                  |
| PPVECODGRR  | CHAR | 4  |   | Code group proposal when inspection point is rejected (rejection of one characteristic at least) | Code group proposal when inspection point is rejected (rejection of one characteristic at least) |
| PPVECODER   | CHAR | 4  |   | Code proposal when inspection point is rejected                                                  | Code proposal when inspection point is rejected                                                  |
| PLNTY       | CHAR | 1  |   | Task list type                                                                                   | Task list type                                                                                   |
| PLNNR       | CHAR | 8  |   | Key of task list group                                                                           | Key of task list group                                                                           |
| PPLVERW     | CHAR | 3  |   | Task list usage                                                                                  | Task list usage                                                                                  |

| Field name: | T    | L  | D | Description                                  | Use in HYDRA                                     |
|-------------|------|----|---|----------------------------------------------|--------------------------------------------------|
| PLNAL       | CHAR | 2  |   | Task list group counter                      | Task list group counter                          |
| ZAEHL       | NUMC | 8  |   | Version counter for task list                | Version counter for task list                    |
| PLANKTEXT   | CHAR | 40 |   | Short text of the task list                  | Short text of the task list                      |
| DATUV       | DATE | 8  |   | Start of validity for task list header       | Start of validity for task list header           |
| PASTRTERM   | DATE | 8  |   | Start date of the inspection                 | Start date of the inspection                     |
| PAENDTERM   | DATE | 8  |   | Finish date of the inspection                | Finish date of the inspection                    |
| KUNNR       | CHAR | 10 |   | Customer number                              | Customer number                                  |
| NAME1KUN    | CHAR | 35 |   | Name 1 of the customer                       | Name 1 of the customer                           |
| LIFNR       | CHAR | 10 |   | Vendor number                                | Vendor number                                    |
| NAME1LIF    | CHAR | 35 |   | Name 1 of the vendor                         | Name 1 of the vendor                             |
| HERSTELLER  | CHAR | 10 |   | Number of the manufacturer                   | Number of the manufacturer                       |
| NAME1HER    | CHAR | 35 |   | Name 1 of the manufacturer                   | Name 1 of the manufacturer                       |
| MATNR       | CHAR | 18 |   | Material number                              | Material number                                  |
| KTEXTMAT    | CHAR | 40 |   | Short text of the material                   | Short text of the material                       |
| KTEXTLOS    | CHAR | 40 |   | Short text of the inspection batch           | Short text of the inspection batch               |
| CHARG       | CHAR | 10 |   | Batch number                                 | Batch number                                     |
| LAGORTCHRG  | CHAR | 4  |   | Storage location of the batch                | Storage location of the batch                    |
| LICHN       | CHAR | 15 |   | Batch number used by vendor                  | Batch number used by vendor                      |
| IDNLF       | CHAR | 35 |   | Material number used by vendor               | Material number used by vendor                   |
| KDMAT       | CHAR | 35 |   | Material number used by customer             | Material number used by customer                 |
| POSTX       | CHAR | 40 |   | Mat. short text used by customer             | Mat. short text used by customer                 |
| WERKVORG    | CHAR | 4  |   | Plant of the goods movement                  | Plant of the goods movement                      |
| LAGORTVORG  | CHAR | 4  |   | Storage location for the goods movement      | Storage location for the goods movement          |
| LOSMENGE    | CHAR | 17 |   | Inspection batch quantity                    | Inspection batch quantity                        |
| MENGENEINH  | CHAR | 3  |   | Base unit of measure of the inspection batch | Base unit of measure of the inspection batch     |
| GESSTICHPR  | CHAR | 17 |   | Sample size for inspection batch             | Sample size for inspection batch                 |
| EINHPROBE   | CHAR | 3  |   | Unit of measure for sample                   | Unit of measure for sample                       |
| EBELN       | CHAR | 10 |   | Purchasing document number                   | Purchasing document number                       |
| EBELP       | NUMC | 5  |   | Item no. of purchasing document              | Item no. of purchasing document                  |
| MJAHR       | NUMC | 4  |   | Year of the material document                | Year of the material document                    |
| MBLNR       | CHAR | 10 |   | Number of the material document              | Number of the material document                  |
| ZEILE       | NUMC | 4  |   | Item in material document                    | Item in material document                        |
| BUDAT       | DATE | 8  |   | Posting date in document                     | Posting date in document                         |
| AUFNR       | CHAR | 12 |   | Order number                                 | Order number                                     |
| KDAUF       | CHAR | 10 |   | Customer order number                        | Customer order number                            |
| KDPOS       | NUMC | 6  |   | Item number in sales order                   | Item number in sales order                       |
| VORKTXT     | CHAR | 40 |   | Short text for operation                     | Short text for operation                         |
| PRPLATZ     | CHAR | 8  |   | Work center                                  | HYDRA Machine / Work center                      |
| PRPLATZWRK  | CHAR | 4  |   | Plant of the target work center              | Plant of the target work center                  |
| PRPLATZTXT  | CHAR | 40 |   | Short text of the work center                | Short text of the work center                    |
| SUBSYS      | CHAR | 6  |   | Identifier of the subsystem                  | Identifier of the subsystem                      |
| QKZPRZEIT   | CHAR | 1  |   | Ind.: work cycle = time                      | "X" Inspection point based on time intervals     |
| QKZPRMENG   | CHAR | 1  |   | Ind.: work cycle = quantity                  | "X" Inspection point based on quantity intervals |
| QKZPRFREI   | CHAR | 1  |   | Ind.: any work cycle                         | "X" Free inspection points                       |

| Field name: | T    | L  | D | Description                         | Use in HYDRA                                                                                                                   |
|-------------|------|----|---|-------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
| QRASTZEHT   | CHAR | 3  |   | Time unit of inspection grid        | Supported units:<br>„S“ → seconds<br>„SEC“ → seconds<br>„MIN“ → minutes<br>„H“ → hours<br>„HUR“ → hours<br>„STD“ → hours       |
| QRASTZFAK   | NUMC | 6  |   | Time factor for inspection grid     | Value for the time interval                                                                                                    |
| QRASTMENG   | CHAR | 17 |   | Quantity between two inspections    | Value for the quantity interval                                                                                                |
| QRASTEREH   | CHAR | 3  |   | Unit of measure of the insp. grid   | Unit of measure for the quantity interval                                                                                      |
| PPKTTYP     | CHAR | 1  |   | Inspection point type               | Type of inspection point<br>“ ” IP for IPC<br>“1” IP for equipment<br>“2” IP functional location<br>“3” IP for physical sample |
| KZEQUNR     | CHAR | 1  |   | Indicator: user field EQUNR active  | “X” Field is active<br>“ ” Field is not active                                                                                 |
| SWEQUNR     | CHAR | 20 |   | Key word for user field EQUNR       |                                                                                                                                |
| KZTPLNR     | CHAR | 1  |   | Indicator: user field TPLNR active  | “X” Field is active<br>“ ” Field is not active                                                                                 |
| SWTPLNR     | CHAR | 20 |   | Key word for user field TPLNR       |                                                                                                                                |
| KZPHYNR     | CHAR | 1  |   | Indicator: user field PHYNR active  | “X” Field is active<br>“ ” Field is not active                                                                                 |
| SWPHYNR     | CHAR | 20 |   | Key word for user field PHYNR       |                                                                                                                                |
| KZUSERC1    | CHAR | 1  |   | Indicator: user field USERC1 active | “ ” Field is not active<br>“X” Optional field<br>“1” Obligatory field                                                          |
| SWUSERC1    | CHAR | 20 |   | Key word for user field USERC1      | Key word displayed when creating / closing inspection points                                                                   |
| KZUSERC2    | CHAR | 1  |   | Indicator: user field USERC2 active | “ ” Field is not active<br>“X” Optional field<br>“1”...“6” Obligatory field                                                    |
| SWUSERC2    | CHAR | 20 |   | Key word for user field USERC2      | Key word displayed when creating / closing inspection points                                                                   |
| KZUSERN1    | CHAR | 1  |   | Indicator: user field USERN1 active | “ ” Field is not active<br>“X” Optional field<br>“1”...“6” Obligatory field                                                    |
| SWUSERN1    | CHAR | 20 |   | Key word for user field USERN1      | Key word displayed when creating / closing inspection points                                                                   |
| KZUSERN2    | CHAR | 1  |   | Indicator: user field USERN2 active | “ ” Field is not active<br>“X” Optional field<br>“1”...“6” Obligatory field                                                    |
| SWUSERN2    | CHAR | 20 |   | Key word for user field USERN2      | Key word displayed when creating / closing inspection points                                                                   |
| KZUSERD1    | CHAR | 1  |   | Indicator: user field USERD1 active | “ ” Field is not active<br>“X” Optional field<br>“1”...“6” Obligatory field                                                    |
| SWUSERD1    | CHAR | 20 |   | Key word for user field USERD1      | Key word displayed when creating / closing inspection points                                                                   |
| KZUSERT1    | CHAR | 1  |   | Indicator: user field USERT1 active | “ ” Field is not active<br>“X” Optional field<br>“1”...“6” Obligatory field                                                    |
| SWUSERT1    | CHAR | 20 |   | Key word for user field USERT1      | Key word displayed when creating / closing inspection points                                                                   |

| Field name: | T    | L  | D | Description                                                                                  | Use in HYDRA                                                                                                                                                                                                                   |
|-------------|------|----|---|----------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| TEILLOSPFL  | CHAR | 1  |   | Indicator: assignment of partial batch to an inspection point required                       | "X" Partial batch confirmation<br>" " No partial batch confirmation                                                                                                                                                            |
| CHARGPFL    | CHAR | 1  |   | Indicator: batch management required                                                         | "X" Batch managed<br>" " No batch management                                                                                                                                                                                   |
| QUANTITIES  | CHAR | 1  |   | Confirmation of quantity required                                                            | "X" Confirmation of quantity required<br>" " Confirmation of quantity not required                                                                                                                                             |
| EVALUATION  | CHAR | 1  |   | Confirmation of a valuation required, else confirmation by QM                                | "X" Confirmation of evaluation required<br>" " Confirmation of evaluation not required                                                                                                                                         |
| KOSTL       | CHAR | 10 |   | Cost center                                                                                  | Cost center                                                                                                                                                                                                                    |
| KZKORRTRAN  | CHAR | 1  |   | Ind.: Correction transmission                                                                | Ind.: Correction transmission                                                                                                                                                                                                  |
| PRUEFSTAT   | CHAR | 1  |   | Status of the inspection                                                                     | Entries correspond with status of inspection requirements:<br>"A" → FRE<br>"B" → ABG<br>"C" → STO<br>"D" → UNT<br>"E" → SKL<br>"F" → GES<br>In case PRUEFSTAT = "E", additionally the skip lot flag is set to "1", else to "0" |
| EINHVORG    | CHAR | 3  |   | Unit of measure for operation                                                                |                                                                                                                                                                                                                                |
| RUECKMPP    | CHAR | 1  |   | Indicator: confirmation of inspection point required. This field is currently not supported. | Not used                                                                                                                                                                                                                       |

### Characteristics in "Z2QAIMV000X000" structure

| Field name: | T    | L | D | Description                                       | Use in HYDRA        |
|-------------|------|---|---|---------------------------------------------------|---------------------|
| SATZART     | CHAR | 3 |   | Record type                                       | Not used            |
| RUECKMELNR  | NUMC | 8 |   | Confirmation number for inspection characteristic | Confirmation number |

| Field name: | T    | L | D | Description                       | Use in HYDRA                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-------------|------|---|---|-----------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ERFASSART   | CHAR | 1 |   | Recording type for insp. charact. | "A" Measured value for single unit<br>"B" Code for single unit<br>"C" Valuation for single unit (OK/not OK)<br>"D" Measured value for sample<br>"E" Code for sample<br>"F" Valuation of a sample<br>"G" Measured value for a characteristic<br>"H" Code for a characteristic<br>"I" Valuation of a characteristic<br>"J" Measured value for single unit in a sample<br>"K" Code for single unit in a sample<br>"L" Valuation for single unit in a sample<br>"M" Measured value for sample of an inspection point<br>"N" Code for single unit of an inspection point<br>"O" Valuation for single unit of an inspection point<br>"P" Measured value for sample of an inspection point<br>"Q" Code for sample of an inspection point<br>"R" Valuation for sample of an inspection point |
| KZBEWSUBSY  | CHAR | 1 |   | Ind.: valuation by subsystem      | "X" Valuation in HYDRA<br>" " Valuation in SAP                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| BEWART      | CHAR | 1 |   | Valuation type for insp. charact. | "A" Valuation by number of non-conforming units (N-C relation)<br>"B" Valuation by number of defects (N-C relation)<br>"C" Valuation according to s method (ISO3951)<br>"D" Valuation according to code<br>"E" Manual valuation<br>"F" Valuation based on the mean value within tolerance limits<br>"G" Valuation at sample level<br>"H" Valuation according to control chart                                                                                                                                                                                                                                                                                                                                                                                                        |

| Field name: | T    | L | D | Description                                 | Use in HYDRA                                                                                                                                                                                                                                                                            |
|-------------|------|---|---|---------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| KZRZWANG    | CHAR | 1 |   | Results recording required                  | <p>" " Inspection for characteristic is optional</p> <p>"+" Inspection required if result for preceding required characteristic is OK</p> <p>"-" Inspection required if result for preceding required characteristic is not OK</p> <p>"X" Inspection for characteristic is required</p> |
| STATUSV     | CHAR | 1 |   |                                             | Not used                                                                                                                                                                                                                                                                                |
| STATUSR     | CHAR | 1 |   |                                             | Not used                                                                                                                                                                                                                                                                                |
| KZPRUMF     | CHAR | 1 |   | Ind.: inspection scope                      | <p>"=" Specified scope of insp. must be adhered to</p> <p>"&lt;" Scope of insp. may be below specification</p> <p>"&gt;" Specified scope of inspection may be exceeded</p> <p>" " Scope of insp. may fall below or exceed specification</p>                                             |
| KZDOKU      | CHAR | 1 |   | Documentation required                      | <p>" " Inspection description for characteristic is optional</p> <p>"." (dot) Inspection description required in case of rejection</p> <p>"+" Inspection description required</p>                                                                                                       |
| KZSERNR     | CHAR | 1 |   | Ind.: record serial number                  | <p>" " Serial number optional with single values</p> <p>"X" Serial number required with single values</p>                                                                                                                                                                               |
| KZTSTICHPR  | CHAR | 1 |   | Ind.: partial samples for charact.          | <p>" " Inspect single sample for characteristic</p> <p>"X" Inspect multiple sample for characteristic</p>                                                                                                                                                                               |
| KZRAST      | CHAR | 1 |   | Ind.: inspection with insp. grid            | <p>" " Sampling procedure without inspection grid</p> <p>"X" Sampling procedure with inspection grid</p>                                                                                                                                                                                |
| RASTER      | NUMC | 3 |   | Inspection frequency within inspection grid | Inspection frequency within inspection grid                                                                                                                                                                                                                                             |
| SOLLSTPANZ  | CHAR | 5 |   | No. of partial samples planned              | No. of partial samples planned                                                                                                                                                                                                                                                          |

| Field name: | T    | L   | D | Description                                           | Use in HYDRA                                                                                                                                                                                                                                                                                                                                                                  |
|-------------|------|-----|---|-------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| BEWARTSP    | CHAR | 1   |   | Valuation type of partial sample                      | "A" Valuation by number of non-conforming units (N-C relation)<br>"B" Valuation by number of defects (N-C relation)<br>"C" Valuation according to s method (ISO3951)<br>"D" Valuation according to code<br>"E" Manual valuation<br>"F" Valuation based on the mean value within tolerance limits<br>"G" Valuation at sample level<br>"H" Valuation according to control chart |
| PRUEFLOS    | NUMC | 12  |   | Number of the inspection batch                        | Number of the inspection batch                                                                                                                                                                                                                                                                                                                                                |
| PLNFL       | CHAR | 6   |   | Number of the task list sequence                      | In accordance with configuration (*1)                                                                                                                                                                                                                                                                                                                                         |
| VORNR       | CHAR | 4   |   | Operation number                                      | In accordance with configuration (*1)                                                                                                                                                                                                                                                                                                                                         |
| MERKNR      | NUMC | 4   |   | Characteristic number                                 | Characteristic number                                                                                                                                                                                                                                                                                                                                                         |
| QPMK_WERKS  | CHAR | 4   |   | Plant of master inspection charact.                   | Plant of master inspection charact.                                                                                                                                                                                                                                                                                                                                           |
| VERWMERKM   | CHAR | 8   |   | Master inspection characteristic                      | Master inspection characteristic                                                                                                                                                                                                                                                                                                                                              |
| MKVERSION   | CHAR | 6   |   | Version of master insp. charact.                      | Version of master insp. charact.                                                                                                                                                                                                                                                                                                                                              |
| QMTB_WERKS  | CHAR | 4   |   | Plant of the inspection method                        | Plant of the inspection method                                                                                                                                                                                                                                                                                                                                                |
| PMETHODE    | CHAR | 8   |   | Inspection method                                     | Inspection method                                                                                                                                                                                                                                                                                                                                                             |
| PMTVERSION  | CHAR | 6   |   | Version of the inspection method                      | Version of the inspection method                                                                                                                                                                                                                                                                                                                                              |
| PMTKURZTXT  | CHAR | 40  |   | Short text of the inspection method                   | Short text of the inspection method                                                                                                                                                                                                                                                                                                                                           |
| PRUEFQUALI  | CHAR | 5   |   | Inspector qualification                               | Inspector qualification                                                                                                                                                                                                                                                                                                                                                       |
| MERKGEW     | CHAR | 2   |   | Weighting of insp. characteristic                     | Weighting of insp. characteristic                                                                                                                                                                                                                                                                                                                                             |
| GEWKURZTXT  | CHAR | 40  |   | Short text for weighting of inspection characteristic | Short text for weighting of inspection characteristic                                                                                                                                                                                                                                                                                                                         |
| KURZTEXT    | CHAR | 40  |   | Short text of the characteristic                      | Short text of the characteristic                                                                                                                                                                                                                                                                                                                                              |
| FORMEL      | CHAR | 120 |   | Formula for inspection charact.                       | Formula for inspection charact.                                                                                                                                                                                                                                                                                                                                               |
| DUMMY10     | CHAR | 10  |   | Additional information 1                              | Customer / project specific usage                                                                                                                                                                                                                                                                                                                                             |
| DUMMY20     | CHAR | 20  |   | Additional information 2                              | Customer / project specific usage                                                                                                                                                                                                                                                                                                                                             |
| DUMMY40     | CHAR | 40  |   | Additional information 3                              | Customer / project specific usage                                                                                                                                                                                                                                                                                                                                             |
| STELLEN     | NUMC | 2   |   | No. of digits after decimal point                     | No. of digits after decimal point                                                                                                                                                                                                                                                                                                                                             |
| MASSEINHSW  | CHAR | 3   |   | Unit of measure for insp. charact.                    | Unit of measure for insp. charact.                                                                                                                                                                                                                                                                                                                                            |
| SOLLWERT    | CHAR | 16  |   | Target value/nominal value                            | Target value/nominal value                                                                                                                                                                                                                                                                                                                                                    |
| TOLERANZOB  | CHAR | 16  |   | Upper tolerance limit                                 | Upper tolerance limit                                                                                                                                                                                                                                                                                                                                                         |
| TOLERANZUN  | CHAR | 16  |   | Lower tolerance limit                                 | Lower tolerance limit                                                                                                                                                                                                                                                                                                                                                         |
| PLAUSIOBEN  | CHAR | 16  |   | Upper plausibility limit                              | Upper plausibility limit                                                                                                                                                                                                                                                                                                                                                      |
| PLAUSIUNTE  | CHAR | 16  |   | Lower plausibility limit                              | Lower plausibility limit                                                                                                                                                                                                                                                                                                                                                      |
| GRENZEOB1   | CHAR | 16  |   | First upper limit value                               | Customer / project specific usage                                                                                                                                                                                                                                                                                                                                             |
| GRENZEUN1   | CHAR | 16  |   | First lower limit value                               | Customer / project specific usage                                                                                                                                                                                                                                                                                                                                             |
| GRENZEOB2   | CHAR | 16  |   | Second upper limit value                              | Customer / project specific usage                                                                                                                                                                                                                                                                                                                                             |
| GRENZEUN2   | CHAR | 16  |   | Second lower limit value                              | Customer / project specific usage                                                                                                                                                                                                                                                                                                                                             |

| Field name: | T    | L  | D | Description                                             | Use in HYDRA                                                                                      |
|-------------|------|----|---|---------------------------------------------------------|---------------------------------------------------------------------------------------------------|
| KATAB1      | CHAR | 1  |   | Ind.: catalog entry 1 is selected set                   | "X" catalog entry 1 is selected set<br>" " catalog entry 1 is not selected set                    |
| KATALGART1  | CHAR | 1  |   | Catalog type 1                                          | Catalog type 1                                                                                    |
| AUSWMGWRK1  | CHAR | 4  |   | Plant of selected set 1                                 | Plant of selected set 1                                                                           |
| AUSWMENGE1  | CHAR | 8  |   | Selected set / code group 1                             | Selected set / code group 1                                                                       |
| KATAB2      | CHAR | 1  |   | Ind.: catalog entry 2 is selected set                   | "X" catalog entry 2 is selected set<br>" " catalog entry 2 is not selected set                    |
| KATALGART2  | CHAR | 1  |   | Catalog type 2                                          | Catalog type 2                                                                                    |
| AUSWMGWRK2  | CHAR | 4  |   | Plant of selected set 2                                 | Plant of selected set 2                                                                           |
| AUSWMENGE2  | CHAR | 8  |   | Selected set / code group 2                             | Selected set / code group 2                                                                       |
| KATAB3      | CHAR | 1  |   | Ind.: catalog entry 3 is selected set                   | "X" catalog entry 3 is selected set<br>" " catalog entry 3 is not selected set                    |
| KATALGART3  | CHAR | 1  |   | Catalog type 3                                          | Catalog type 3                                                                                    |
| AUSWMGWRK3  | CHAR | 4  |   | Plant of selected set 3                                 | Plant of selected set 3                                                                           |
| AUSWMENGE3  | CHAR | 8  |   | Selected set / code group 3                             | Selected set / code group 3                                                                       |
| KATAB4      | CHAR | 1  |   | Ind.: catalog entry 4 is selected set                   | "X" catalog entry 4 is selected set<br>" " catalog entry 4 is not selected set                    |
| KATALGART4  | CHAR | 1  |   | Catalog type 4                                          | Catalog type 4                                                                                    |
| AUSWMGWRK4  | CHAR | 4  |   | Plant of selected set 4                                 | Plant of selected set 4                                                                           |
| AUSWMENGE4  | CHAR | 8  |   | Selected set / code group 4                             | Selected set / code group 4                                                                       |
| KATAB5      | CHAR | 1  |   | Ind.: catalog entry 5 is selected set                   | "X" catalog entry 5 is selected set<br>" " catalog entry 5 is not selected set                    |
| KATALGART5  | CHAR | 1  |   | Catalog type 5                                          | Catalog type 5                                                                                    |
| AUSWMGWRK5  | CHAR | 4  |   | Plant of selected set 5                                 | Plant of selected set 5                                                                           |
| AUSWMENGE5  | CHAR | 8  |   | Selected set / code group 5                             | Selected set / code group 5                                                                       |
| SOLLSTPUMF  | NUMC | 7  |   | Sample size to be checked per inspection characteristic | If SOLLSTPANZ > 0, then the sample size is calculated through the formula SOLLSTPUMF / SOLLSTPANZ |
| PROBEMGEH   | CHAR | 3  |   | Unit of measure for sample                              | Unit of measure for sample                                                                        |
| PROBMGFAK   | NUMC | 6  |   | Factor for sample unit of measure                       | Factor for sample unit of measure                                                                 |
| ANNAHME     | NUMC | 5  |   | Acceptance number for attributive inspection            | Acceptance number for attributive inspection                                                      |
| RUECKWEZ    | NUMC | 5  |   | Rejection number for attributive inspection             | Rejection number for attributive inspection                                                       |
| KFAKTOR     | CHAR | 16 |   | K factor for variable inspection                        | K factor for variable inspection                                                                  |
| QRKNR       | NUMC | 12 |   | Control chart number                                    | Transformation of SAP control chart number into HYDRA control chart number                        |
| PHYSPROBE   | NUMC | 6  |   | Number of the physical sample                           | Number of the physical sample                                                                     |
| KZKORRTRAN  | CHAR | 1  |   | Ind.: correction transmission                           | " " First transmission<br>"X" Correction transmission                                             |
| ZAEHL       | NUMC | 8  |   | Version counter                                         | Version counter                                                                                   |



| Field name: | T    | L | D | Description                 | Use in HYDRA                                                                                                       |
|-------------|------|---|---|-----------------------------|--------------------------------------------------------------------------------------------------------------------|
| ANTVERF     | CHAR | 1 |   | Share calculation procedure | "A" Binomial distribution<br>"B" Poisson distribution<br>"C" Normal distribution<br>" " Distribution not specified |

### Catalog master data in "Z2QAICA000X000" structure

| Field name: | T    | L  | D | Description                           | Use in HYDRA                                                                   |
|-------------|------|----|---|---------------------------------------|--------------------------------------------------------------------------------|
| SATZART     | CHAR | 3  |   | Record type                           | Not used                                                                       |
| KATAB       | CHAR | 1  |   | Ind.: entry is selected set           | "X" entry is selected set<br>"X" entry is no selected set                      |
| KATALGART   | CHAR | 1  |   | Catalog type                          | Catalog type                                                                   |
| AUSWMGWRK   | CHAR | 4  |   | Plant of the selected set             | Plant of the selected set                                                      |
| AUSWMENGE   | CHAR | 8  |   | Selected set                          | Selected set                                                                   |
| CODEGRUPPE  | CHAR | 8  |   | Code group                            | Code group                                                                     |
| CODE        | CHAR | 4  |   | Code                                  | Code                                                                           |
| KURZTEXT    | CHAR | 40 |   | Short text of the code                | Short text of the code                                                         |
| BEWERTUNG   | CHAR | 1  |   | Valuation                             | "A" Acceptance (OK)<br>"R" Rejection (not OK)<br>" " Valuation not carried out |
| FEHLKLASSE  | CHAR | 2  |   | Defect class                          | Always the same values allowed. Defined in Customizing (transaction OQC7)      |
| MUSSTEXTKZ  | CHAR | 1  |   | Ind.: text required for confirmation. | " " Text not obligatory<br>"X" Text obligatory                                 |
| BB_VORSCH   | CHAR | 1  |   | Ind.: carry out inventory posting     | " " No inventory posting<br>"X" Inventory posting carried out                  |
| QKENNZAHN   | NUMC | 3  |   | Quality score                         | Quality score                                                                  |

### Inspection Points in "Z2QAIPP000X000" structure

| Field name: | T    | L  | D | Description                                                                                                                                                                                                  | Use in HYDRA                       |
|-------------|------|----|---|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------|
| SATZART     | CHAR | 3  |   | Record type                                                                                                                                                                                                  | "Q85" Download of inspection point |
| PRUEFLOS    | NUMC | 12 |   | Inspection batch number                                                                                                                                                                                      |                                    |
| PLNFL       | CHAR | 6  |   | Operation sequence in task list                                                                                                                                                                              |                                    |
| VORNR       | CHAR | 4  |   | Operation number                                                                                                                                                                                             |                                    |
| PROBENR     | NUMC | 6  |   | Sample number                                                                                                                                                                                                |                                    |
| TEILLOS     | NUMC | 6  |   | Partial batch number                                                                                                                                                                                         |                                    |
| MENGE       | CHAR | 17 |   | Inspection point quantity                                                                                                                                                                                    |                                    |
| EINHPR      | CHAR | 3  |   | Unit of measure for inspection point                                                                                                                                                                         | Not used                           |
| EQUNR       | CHAR | 18 |   | Equipment number Cannot be defined freely (value range determined by inspection batch); inspection points of type 1 through 3 already defined (these inspection points can be retrieved with function module |                                    |

| Field name: | T    | L  | D | Description                                                 | Use in HYDRA               |
|-------------|------|----|---|-------------------------------------------------------------|----------------------------|
| TPLNR       | CHAR | 30 |   | Number of functional location (see EQUNR)                   |                            |
| PHYNR       | CHAR | 12 |   | Number of physical sample (see EQUNR)                       |                            |
| USERC1      | CHAR | 18 |   | User field for 18 characters                                |                            |
| USERC2      | CHAR | 10 |   | User field for 10 characters                                |                            |
| USERN1      | NUMC | 10 |   | User field for 10 digits                                    |                            |
| USERN2      | NUMC | 3  |   | User field for 3 digits                                     |                            |
| USERD1      | DATE | 8  |   | User field for date                                         |                            |
| USERT1      | TIME | 6  |   | User field for time                                         |                            |
| VKATART     | CHAR | 1  |   | Catalog type                                                | Not used (only for upload) |
| VWERKS      | CHAR | 4  |   | Plant                                                       | Not used (only for upload) |
| VAUSWAHLMG  | CHAR | 8  |   | Selected set of the usage decision for the inspection point | Not used (only for upload) |
| VCODEGRP    | CHAR | 8  |   | Code group of the usage decision                            | Not used (only for upload) |
| VCODE       | CHAR | 4  |   | Code of the usage decision                                  | Not used (only for upload) |
| VTEXT       | CHAR | 40 |   | Short text for partial batch                                |                            |
| MATNR       | CHAR | 18 |   | Material number                                             | Not used                   |
| CHARG       | CHAR | 10 |   | Batch number                                                |                            |
| PRUEFDATUM  | DATE | 8  |   | Start date of the inspection                                | Not used                   |
| PRUEFZEIT   | TIME | 6  |   | Start time of the inspection                                | Not used                   |
| PRUEFER     | CHAR | 12 |   | Name of the inspector                                       | Not used                   |
| KZRMART     | CHAR | 1  |   | Confirmation type, currently not used                       | Not used                   |
| URSACHEAS   | CHAR | 4  |   | Reason for scrap, currently not used                        | Not used                   |
| MENGEAS     | CHAR | 17 |   | Scrap quantity                                              |                            |
| MENGENA     | CHAR | 17 |   | Rework quantity                                             |                            |

## Error messages in “Z2QIERR000X000” structure

| Field name: | T    | L  | D | Description                                | Use in HYDRA                                                            |
|-------------|------|----|---|--------------------------------------------|-------------------------------------------------------------------------|
| LFDNR       | NUMC | 4  |   | Consecutive number                         | Usage in HYDRA Escalation Management (Acronym complies with field name) |
| MSGID       | CHAR | 20 |   | Message class                              | Vide field LFDNR                                                        |
| MSGNR       | NUMC | 3  |   | Message number                             | Vide field LFDNR                                                        |
| MSGTYPE     | CHAR | 1  |   | Message type (E, I, W,...)                 | Vide field LFDNR                                                        |
| MSGTEXT     | CHAR | 73 |   | Message text                               | Vide field LFDNR                                                        |
| LOG_NO      | CHAR | 20 |   | Application log: protocol number           | Vide field LFDNR                                                        |
| LOG_MSG_NO  | NUMC | 6  |   | Application log: number of current message | Vide field LFDNR                                                        |
| PARAM_NAME  | CHAR | 32 |   | Parameter name                             | Vide field LFDNR                                                        |
| PARAM_ROW   | NUMC | 10 |   | Line in parameter                          | Vide field LFDNR                                                        |
| PARAM_FIELD | CHAR | 30 |   | Field in parameter                         | Vide field LFDNR                                                        |
| PRUEFLOS    | NUMC | 12 |   | Inspection batch number                    | Vide field LFDNR                                                        |
| PLNFL       | CHAR | 6  |   | Sequence of operations within a task list  | Vide field LFDNR                                                        |
| VORNR       | CHAR | 4  |   | Operation number                           | Vide field LFDNR                                                        |

| Field name: | T    | L | D | Description                                             | Use in HYDRA     |
|-------------|------|---|---|---------------------------------------------------------|------------------|
| VORGLFNR    | NUMC | 8 |   | Consecutive node number from order counter APLZL        | Vide field LFDNR |
| MERKNR      | NUMC | 4 |   | Inspection characteristic number                        | Vide field LFDNR |
| KATAB       | CHAR | 1 |   | Indicator: catalog entry is a selected set              | Vide field LFDNR |
| KATALGART   | CHAR | 1 |   | Catalog type of the assigned code group or selected set | Vide field LFDNR |
| AUSWMGWRK   | CHAR | 4 |   | Plant of the assigned selected set                      | Vide field LFDNR |
| AUSWMENGE   | CHAR | 8 |   | Assigned code group or selected set                     | Vide field LFDNR |
| CODEGRUPPE  | CHAR | 8 |   | Code group                                              | Vide field LFDNR |
| CODE        | CHAR | 4 |   | Code                                                    | Vide field LFDNR |
| RUECKMELNR  | NUMC | 8 |   | Confirmation number for the inspection point            | Vide field LFDNR |
| PROBENR     | NUMC | 6 |   | Number of the sample                                    | Vide field LFDNR |
| STUECKNR    | NUMC | 4 |   | Consecutive number for unit to be inspected             | Vide field LFDNR |
| SATZART     | CHAR | 3 |   | Record types                                            | Vide field LFDNR |