


1 FMEA (Failure Mode and Effects Analysis)

Overview

Menu	Quality management → FMEA → FMEA
Transaction code	fmea
Function authorization	fmea

The Failure Mode and Effects Analysis (FMEA) is a targeted method to identify potential failures at an early stage. Using this method, you assess the risks resulting from failures and develop countermeasures. We differentiate between system and process FMEA depending on the object.



The screenshot shows the 'FMEA Übersicht' (FMEA Overview) window. It features a top toolbar with various icons for data management and functions. Below the toolbar, there are input fields for 'FMEA-Nummer', 'FMEA-Art', 'Projektname', and 'Verantwortungsbereich'. A table lists FMEAs with columns for 'FMEA-Nummer', 'FMEA-Art', 'Projektname', 'Status', 'Bearbeitungsgrad', and 'Maßnahmenstatus'. The table contains two entries: one for '334' (Produkt) and one for '664' (Prozess). To the right, a detailed view of an FMEA is shown, including fields for 'FMEA-Nummer', 'FMEA-Art', 'Projektname', 'Verantwortungsbereich', 'Bewertungskatalog', 'Status', 'Bearbeitungsgrad in %', 'Arbeitsgang', 'Artikel', 'Artikelnummer', 'Artikelbezeichnung', 'Zeichnungsstand', 'Zeichnungsnummer', 'Artikelmodell', 'Artikel ABC', 'Freigabe', and 'Freigabetyp'.

Purpose

This function generates and manages FMEAs. The function generates process or system FMEAs.

Integration

You need the application to process FMEAs.

When generating an FMEA, different master data is accessed:

- Companies or persons, employees in charge, ordering party, project manager, created by (name), team stored in HYDRA

- FMEA article
- Orders/operations
- FMEA Rating Numbers

Requirements

The licenses FMEA-EVS and FMEA-VDF are required for this function.

Masterdata must be created to generate a FMEA. Maintenance of masterdata depends on the respective application. As a rule the following masterdata must be maintained:

- Article/Item
- FMEA Rating Numbers
- Failure
- Measures
- Staff
- Responsibility areas

Selection criteria

The application provides the following selection criteria:

Tab *FMEA*

Number

You can filter by entering the manually assigned FMEA number. The number can contain numbers and letter.

FMEA type

FMEAs are separated into system or process FMEA. Either type is displayed depending on selection.

Responsibility area

Assigned responsibility areas are filtered. Like assignment of locations specified in the configuration.

Tab *Project manager*

Project manager

The contents of the list of the project managers are filtered. In the master data it is defined, which entry is accepted to the list of the party in charge.

Project manager, name 1

Content of the field "name 1" of project leader's list is filtered. For departments it is the name of the department, for external persons the surname and for companies the company name

Tab *Party in charge***Party in charge**

The contents of the party in charge list may be filtered. In the master data it is defined, which entry is accepted to the list of the party in charge.

Party in charge, name 1

The content of the field "name 1" of the list of responsible persons may be filtered. For departments it is the name of the department, for external persons the surname and for companies the company name

Field descriptions**Tab *FMEA*****Number**

Alphanumerical field for free allocation of an FMEA number

Version

Alphanumerical versioning of a FMEA number

FMEA type

Here you can select if it is a process or a system FMEA

Project title

Free text field to allocate a project name

Responsibility area

You can allocate, if available, areas of responsibilities.

Assessment catalog

You can select an assessment catalog from the master data to draw numbers for further processing the FMEA.

Name of assessment catalog

Name of the assessment catalog selected from master data

Status

Displays the abbreviation of FMEA status There are the following statuses:

"completed"

"in process"

"open"

"measure definition" Further statuses can be added by way of customizing.

Processing degree in %

You can manually enter in this field the processing status of the FMEA in percentages.

Measure as of (status)

You can document in this field manually the current measure status (date) of the FMEA.

Operation

Here you can open the standard application "Operation" and the selected operation is accepted.

OP name

Associated operation name of the operation number, that is automatically displayed after selection of operation.

Article Id / designation / model / ABC / drawing issue number / drawing number

The selection list of the article master data may be opened to accept an article in order to specify information for the FMEA. Article data is automatically displayed (designation, model, ABC, drawing issue number, drawing number). Instead of selecting the article, the article number and drawing issue number can also be entered. In this case, article related data is generated from the master data catalog and is displayed after storage.

Release type

Different types may be selected when inputting data. This field does not have a special function, meaning it depends on the corresponding application who is to be entered as the responsible party. However, this is not monitored by a special function.

Release

Display the list of people or show the assigned party in charge of the release. List entry of party in charge of the release is defined in the master data. The selected entry is accepted. (Party in charge of release)

Release Name 1, Name 2, Name 3

Display of the content of the fields name 1, name 2 and name 3 of the party in charge of the release
The customer name and the content of the address fields 1 and 2 are displayed for customers. The last name, first name and initials are displayed for external persons.

Released on

Selection / display date of release

Party in charge, type

Different types may be selected when inputting data. This field does not have a special function, meaning it depends on the corresponding application who is entered as the responsible party. Generally, it is the person responsible for detailed processing meaning provision of information for the FMEA. However, this is not monitored by a special function.

Party in charge

Display list of parties in charge or display of the assigned party in charge. In the master data it is defined, which entry is accepted to the list of the party in charge. The selected entry is used as the responsible party.

Party in charge, Name 1, Name 2, Name 3

The field contents of Name 1, Name 2 and Name 3 of the party in charge are shown. The customer name and the content of the address fields 1 and 2 are displayed for customers. The last name, first name and initials are displayed for external persons.

Project manager, type

Different types may be selected when inputting data. This field does not have a special function, meaning it depends on the corresponding application who is entered as the responsible party. Generally, it is the person responsible for detailed processing meaning provision of information for the FMEA. However, this is not monitored by a special function.

Project manager

Display list of parties in charge or display of the assigned party in charge. In the master data it is defined, which entry is accepted to the list of the party in charge. The selected entry is used as the responsible party.

Project manager (project manager, - type, name 1, name 2, name 3)

Display content of the fields name 1, name 2 and name 3 of the project manager. The customer name and the content of the address fields 1 and 2 are displayed for customers. The last name, first name and initials are displayed for external persons.

Ordering party (Ordering party, -type, name 1, name 2, name 3)

Display content of the field name 1, name 2 and name 3 of the project sponsor. The customer name and the content of the address fields 1 and 2 are displayed for customers. The last name, first name and initials are displayed for external persons.

Team no., team name

A team may be entered or selected. Teams are defined within master data. After saving, the name is displayed in addition to the team number.

Start date

Display or entry of the FMEA start date

Finish date

Display or entry of the FMEA finish date

Duration

Automatic generation of the duration (difference between start and finish date)

Target expenditure in days

Display or entry of the planned FMEA expenditure

Actual expenditure in days

Display or entry of the planned FMEA expenditure


Production release date

Display or entry of the production release date


Objective

Empty field to describe the FMEA objective in detail

Toolbar



The below dialog opens to copy a data record:



The selected data record is displayed. Either the number or the version must be changed in order to copy the data record. Click on the green check and the previously selected FMEA is copied and stored with a new name. All sub structures and the assigned team are also copied.



The FMEA for the selected header data record is opened. [FMEA](#)



Team

Link to request the application [Team members](#)



Document

This function opens the application *Document management*.

Dokumentenverwaltung

Allgemein Profile

Daten anfordern Abbrechen Druckvorschau Alles drucken Einfügen Bearbeiten Löschen Dokument anzeigen Speichern Hilfe zur Bedienung Hilfe zur Anwendung Hilfe zur Detailanwendung Hilfe

Selektion

Bezeichnung

Dokumententyp Verknüpfungstyp

☐ Langzeitdaten berücksichtigen

Dokumentenverwaltung

Ziehen Sie eine Spalte hierher, um nach dieser zu gruppieren

Position	Bezeichnung	Dokumententyp	Verknüpfungstyp	URL-Link
1	Test	TEXT	TEXT	
10	Zeichnung	FILE	FILE	Certificate.docx

Dokumentenverwaltung

Allgemein Verwaltung

Position 10

Bezeichnung Zeichnung

Dokumententyp FILE

Verknüpfungstyp FILE

URL-Link Certificate.docx

☐ Sichtbar am Terminal