

1 Generate Transport Orders

Overview

Menu	Material management → Transport management → Generate transport orders
Transaction code	gtro.create
Function authorization	gtro.create
License	MPL-TRA

Usage

The *Generate Transport Orders* application provides users with the possibility to manually generate a transport order for a batch or a resource.

Prerequisite

The database patch ***dbp_mpl_transportation.hsc*** must have been run.

To create the transport order, an active work plan must be configured with an appropriate order type.

Fig.: Generate transport order for a batch

Parameters

The following parameters may be assigned for generating a transport order:

Order type

The order type is set to TRNS (if available) and is required for generating the transport order from a work plan. The work plan must be stored in work plan management and must be activated.

For batch-related transport, a work plan with the article number is searched. If it is not found, a work plan without article number is then searched.

For the transport of a resource, a work plan without an article number is used.

This is a mandatory field.

Final product

The final product number determines which type of material is to be transported. This number is transferred to the transport order. If a batch is transported, the entry must match the article at the batch. If a resource is transported, the article number is irrelevant.

For batch-related transport, this is a mandatory field.

Batch number

For a batch-related transport, an existing and free batch with the batch class (G) yield must be entered for transport. Upon successful generation, the batch is assigned to the transport order and receives the transport status B. The batch must be in the source material buffer.

Resource type

For the transport of a resource, the resource type must be entered.

Resource

For a resource transport, entry of the resource number and resource type is relevant to ensure clear assignment. A resource may only be transported if it has not yet been assigned to a transport order and is not in the "locked" status. For this purpose, the resource must be located in the "preceding material buffer".

Preceding material buffer

For batch-related transport, the batch must be located in this material buffer. This is the material buffer from where the transport is to be started..

This is a mandatory field.

Subsequent material buffer

This material buffer corresponds to the buffer to which a batch or a resource is to be transported.

This is a mandatory field.

Start date

Specifies the planned start date of the transport. The date is transferred to the transport order in the Earliest start date field.

End date

Specifies the planned end date of the transport. The date is transferred to the transport order in the Latest end date field.

Badge

To create a transport order manually, the badge number of a person known to the system has to be entered.

This is a mandatory field.

Toolbar

The following functions are available in the toolbar:

**Generate transport order**

This function can be used to generate the transport order. If a transport order is generated successfully, the order number is indicated via a notification dialog:

**Order overview**

This button can be used to switch to the [order overview](#) application. Transfer of order type and article number if selected.