

1 Resource View of the Graphic Planning Board

Overview

Menu	Production control → Production preparation → Graphic planning Production control → Production preparation → Info shop floor planning
Tab	Planning details

Usage

You can start the "resource view" in the [graphic planning board](#) to get an overview of the assignment of secondary resources.

Integration

The graphic planning board is used to plan operations onto workplaces. Any allocation of secondary WRM resources (e.g. tools, equipment) is also accounted for in planning.

If an operation requiring a tool is planned, the planner is informed if the tool has already been planned for use elsewhere during the period in question. Yet planners have no overview informing them when the tool is not in use.

The resource view of the graphic planning board also shows assigned resources in a Gantt chart.

Requirement

You can only display such resource types identified as being "relevant for assignment" in the configuration of resource types.

In the "views" tab of the HLS settings you have selected the types of resources which you would like to view in the resource view.

In the graphic planning board you have selected a [planning profile](#) and requested data.



The number of resource types as well as the resources assigned to this resource type affect the time required for requesting data.

Once the resource view has been enabled by clicking the relevant button, it will be displayed and can be placed at the required position within the graphic planning board.

Table

Resources are listed in tabular form on the left-hand side of the resource view. Only resources planned for operations shown in the capacity view are displayed.

When data is requested in the planning board only those resources of operations which have already been planned for workplaces/machines and whose resource(s) is/are available within the Tool and Resource Management module are displayed in the resource view.

Data is displayed in a hierarchical structure: resource type → resource family (name) → resource. Resources that are not assigned to a resource family are displayed in a pseudo resource family.

The below-mentioned data is shown for each resource:

- color of the current resource status
- resource number according to the resource stock
- name of the resource according to the resource stock

The following functions can be started using the context menu of the resource allocation (Gantt):

- Resource configuration (res)
- Maintenance calendar (rmcal)

Gantt

On the right within the resource allocation view, resources are displayed as bars. This area is synchronized with the capacity view. In other words, scrolling into the future in the capacity view results in the resource allocation view being scrolled into the future as well and vice versa; the time scales of the two views are thus always synchronous.

Coloring of bars corresponds to that of the capacity view (according to HLS settings). The bars do not have a color gradient. The MES order number and the article/item number of the operation are displayed as text in the bar.



The resource view does not show any periods outside of shifts; the length of individual resource bars is aligned with the length of the operation; this segment always represents the period between the planned start and the planned end of the operation.

Displaying the resource allocation

If an operation is planned for a workplace and the respective resource has so far not been visible within the resource view the resource will not be displayed. Resource data is not updated automatically. The resource becomes only visible within the resource view after having saved and updated the planning board.

If, as a result of deallocating all of the operations, a resource is no longer allocated at all, it is nonetheless still displayed in the resource view dialog.

Tooltip

The tooltip shows all data selected in the "tooltip" tab of HLS settings. In addition, the workplace and the workplace group are shown for which the operation is planned which the resource has been assigned to.

Context menu

The following functions can be started using the context menu of the resource allocation (Gantt):

-  Order overview (orov)
-  Order information (orin)
-  Deallocating: deallocates the operation which the resource is assigned to.

Displaying blocks

Locked resources are represented by resource bars from the start of the lock to the time when it ends. Locked bars are red, regardless of the color corresponding to the status of the resource labeled as "locked".

Planning functions

The following planning functions are possible in the resource view, provided that the planner has the relevant authorizations for planning.

- Horizontal (chronological) re-planning: By moving a bar in the resource view, the corresponding operation will be re-planned temporally. When "releasing/dropping" the bar, checks are performed according to the settings made in HLS.
- Deallocate: the relevant operation can be deallocated using the context menu.

Both activities result in updating of the other views (Gantt, tabular pool of groups, tabular pool of workplaces).