

1 Wage and Premium Indicators

Summary

Menu	Master data → Workplaces / machines → Wage indicators
Transaction code	Prin
Function authorization	Mdprin

Usage

Premium indicator is a key term that refers to a wage payment. Each employee is assigned to a certain premium based on which category he or she falls under according to the relevant collective bargaining agreement. If his or her activity in production deviates from plan specifications then the BDE system will record this. The employee provides his/her premium indicator when logging on to a machine. HYDRA transmits the premium indicator to the payroll accounting system. There, the wage to be paid to the employee is calculated based on a target/ actual comparison.



This function is only available at the Windows based CTWIN or AIP terminals.

Selection criteria

The application provides the following selection criteria:

Workplace

Unique workplace number for which premium indicators are recorded.

Field descriptions

Workplace

Workplace number

Premium indicator

Premium indicator (ID). The worker must enter this ID at the shop floor terminal.

Designation

Description of the premium indicator