

1 Data Structure of Order Sequences

Each of the fields for a sequence is described below. The actual sequence of the editing dialogs may deviate from the one illustrated here. Information about sequences can be found in the document [edit sequences](#).

In order to simplify matters, the term order will generally be used, regardless of whether an order or a work plan is being discussed. Only in examples in which it would make sense for the overall understanding to differentiate between the two will we use the term work plan.

Order/ work plan

Order for which the sequence is defined. A sequence can only be set up for an order, if the order header already exists in MES.

Sequence

Identification of the sequence within an order.

Please note: The standard sequence always has the sequence number 0.



If the "sequence" field is not shown, the sequence number length is 0 in the basic parameter settings. Please contact MPDV.

Designation

Description of the sequence.

Sequence category

S = Standard sequence

There is only one standard sequence for every order; it cannot be deleted.

P = Parallel sequence to the standard sequence

There can be several parallel sequences for each order.

A = Alternative sequence to the standard sequence

There can be several alternative sequences for each order.

Please note:

The sequence category cannot be edited after a sequence has been set up!

Active

The qualification "Active" is only relevant for alternative sequences:

J = Active

N = Not active

If a new alternative sequence is set up, it is set as **not active**.

For standard sequences and alternative sequences, this qualification is always set to **active**.

Orientation

If there are several parallel sequences, the lead times generally vary in length. This creates time buffers in the sequences. The orientation function controls whether these buffers are at the beginning or the end of the sequences. The following options are available:

F = Earliest due date

If the sequence is set for the earliest date, the buffer will be at the end of the sequence.

S = Latest due date

If the sequence is set for the latest date, the buffer will be at the beginning of the sequence.

N = Not relevant; this is the case for standard sequences and alternative sequences.

If there are several parallel sequences for a given standard sequence, the orientation of the standard sequence is used for all segments of the standard sequence for which parallel sequences exist.

Version

Change number/version; for information purposes only.

Branch operation

Operation number of a standard sequence operation,

before which a parallel sequence should branch off, or

from which on an alternative sequence should be replaced.

This is a mandatory field for parallel and alternative sequences. For a standard sequence, this field must remain empty.

If manually setting up an alternative or parallel sequence, the branch operation of the standard sequence must already exist in the orders on hand. When a sequence is handed over via an interface, a valid order number also must be handed off (there is no plausibility check).

Return operation

Operation number of a standard sequence operation,

after which a parallel sequence should branch off, or

up to which an alternative sequence should be replaced.

This is a mandatory field for parallel and alternative sequences. For a standard sequence, this field must remain empty.

If manually setting up an alternative or parallel sequence, the branch-off operation of the standard sequence must already exist in the orders on hand. When a sequence is handed over via an interface, a valid operation number also must be handed off (there is no plausibility check).

Reference sequence

The reference sequence determines the sequence in the order that the reference operations (branch and return) refer to. This is **always** the standard sequence (sequence number 0).

This is a mandatory field for parallel and alternative sequences. The standard sequence must already exist.

For a standard sequence, this field must remain empty.