

1 Logging Key Overview

Summary

Please note:

The "action" field is used as "%AKTION%" in any case. For lack of space, this is not stated in each individual case.

USRFLDCF G	MSTTXT	AUART	NRKREIS	BEARBFT	FKTPROF	MNR	OBJEKT
USRFLDCF G	MSTTXT	AUART	NRKREIS	BEARBFT	FKTPROF	MNR	KEY1
%USRFLDC FG.OBJTYP %	%MSTTXT. STNR%	%AUART.A UART%	%NRKREIS. OBJTYP%	%BAERBFK T.BEARB%	%FKTPROF .FKTPROF %	%AMNR.MN R%	KEY2
%USRFLDC FG.USRFLD %			%NRKREIS. ART%	%BEARBFK T.ART%	%FKTPROF .FKT%		KEY3
				%BEARBFK T.FKT%	%FKTPROF .BERECHT %		KEY4
				%BEARBFK T.BERECHT %			KEY5
user field key	status texts	order type	number range	function authorizatio ns	function profiles	machines	KEYNAME1
object type	status number	order type	objecttype	user	function profil	machinnun ber	KEYNAME2
userfield			form	type	function		KEYNAME3
				function	authorizatio n		KEYNAME4
				authorizatio n			KEYNAME5

STKL	BDEJMOD	MDEFEITG	BDETMOD	GRPRES	MNRTNR	GR	GRTXT	USRFLDEL EM	USRFLDDE F	OBJEKT
STKL	BDEJMOD	MDEFEITG	BDETMOD	GRPRES	MNRTNR	GR	GRTXT	USRFLDEL EM	USRFLDDE F	KEY1
%STKL.STK L%	%BDEJMO D.JAHR%	%MDEFEIT G.DAT%	%BDETMO D.SKMODN R%	%GRPRES: GRP%	%MNRTNR. MNR%	%GR.MNR %	%GRTXT.G RTXTNR%	%USRFLDE LEM.OBJTY P%	%USRFLDD EF.KENN%	KEY2
%STKL.STK LNR%		%MDEFEIT G.VERWEIS %		%GRPRES: RESTYP%	%MNRTNR. TNR%	%GR.ART%		%USRFLDE LEM.USRFL D%	%USRFLDD EF.KENN:Z %	KEY3
		%MDEFEIT G.JAHR%		%GRPRES: RES%		%GR.GR%		%USRFLDE LEM.IDX%		KEY4
										KEY5
Disturbance classes	year model	pub.holidays	day types	group assignment	machine- terminal assignment	reason assignment	reason text	user fields	field type definitions	KEYNAME1
	year	date	day type	group	machine	workplace	reason text	object type	field type	KEYNAME2
		reference		resource typ e	terminal	form		user field keys		KEYNAME3
		year		resource		reason		field-ID		KEYNAME4
										KEYNAME5

LIC	EXPR	EINHUMR	VACODE	EINH	BPOS	DLGCFG	TGRP	ZYP	RESWART	OBJEKT
LIC	EXPR	EINHUMR	VACODE	EINH	BPOS	DLGCFG	TGRP	ZYP	RESWART	KEY1
%LIC.CAT%	%EXPR.EXPR%	%EINHUMR.EINH:V%	%VACODE.VERARBCODE%	%EINH.EINH:H%	%BPOS.MNR%	%DLGCFG.VERWEIS%	%TGRP.TGRP%	%ZYP.MNR%	%RESWART.VERWEIS%	KEY2
%LIC.PROKEY%		%EINHUMR.EINH:Z%			%BPOS.BPOS%	%DLGCFG.DLG%		%ZYP.MNR:Z%		KEY3
		%EINHUMR.MAT%				%DLGCFG.TYP%				KEY4
		%EINHUMR.MATTYP%				%DLGCFG.DLGUSR%				KEY5
licenses	formula management	unit conversion	processing codes	units		dynamic dialogs	terminal groups	cycle parameters	maintenance calendar	KEYNAME1
category	formula	unit from		unit		reference	terminal group	machine number	reference	KEYNAME2
product		unit to				dialog				KEYNAME3
		material				type				KEYNAME4
		material application type				user				KEYNAME5

ASTXT	AST	BEARBCFG	BEARB	BEARBVAB PROF	BEARBKST	PRNLAYCF G	INI	MLEBASC F G	BMK	OBJEKT
ASTXT	AST	BEARBCFG	BEARB	BEARBVAB PROF	BEARBKST	PRNLAYCF G	INI	MLEBASC F G	BMK	KEY1
%ASTTXT.A STXTNR%	%AST.AUA RT%	%BEARBCF G.BEARB%	%BEARB.B EARB%	%BEARBVA BPROF.VE RWEIS%	%BEARBKS T.BEARB%	%PRNLAYC FG.ID%	%INI.INI%	%MLEBASC FG.VERWEI S%	%BMK.BMK NR%	KEY2
	%AST.ASTT YP%				%BEARBKS T.FIR%	%PRNLAYC FG.TYP%	%INI.USR%	%MLEBASC FG.MESTY P%		KEY3
	%AST.AST %				%BEARBKS T.KST%			%MLEBASC FG.MESVA R%		KEY4
								%MLEBASC FG.MESFC T%		KEY5
status text	order status	account rules	user administratio n	responsibilit y areas	cost center authorizatio n	report configuratio n	INI configuratio n	MLE basic configuratio n	resource performance account	KEYNAME1
status texnumber	order type	user	user	reference	uer	configuratio n	INI	reference	resourcen umber	KEYNAME2
	status type				company	type	user	message type		KEYNAME3
	status				cost center			variant		KEYNAME4
								function		KEYNAME5

STATXT	PNR	MST	MATMATP	MATTYPTP	MATTYP	MATPUF	LSTCODE	GRP	BEARBPROF	OBJEKT
STATXT	PNR	MST	MATMATP	MATTYPTP	MATTYP	MATPUF	LSTCODE	GRP	BEARBPROF	KEY1
%STATXT.S TATXTNR%	%PNR.PNR %	%MST.MNR %	%MATMAT TYP.MAT%	%MATTYPT PE.MATTYP %	%MATTYP. MATTYP%	%MATPUF. MATPUF%	%LSTCODE .LSTCODE %	%GRP.GRP %	%BEARBPR OF.BEARB %	KEY2
%STATXT.A TYP%		%MST.MST %		%MATTYPT PE.TPE%			%LSTCODE .LST%		%BEARBPR OF.BEARB PROF%	KEY3
									%BEARBPR OF.VERWEI S%	KEY4
										KEY5
	HR master data	machine status			material types	material buffer	automatic status change	groups		KEYNAME1
	personnel number	machine	material	materialtyp	material type	material		group		KEYNAME2
		status								KEYNAME3
										KEYNAME4
										KEYNAME5

BEARBPRO F	MATLIST	FERTVAR	RUEW	MST	MATMATPU F	WART	VABPROF	TPE	TNR	OBJEKT
BEARBPRO F	MATLIST	FERTVAR	RUEW	MST	MATMATPU F	WART	VABPROF	TPE	TNR	KEY1
%BEARBPR OF.BEARB %	%MATLIST. ANR%	%FERTVAR .VERWEIS %	%RUEW.TY P%	%MST.MNR %	%MATMAT PUF.MAT%	%WART.MN R%	%VABPROF .VABPROF %	%TPE.TPE %	%TNR.TNR %	KEY2
%BEARBPR OF.BEARB PROF%			%RUEW.M GRP%	%MST.MST %	%MATMAT PUF.MATP UF%					KEY3
%BEARBPR OF.KENN%										KEY4
%BEARBPR OF.VAL%										KEY5
							responsibilit y profiles	transport unit	terminals	KEYNAME1
					material				terminalnum ber	KEYNAME2
					materialbuff er					KEYNAME3
										KEYNAME4
										KEYNAME5

RESSTA	RESFAM	RESTYP	RES	PLANVAR	OBJEKT
RESSTA	RESFAM	RESTYP	RES	PLANVAR	KEY1
%RESSTA. RESTYPID %	%RESFAM. RESFAM%	%RESTYP. RESTYP%	%RES.RES TYP%	%PLANVAR .PLANVAR %	KEY2
		%RESTYP. RESTYEXT %	%RES.RES %		KEY3
		%RESTYP. PLAUS:BEL %			KEY4
					KEY5
					KEYNAME1
					KEYNAME2
					KEYNAME3
					KEYNAME4
					KEYNAME5