

1 Settings for List of Produced Output Batches

Activation at the machine

For the purpose of activating the list of produced output batches in the basic screen of the terminal, the display of the third list of the machine to be activated has to be activated in the [machine master record](#) (Workplace configuration → Entry → Display 3rd list).

Definition of the Number of Entries in the List

The number of entries in the list may be customized by extending the data provision for the machine list (mnr.lst) at the terminal on the server side (extended customizing). For this purpose, the additional column "MNR.NUMBER_OF_BATCHES" has to be provided at the server.

Customization of Visible Columns in the List

The list contents can be configured in section [MNR_AMAT.LST] of the file ctaipplay.ini.

Example:

CTAIPLAY.INI
<pre>[MNR_AMAT.LST] GRID_FONT=Arial GRID_FONTSIZE=9 GRID_COLOR=clBlack GRID_BACKGROUND=clWhite GRID_ORDER=ROW.IDX=- GRID_CAPTION=Produzierte Ausgangslose EXAMINE_SCANEXPR1=KLASSE=G EXAMINE_SCANCOLOR1=clGreen EXAMINE_SCANEXPR2=KLASSE=A EXAMINE_SCANCOLOR2=clRed ; ROW.IDX=N10,50,R,Row CNR=C20,150,L,Losnummer ;CNR=*CNR,Los ATK=C25,125,L,Artikel ; ATK=*ATK ; KLASSE=C3,40,Z,* MENGE=N12.0,70,R,Menge EINH=C3,30,Z,ME DAT=dd.mm.yyyy,70,L,Datum ZEI=hh:mm:ss,60,L,Zeit ATKBEZ=C30,200,L,Artikelbezeichnung</pre>

Configuration of Server-Based Comparison

The server-based comparison is activated by an entry in the customer-specific configuration file "ctwinlisten.ini". As with [hytnrcfg.ini](#), this file can be maintained both globally (for all terminals), on a terminal group level, and on terminal level.

Activation is effected by entering a LOADCYCLE larger than 0 (seconds).

CTLISTEN.INI

```
[#LIST#TNR-ALOSE]
LOADCYCLE=900
```

The prerequisite for the server comparison is the default configuration file "ctlisten.cfg", which contains the application-specific configurations of the server list.

CTLISTEN.CFG

```
[#LIST#TNR-ALOSE]
CMD=DLG=LIST;13|MOD=P|      ; (Default <ANZ=250>)
LOADCYCLE=0
QUEUEEMPTY=TRUE
FORCENOTIFY=TRUE
```