

1 Configuration of Kaba Offline Components

1.1 Configurations in HYDRA

1.1.1 Terminals

Since the offline components are not connected to an access terminal in deviation to the online accesses, and since the connection to offline components is made via the programmer, a [terminal](#) of the "Kaba Programmer" type (terminal type 144) has to be created for the offline components. This "terminal" is then entered as such in the accesses created for the offline components.

As regards the PZE terminals to be used for validating and loading authorizations on badges, one of the four absence reason buttons has to be configured with the function "CL" for "Load authorizations".



Writing the authorizations on badges is only possible at terminals with the AIP or ctwin terminal programs.

In order to be able to use a PZE terminal for writing authorizations on badges, it must be fitted with a write-capable reader. In many cases it is necessary to replace the reader in the PZE terminal by a write-capable reader.

1.1.2 Access groups

A maximum of 512 door groups can be created in B-COMM. For this reason, the interface only synchronizes the [access groups](#) with numbers below 512. Access groups with numbers as from 512 are ignored and recorded in the interface log.

Only access groups with a minimum of one KABA offline component are transferred. You can identify these accesses if they are assigned to a terminal of the type "KABA Programmer".

1.1.3 Accesses

The option *offline component* has to be activated for the [accesses](#). Only accesses in the numbering range from 512 through 4511 are considered. The access must be assigned to a terminal of the "Kaba Programmer" type (terminal type 144) so that it is synchronized with B-COMM.



Accesses which are assigned to a terminal of the "Kaba Programmer" type but are not located within the valid range of numbers are ignored and recorded in the error log of the interface.

1.1.4 Access time models / access periods

When configuring the [access time models](#), take into account that B-COMM supports a maximum number of 15 time profiles in one administration area. For this reason, only the access time models with the numbers 1 through 15 are synchronized with B-COMM via the interface.

With B-COMM, times can only be recorded accurately to the minute. The last minute is always included completely in the valid time slot. In HYDRA, a time slot ends with the last second before the indicated end period. For this reason, the end times of the time slots are generally reduced by one minute when transferred to B-COMM. Example: A period from 7:00 AM to 5:00 PM in HYDRA corresponds to a time slot from 7:00 AM to 4:59 PM in B-COMM.

B-COMM only supports times between 12:00:00 AM and 11:59:00 PM in the time slots. HYDRA is theoretically capable of specifying periods with negative times and times over 12:00:00 PM on neighboring days. This is not possible in B-COMM. For this reason, times outside the range valid for B-COMM are automatically limited to the valid range upon synchronization.

Please also note that B-COMM supports a maximum of 12 access periods per access time model. Since the configuration of special functions, e.g. public holidays or doors permanently open, is managed differently in B-COMM and HYDRA, more than one B-COMM time slot may result from a single HYDRA access period. This means that the maximum number of 12 time slots may be exceeded even if fewer access periods are configured in HYDRA.



If more than 12 time slots are required in B-COMM, the entire access time model is not transferred to B-COMM, so that this error will be noticed in any case. In addition, this will be recorded in the interface log.

Kaba Benzing does not support any validity period for access time models. For this reason, the currently valid access time model is always transferred to B-COMM. If the access time model changes in the future, this change has to be transferred to the offline components on the relevant day.



As regards changes to the access time models, please take into account that the transfer of access time models to the components via the programmer is time-independent from writing the authorizations on the badge. For this reason, it is almost impossible to change the numbers or meanings of access time models.

1.1.5 Opening hours

B-COMM does not support any [opening hours](#) in the HYDRA sense. The definition of when a badge is granted access depends solely on the access authorizations of the badge.

For B-COMM, the opening hours in HYDRA are used solely to configure Doors permanently open and Office unlocked (see following section).

Kaba Benzing does not support any validity period for opening hours. For this reason, the currently valid opening hours are always processed in the interface to B-COMM. If the access time model of opening hours changes in the future, this change has to be transferred to the offline components on the relevant day.

1.1.6 Opening hours/doors permanently open/office unlocked

It is not possible to combine Doors permanently open and Office unlocked in one access time model in B-COMM. If an access time model with both functions exists in HYDRA, only the Doors permanently open function will be transferred to B-COMM.



The authorization for implementing Office unlocked must be assigned to the badge via the [access authorizations](#) of the access profile in addition to the access time model of HYDRA opening hours.

1.1.7 Multiple access time models for one access group

By assigning several access time models to one badge, it is possible that the badge has several authorizations with different access time models for the same access group. If the validity periods of the authorizations overlap, only the authorization with the lower number of the access time model is written on the badge.



Consequently, the structure of the access time models should ensure that models with a lower number include the longer access periods, and the models with very restricted access periods should be assigned with higher numbers. An access time model granting authorization for 24 hours on every day should be number 1.

1.1.8 Public holidays

For B-COMM, special days and days off are derived from the [public holidays](#) in HYDRA.

HYDRA public holidays of the "Other day off" type become days off in B-COMM. Other types of public holidays become special days.



B-COMM only processes 2 types of public holidays. For this reason, the HYDRA public holiday types *Public holiday* and *Important public holiday* are transferred to B-COMM with the same time authorizations. Consequently, it makes no sense to enter deviating [access periods](#) for the public holiday type *Important public holiday* in the [access time models](#) used in the offline

components.



All future public holidays entered in HYDRA are forwarded to B-COMM and transferred to the offline components via the programmer. After entering the public holidays for a new year, it is necessary to distribute them to all offline components by means of the programmer (provided there are deviating time slots for public holidays in the offline components).

1.2 Data managed in the B-COMM server

1.2.1 Administration area

1.2.1.1 Overview

Only one administration area is managed by the interface from HYDRA. By default, this is the administration area with the number 1. If required, the number can be adjusted by customizing the interface.

HYDRA automatically synchronizes the tabs *Time profiles/TimePro*, *Door(groups)* and *Days off/Special days* of the administration area. The master data of the administration area itself (tabs *Parameters* and *Master*) are not managed by the interface. They must be maintained manually in the B-COMM GUI.

Before the first successful run of the interface, the CardLink administration area has to be created in B-COMM, otherwise synchronization will not be possible.

1.2.1.2 Parameters tab

The settings in the *Parameter* tab are not managed by the interface from HYDRA. They must be edited in B-COMM.

1.2.1.3 Master tab

The settings in the *Master* tab are not managed by the interface from HYDRA. They must be edited in B-COMM.

1.2.1.4 Time profiles/TimePro tab

The data in the *Time profiles/TimePro* tab is maintained completely via the interface from HYDRA and derived from the access time models. Manual modifications in B-COMM are overwritten with the next synchronization from HYDRA.

The *OfficeIndividual* mode is used for Office unlocked in the time profiles of type *TimePro*. As a consequence, it is possible to control Office unlocked for each badge individually.

1.2.1.5 Door (groups) tab

The data in the *Door (groups)* tab is maintained completely via the interface from HYDRA and derived from the access groups and opening hours in HYDRA. Manual modifications in B-COMM are overwritten with the next synchronization from HYDRA.

Since B-COMM does not support any opening hours in the HYDRA sense, the time profile *Default (always)* is assigned to the door groups.

1.2.1.6 Days off/special days tab

The data in the *Days off/special days* tab is maintained completely via the interface from HYDRA and derived from the public holidays in HYDRA. HYDRA public holidays of the "Other day off" type become days off in B-COMM. Other types of public holidays become special days.

Manual modifications in B-COMM are overwritten with the next synchronization from HYDRA.

1.2.2 Components

1.2.2.1 Overview

The components correspond to the accesses in HYDRA. Some settings are synchronized from HYDRA in the components, others do not have any equivalent in HYDRA and must therefore be maintained manually in B-COMM. When synchronizing the components from HYDRA to B-COMM, the following incidents may occur:

1. **The HYDRA access already exists as a component in B-COMM**
The already existing data of the component is superimposed by the data from HYDRA (details are described below).
2. **The HYDRA access HYDRA does not yet exist in B-COMM**
The new component is copied from the first component of B-COMM (sorted by index) and subsequently the data from HYDRA is superimposed (details are described below). If no first component is available, no accesses can be transferred from HYDRA to B-COMM. This is recorded in the log file.
3. **The component in B-COMM no longer exists as an access in HYDRA**
The component is deleted completely from B-COMM.

The key for synchronizing the HYDRA accesses to the components in B-COMM is the door number (*Door (groups)* tab, *Door number* field).

1.2.2.2 Parameters tab

The following fields are synchronized from HYDRA:

Name

The name is composed of the number and the designation of the access. Since B-COMM has restrictions in this field, the following changes are made to the name: Lower case letters are converted into upper case letters, impermissible characters are replaced with minus signs, and the length is limited to 30 characters.

Validation

This field is assigned with the value 3.

Lock opening time (door bolt)

The lock opening time is transferred from the field "Relay time: opener" of the HYDRA access and limited to the valid value range from 2 to 10 seconds.

All other fields must be edited manually in B-COMM.

1.2.2.3 Master tab

The settings in the *Master* tab are not maintained by the interface from HYDRA. They must be edited in B-COMM.

1.2.2.4 Door (groups) tab

Door number

The door number is the key via which HYDRA synchronizes the accesses to the components.

The *Door (groups)* are derived from the HYDRA access groups and accesses.

The tab is transferred completely from HYDRA; manual changes are overwritten with the next synchronization.

1.2.2.5 TimePro tab

The TimePro function is activated by the interface. Time profiles of the TimePro type are derived from the opening hours of the access group of the relevant access.

The tab is completely transferred from HYDRA; manual changes are overwritten with the next synchronization.

1.2.2.6 Days off tab

The days off of a component are derived from the HYDRA public holidays of the *Other day off* type. The access location is considered in this case. A public holiday is valid for the access if the location of the public holiday is empty or coincides with the location of the access group.

1.2.2.7 Special days tab

The special days of a component are derived from the HYDRA public holidays of the *Public holiday and Important public holiday* type. The access location is considered in this case. A public holiday is valid for the access if the location of the public holiday is empty or coincides with the location of the access group.