

1 Create/Cancel Group Batch

Usage

The function can be used to combine several batches to a group batch at the AIP and to cancel it at a later point in time.

Dialog configuration

Dialog configuration (CNR.BATCH_GROUP_A)

Define the AIP function keys in the file *ctaipbut.ini*:

```
[ANR-LN-Page4]

...

1=BATCH_GROUP_A,L,Gruppenlos bilden,Losgruppe_bilden.png

2=BATCH_GROUP_C,L,Gruppenlos auflösen,Losgruppe_auflösen.png
```

The sections [BATCH_GROUP_A.LST] and [BATCH_GROUP_C.LST] are required in the layout configuration of *ctaipplay.ini*:

```
[BATCH_GROUP_A.LST]

GRID_FONT=Arial

GRID_FONTSIZE=9

GRID_COLOR=clBlack

GRID_BACKGROUND=clWhite


CNR=C20,100,L,Batch

ATK=C20,100,L,Material

ATKBEZ=C40,140,Designation

HZTYP=C40,150,L,Material Type

RESAUNR=C12,100,L,Order

RESAGNR=C4,50,L,OP

; for set then position

;U_POSITION=C8,60,R,Position
```

```
[BATCH_GROUP_C.LST]

GRID_FONT=Arial
GRID_FONTSIZE=9
GRID_COLOR=clBlack
GRID_BACKGROUND=clWhite


CNR=C20,100,L,Batch
ATK=C20,100,L,Material
ATKBEZ=C40,140,Designation
HZTYP=C40,150,L,Material Type
RESAUNR=C12,100,L,Order
RESAGNR=C4,50,L,OP
; for set then position
;U_POSITION=C8,60,R,Position
```

System configuration

Further system configurations are not required to group/cancel batches.