

1 Batch Grouping

Usage

You make use of the function to use several batches of a group within the process at AIP.

Dialog configuration

Dialog configuration (BATCH_GROUP_B)

Define the AIP function keys in the file **ctaipbut.ini**:

```
[ANR-LN-Page4]
...
3=BATCH_GROUP_B,L,Losgruppenbildung,Losgruppierung.png
```

The section [BATCH_GROUP_B.LST] is required in the layout configuration of **ctaipay.ini**:

```
[BATCH_GROUP_B.LST]
GRID_FONT=Arial
GRID_FONTSIZE=9
GRID_COLOR=clBlack
GRID_BACKGROUND=clWhite

CNR=C20,100,L,
ATK=C20,100,L,
ATKBEZ=C40,140,
HZTYP=C40,150,L,
RESANR=C12,100,L,Operation
```

System configuration

Further system configurations are not required to group batches.



An appropriate OP has to be available in the system to be able to use the batches in the dialog and in order for an OP to be logged on in the background.

The relevant OP can be determined by:

- a special batch reservation (affecting several orders)
- the order network (sequence of OPs in an order)