

1 Create/Cancel Group Batch

Summary

Within the production area, it is necessary to compress batches to a group with one ID and to provide this package/group within another area. It is assumed here that the identified material only switches positions and this movement is irrelevant to batch tracing (e.g. picking or transfer posting of batches in a group and provision for production or transport).

Usage

The function is used to combine batches of different or identical materials, which is to be resolved/canceled at a later point in time providing the batches "unaffected".

Prerequisite/configuration

The configuration for AIP is described [here](#).

The configuration for AIP2 is described [here](#).


The logical process and posting are described [here](#).

Generate group batch



If the terminal is offline, only a limited number of posting functions is provided based on the available data. If the terminal is offline, errors are not displayed e.g. if posting failed on the server.

Dialog



Description of display fields:

- **Machine**
Used workplace/machine
- **Group batch**
Generated group batch that is currently being created.
- **Batch number**
Entered number of the batch that is to be recorded for the group batch.
- **Number of batches**
Number of individual batches included in the group batch.
- **Staff badge number**
The user's staff badge number.
- **Result list**
List of all individual batches included in the group batch with batch number, material number etc.

Function keys

- **Function key "cancel"**
The function key terminates the dialog and rejects data input.
- **Function key "add"**
An individual batch may be assigned to the group batch using this function key.
- **Function key "remove"**
A selected individual batch may be removed from the group batch using this function key.
- **Function key "complete"**

This function key completes the group batch, i.e. it is generated.


Procedure

For the user the procedure is as follows:

- The user opens the "create group batch" dialog in the basic screen of the terminal
- The user enters the batches (manually or by scanning) he/she wants to group
- The user may view the group batch number in the dialog
- The dialog's result list shows the entered batches that are to be grouped.
- Individual batches may still be removed or added, as long as the user has not confirmed the dialog by the "complete" key.

Cancel group batch

Dialog



Description of display fields:

- **Machine**
Used workplace/machine
- **Target buffer**
Material buffer to which the batch is transferred. If the field remains empty, no transfer posting takes place and the material buffer remains.
- **Batch number**

Entered number of the group batch that is to be canceled (re-posted).

- **Staff badge number**

The user's staff badge number.

- **Result list**

List of all individual batches included in the group batch with batch number, material number etc.

Function keys

- **Function key "cancel"**

The function key terminates the dialog and rejects data input.

- **Function key "complete"**

This function key cancels the group batch.

Procedure

For the user the procedure is as follows:

- The user opens the "cancel group batch" dialog in the basic screen of the terminal
- The user enters the group batch (manually or by scanning) he/she wants to cancel
- The dialog's result list shows the batches pertaining to the grouping.
- In the "material buffer" field the user may enter a new material buffer to which all individual batches of the group are to be re-posted.
 - If the user does not fill out the field, the material buffers of the individual batches remain as before.
- As long as the user has not closed the dialog by "cancel group", it remains open and/or can be cancelled. Data will be rejected.