

1 Output Batch Change

Summary

Output material may be changed for a running OP using the "output batch change" option.

Configuration

Further system configurations are not required to be able to use the output batch change dialog.

Dialog

Change Outgoing Batch
<CA_WL_MPL>

Workplace
R000
Material
5468-41-0010

Operation
MPL000010010

New batch
PR4RH6A112

Target buffer
MP_N_50505

Transp. unit
ROLLCONT

Quality
Yield
Scrap

Qty
0
M

Reason
0

Comment

Input mat. no.	Input mat. des.	Batch No.	Custom. batch no.	Remainder Unit
3846-98	Aluminum roll 800 mm x 1000m x 1 mm			0 M
5468-41-0010	Aluminum roll 200 mm x 1000 m x 0,5 mm			

Staff Number

Cancel
Preced. batches
Change i.batch
Change Outgoing Batch

03.07.14 13:09:57

The input batches that are logged on are displayed with their available remaining quantity in a list within the output batch change dialog. The following data may be entered:

Target buffer

Material buffer for which the current batch is to be produced. The output material buffer of the machine is pre-assigned as default value.

Transport unit

A transport unit defined within the system may be assigned here. The selection refers to transport units that were assigned to the material type of the OP.

Comment on batch

In this field a comment may be saved for the batch to be produced.

Quantity

The batch to be produced is posted with the quantity entered here. The quantity is taken over as primary quantity of entry to the order and machine and a goods movement is generated as goods receipt.

Quality

A batch may be classified as yield or scrap quantity. The system posts yield batches with the "free" status. Scrap batches automatically get the "blocked" status. When scrap is selected, a valid scrap reason has to be assigned.

"Preceding batches" function key:

This button opens a list with output batches which have already been produced for this OP.

Display preceding batches
<C_VLOS_MPL>

Workplace

R000

Operation

MPL000010010

Preced. batches

Input mat. no.	Input mat. des.	Custom. batch no.	Target
5468-41-0010	Aluminum roll 200 mm x 1000 m x 0,5 mm	PR4RD97116	MP_N_50500
5468-41-0010	Aluminum roll 200 mm x 1000 m x 0,5 mm	PR4RD97115	MP_N_50500
5468-41-0010	Aluminum roll 200 mm x 1000 m x 0,5 mm	PR4RD97112	MP_N_50500
5468-41-0010	Aluminum roll 200 mm x 1000 m x 0,5 mm	PR4RD96116	MP_N_50500
5468-41-0010	Aluminum roll 200 mm x 1000 m x 0,5 mm	PR4RD96115	MP_N_50500
5468-41-0010	Aluminum roll 200 mm x 1000 m x 0,5 mm	PR4RD96114	MP_N_50500

Cancel

Re-print

03.07.14 13:10:35

"Change inp. batch" function key:

Using this button the user can switch to the "input batch change" function.

New batch

When a current output batch is completed, a new batch number is simultaneously created for the next batch. The batch number may be assigned automatically or manually. The batch generated in this way is created with the batch number in the system and set to the "running" status.