

1 Sequencing List - Transport Orders

Overview

License	MPL-TRA
---------	---------

Usage

The functionality described below provides additional data in the sequencing list (LIST;11) for entering transport orders.

Prerequisite

The data base patch ***dbp_mpl_transportation.hsc*** must have been run.



The list will only show orders which are configured for display in the sequencing list at the terminal. To display the functionality at the terminal, it is necessary for running operations of this transport order type, too, to be included in the list.

Features

Extended data fields for entering transport orders in the ANR list (LIST;11):

Transport type (AGR_TRANR_ART)

This defines which type of transport is intended for the operation.

L = Batch-related transport

R = Resource transport

A = Article-related transport

Assigned resource (AGR_TRANR_RES) and resource type (AGR_TRANR_RESTYP)

Resource number for transport type R

Assigned batch (AGR_TRANR_CNR)

Number of batch for transport type L

Source material buffer (AGR_TRANR_SMP)

Material buffer from which the transport is to be started.

Target material buffer (AGR_TRANR_TMP)

Material buffer to which the object is to be transported.

Triggering operation (AGR_TRIGGER_ANR)

Production operation which created the transport order (e.g. scheduled operation through planning or operation which created the batch for transport).

Configuration

The additional columns in the sequencing list are to be activated at the terminal via the AKRO mechanism in the ctaipplay.ini/n file.