

1 General Operating Instructions for MES-Cockpit

Depending on the installed version, MES Cockpit provides you with different applications, such as the performance analysis or current overviews with different functions. This section deals with the general operation of MES Cockpit focusing on functions applicable to multiple applications.

1.1 Home Screen

The "Home Screen" is the start page for MES Cockpit and enables the user to go to the available applications (depending on the license) and display relevant data. The user can switch between the following applications:

- **Performance analysis**
Leads to the KPI analysis referring to several systems showing the trend of KPIs. Information and KPIs are provided for the following objects: workplaces, orders and operations.
- **Production Monitoring**
Shows an overview of status information across several systems on the objects workplaces, orders and operations including display of current shift KPIs for the selected objects.
- **Workplaces/machines**
Tabular overview of workplaces/machines to visualize the current machine condition (status, point in time since when the status is applicable) including basic information on the workplace/machine. It is an application relating to systems.
- **KPI monitor**
When starting the KPI monitor, it first provides an overview of the whole site and enables to drill down key figures in relation to cost centers, machine groups and the single object "machine". It is an application relating to systems.
- **Messages listing**
List of planned maintenance orders (pool of orders including orders/OPs of the "maintenance" category). It is an application relating to systems.
- **Contact person**
Search for contact partners within the company and check if they are available. It is an application relating to systems.

1.2 Basic functions of the Home Screen

Besides the possibility to switch to the available applications, the home screen of MES Cockpit also provides the following functions:

Log on and off

You have to log on to MES Cockpit to be able to use MES Cockpit functions. Upon calling online functions, MES Cockpit automatically logs on to the registered HYDRA system and relevant data is shown.

HYDRA user

The logon requires a user created for MES Cockpit and a relevant password.

The "change password" function changes the password defined for the user to log in to the single systems via the web interface.



Please note that most of the browsers save the login name and often offer to save the relevant password. This function is not part of MES Cockpit and therefore cannot be disabled in MES Cockpit.

Language

Using the radio group buttons, it is possible to switch between the different languages that are available for the user. MPDV can provide additional language packs on request.

Settings

By the "system" selection list, you can choose the HYDRA system you intend to work with. The available systems are defined during implementation and/or by your administrator.

By clicking "OK", you confirm the entered data and log in with the relevant user to the selected system. An error message occurs, if the login fails.



Help

MES Cockpit provides a context-sensitive help function, i.e. the content of the displayed help file depends on the contents of the current screen.



Logout

By clicking the "logout" button the user logs off from MES Cockpit. The user has to log in once more to switch to the other applications.



Back

By using the MES Cockpit icon or the arrow in front of it, it is possible to go back step by step.

1.3 Further basic functions

In addition to the above-described basic functions, the applications provide further basic functions:



Home

The "Home" button leads the user back to the home screen.



Update

The displayed page is refreshed.



Filter

The filter allows restricting the data displayed online. This function cannot be used in the Performance Analysis.