

# 1 Batch Tracing

## Summary

|                        |                                                     |
|------------------------|-----------------------------------------------------|
| Menu                   | Material management → Batch tracing → Batch tracing |
| Transaction code       | battr                                               |
| Function authorization | battr                                               |

## Usage

The application is only available in the structure described here if the modification [battrextensionselection](#) is enabled.



If you do not use the modification, please refer to this [document](#).

This evaluation is to be used to determine, with regard to the output batches, which input batches have entered and with regard to input batches, which output batches they have entered into. The direct predecessors (batch origin) and the direct successors (batch consumption) are shown.

The batch quantity for which batch tracing is to be performed can be specified by the exclusive entry of the machine number, order number, material number or batch number. Here only those batches are considered that were generated in the specified period.

## Selection Criteria

The application provides the following selection criteria.

### General

#### Evaluation mode

The evaluation mode can be used to select which one of the below-mentioned selection criteria is used:

- Batch number
- Material
- Workplace
- MES order number

**Origin:**

When the identifier "Origin" is selected, the overall batch origin/development is determined. The batch origin displays all of the batches that entered and all of the output batches for the selected selection criterion (e.g. batch number, material, etc.).

**Consumption:**

If the "consumption" identifier is selected, all output batches are determined that have been consumed for the relevant selection criterion (e.g. batch number, material, etc.).

**Direct input/ output batches:**

When the identifier "Direct input/output batches" is selected, the input batches that entered directly and/or the output batches that were produced directly from the input are displayed.

**Initial/final batches**

All linked input or output batches matching the entered selection criterion (e.g. batch number, material, etc.) up to the origin and/or end of the process are shown.

**Date from ... to ...**

All produced input and output batches in the selected period are displayed.

**Consider long-term data**

Data from the long-term archive are selected as well.

**Attributes****Attributes 1 - 10**

Selecting an attribute as a selection criterion displays all links/relationships of batches that currently have this identifier.

**Batch attributes****Batch attributes**

Selecting a batch attribute as a selection criterion displays all links/relationships of batches for the material type of which this batch attribute has been configured and that are currently assigned this identifier.

**Alternative batch numbers****Alternative batch number 1-20**

Selecting an alternative batch number as a selection criterion displays all relationships/links of batches that currently have this identifier.

If several selection criteria are used overlapping results are displayed in the workplace overview.

Please note:

- If the batch number is displayed with zeroes (e.g. 0000000000), there is no input batch for the batch origin.

## Field Descriptions

In the input/output batch detail application, all batches are displayed according to the selections entered.

A selection of columns are described below:

### Input batch

Input batch number

### Output batch

Output batch number

### Workplace

Workplace at which the batch was generated

### Material type

[Material type](#) of the batch

### Material

Material number of the batch

### Designation

Plain text of the material

### Production date/ Logon or logoff date

Production date and time for output batches

Logon or logoff date and time for input batches

### Serial number

Assigned serial numbers for this batch. The ADE-SNR functionality can be used to establish a connection between a batch and a serial number.

## Toolbar



### Graphic batch tracing

Starts the application [Graphic batch tracing](#).