

1 DNC resource configuration

Overview

Menu	Master data → Resources → DNC resource configuration
Transaction code	dncre
Function authorization	mdres.*

You use the DNC resource configuration to view and edit DNC resources. The functionality is basically identical to the one of the resource configuration.

Purpose

You can use the DNC resource configuration to create and edit DNC resources. The application shows all resources matching the conditions you specified in the selection parameters.

Integration

Use the master data function "Resource configuration" to create, edit or delete any resources.

Selection criteria

The application provides the following selection criteria:

Resource from ... to ...

This selection criterion refers to the resource. You can also use wildcards (placeholders *).

Resource status

Status of the resource

Resource type

Type of resource.

Designation

Name of the resource.

File name

File name assigned to the resource

Cost center

Cost center of the resource.

Resource family

The resource family to which the resource is assigned.

Responsibility area

Responsibility area to which the resource is assigned.

Storage location

Regular storage location of the resource.

MD user fields

MD user fields 1- 6 of the resource. If you select a resource family in the selection panel, the application shows the field names according to the assigned user field definition.

Field descriptions

You can find the field descriptions in the application "Resource configuration".

Toolbar

The individual functions of the toolbar are included in the application "Resource configuration".

Notes on processing



The application DNC resource configuration automatically restricts the number of displayed data records. If you select the selection criteria and the number of resulting data records is higher than 500, the system issues a message that you must further narrow down the result by adding further selection criteria. You can configure the number of data records that triggers this automatic message.

The application DNC resource configuration identifies the number of resulting data records when you request data after having entered the selection criteria. If the number exceeds 500 data records, the data request is interrupted. A message is issued that asks you to narrow down the selection. If the number of data records is smaller than 500, the data records are displayed in the application.

You can configure the limit value individually (i.e. set a value >500). Enter the respective value in the application "INI data configuration" (transaction code: inidcfg).

Required INI data configuration

Field	Value	Comment
Name	DNC	Always: DNC
Section	RESOURCELIMIT	Always: RESOURCELIMIT
Key	COUNT	Always: COUNT

Value	Integer value e.g. 1000	Limit value for the automatic restriction of displayed data records in the application DNC resource configuration.
Active	Yes	Always: Yes