

1 PDV Events

Summary

Menu	Master Data → Process Data Processing → Events
Transaction code	peve
Function authorization	peve

Utilization

With PDV events, various events that can occur on the machine can be configured and collected. In addition, the configured PDV events can be identified as an alarm, which can create an appropriate output signal if it occurs on the machine.

The assignment of the PDV events to a physical channel on a machine is performed by configuring the logical channels. A log, or the time-related documentation of the events that occur, can be carried out using the protocol dialog described in the "Process events" application.

PLEASE NOTE!

To do this, in the configuration of the logical channels both the type (E) and the related control must be correctly parameterized.

Selection parameters

The following selection criteria are available in the respective application:

Event ID

Option to search for an event identification with a wildcard function.

Designation

Option to search for an event designation with a wildcard function.

Field description

The PDV event configuration contains the following information:

Event ID

Unique identification of the configured event

Designation

Optional parameter with which a designation can be assigned to an event configuration

Alert

Identifier as to whether or not the event is to trigger an alarm (physical signal) when it occurs

Alert duration

Delay time specifying how long after the event has occurred, the alert is to remain at the alarm channel. The unit is entered in seconds.

Event type

Declaration of the event type: entered as event (F) or as hint (H). If no type is defined, the default type (P) will be entered.

Event category

Category to classify events (also referred to as malfunctions) and notes e.g. in the evaluation of process events.