

1 Planning Profiles

Overview

Menu	Master data → Production control → Planning profiles
Transaction code	Plprof
Function authorization	Plprof

Purpose

You use this function to create or modify planning profiles in the system.

Integration

By using planning profiles, you can narrow down the data displayed in the different planning functions (e.g. workplaces, staff).

- [Graphic planning](#) (transaction grap)
- Graphic order sequencing (transaction graps)
- [Workplace assignment](#) (transaction wpas)

Requirements

You have structured the workplaces to be planned based on capacity groups and set them up in the system.

Selection criteria

The application provides the following selection criteria:

User

User name for whom the planning profiles that were configured beforehand are to be displayed.
You can also run a search using wildcards.

Global planning profiles are not shown if you select a specific user.

Planning profile

Name of the planning profile to be searched. You can also run a search using wildcards.

Field descriptions

User

User for whom the subsequent capacity group is to be assigned or has been assigned in the planning profile.



You can leave this field empty if the modification [PLPROF-GLOBAL](#) has been enabled.
This is a global planning profile that can be selected for every user.

Profile

Name of the planning profile.

You cannot use names in global and user-specific planning profiles.

Selection

You can assign different objects to a planning profile subject to the application and its product version:

Application	Modification	
Graphic planning		Group
Graphic planning	PLPROF-MNR	Group, workplace  If you assign single workplaces to a planning profile, the dialog still shows the group the workplaces belong to.
Graphic order sequencing		Group
Workplace assignment		For workplaces: group For staff: area, cost center, department, employee subgroup, employment relationship, person
Workplace assignment	PLPROF-MNR	For workplaces: workplace, group For staff: area, cost center, department, employee subgroup, employment relationship, person

Value

Subject to the selection made, you have to enter the relevant value in this field.

If you select "group", it might be a capacity group configured as bottleneck or throughput capacity.

In general, the graphic planning board, graphic order sequencing or workplace assignment only shows the workplaces for which you are authorized via the responsibility.

Order

This field specifies the order of groups in the [graphic planning board](#).



We strongly advise to input data in this field, because the order of groups might otherwise be arbitrary. Ideally, you should use intervals of 10.



If the modification [PLPROF-MNR](#) is enabled, the value defined for the workplaces specifies the order of groups when you assign workplaces to a planning profile.

Within a group, you can sort workplaces by using the “position” field of the [group assignment](#).

The following options are only relevant for the [graphic planning board](#):

Visible in shop floor planning

This field specifies if the current group is shown when selecting a planning profile.

Show workplaces without responsibility area authorization

This option shows the workplaces of the selected group in the Shop Floor Scheduling module although the user does not have the required responsibility area authorization.

Allow planning without responsibility area authorization

When resolving conflicts occurred during manual planning, this option moves an operation for which the user does not have the responsibility area authorization. You cannot shift the operation manually; rather shifting can only be done as a means of resolving conflicts.