

1 Resource types


Overview

HYDRA menu	Master Data → Resources → Resource types
FEDRA menu	Detailed scheduling → Master data → Resource types
Transaction code	restyp
Function authorization	mdrtyp.*

This document describes the application "Resource types" on the client.

Purpose

Resources are classified in resource types with respect to their function and use. For example, you can group tools by assigning them to the resource type "Tool".



You use resource types not only to classify resources, but also to control specific functionalities. For example, the resource type is used to control whether or not an assignment check for resources is made in the shop floor scheduling (only relevant if the additional function is used).

The resource types listed in the following table have been predefined by MPDV. They are created as part of the implementation process.

Resource type	Abbreviation/ Ident
Machine	MNR
Tool	WNR
Staff	PER
Gage	PRM
Device	VOR
DNC-Programm	DNC
Document	DOC
Energy counter	ENE

Note

Various resource types are subject to certain technical restrictions. For example, users cannot delete the resource types "Machine", "Tool", and "Staff". Further information on this subject can be found in the chapter about configuring resources types.

Integration

You use resource types as a characteristic to specify differences between resource objects. The resource type therefore is the top classification criterion.

Selection parameters

In the selection panel, you can filter by higher-level or assigned resources. The application provides the following selection criteria:

Resource type

Type of resource

Field descriptions**ID**

Unique internal key.

This value may not be modified for the resource types delivered by MPDV because a range of processing depends on it.

Resource type

Unique "self-explanatory" designation of the resource type, e.g. "Machine" or "Tool".

You can select this value in the various functions. Only the resource type allows you to identify a resource or its resource ID uniquely. That is why, evaluations also show the resource type of the resource.

Description

Explanation of the resource type; in form of a comment.

User field key

Refers to a valid user field key

Field description for tab **General**

Assignment

This option specifies whether or not a resource of this resource type should be assigned. An assignment is a prerequisite for performing an availability check for the resource when planning an OP on a machine in the detailed scheduling of the HYDRA shop floor scheduling (HLS).

Possible values:

N = No, no assignment

G = Assignment of the total duration of an operation

Please note: For the resource type DNC, the setting should be set to *None* because there is an "endless" capacity for resources of this type.

Please note: For resources of type MNR (machines) the setting has no significance because machines are always assigned as primary capacities.

Automatic creation

Identifier that indicates whether or not a stock is to be created automatically for a resource of this type if this resource is transferred using the component list from the PPS and if this resource does not yet exist in the WRM product group.

Please note: This identifier is inactive and cannot be changed for the resource type "Machine".

→ Status assignment

This identifier specifies whether or not a status configuration (menu *WRM: Master data* → *Status assignment*) is allowed for this resource type.

Note:

This identifier is inactive and cannot be changed for the resource types "Machine" and "Staff".

Log on with OP

This identifier is used to control whether or not a resource of this type, which is assigned to the operation as a component, is logged on. Possible values:

None: The resource is not logged on.

Implicit: The system automatically (implicitly) logs on the resource that is assigned to the operation as a production resource and tool; you can neither log on the resource manually (explicitly) nor change the logon.

Explicit: You can manually (explicitly) log on the resource that is assigned to the operation as a production resource and tool or you can log on another resource instead. If you do not log on the resource or another resource explicitly, the system implicitly (automatically) logs on the current resource; in this way, the current resource serves as a "default".

Note:

This value is used as a "Copy template", if you manually create a resource for the first time in the MOC. Er wird direkt in das entsprechende Konfigurationsfeld der (neu angelegten) Ressource übernommen. For the rest of the process, only the value specified for the resource is used.

In general, this identifier should be inactive for resource type DNC because a specific processing exists for it in the HYDRA product group DNC (NC programs are logged on separately) (only applies when using HYDRA).

Post to resource

This identifier is used to specify if a resource can be posted to or not. If the identifier is set, the resource is logged on automatically with an operation logon.

The identifier must be set if cycles and times are to be posted for resources of this type, e.g. for evaluating the use of resources (in the evaluation function of the same name) or for consideration in the maintenance calendar (WRM-WWR).

This identifier should not be set for resources of type "Document", "Staff" and "DNC".

Note:

This identifier is only considered for resources that contain the number value 1 in the resource stock.

This value is used as copy template if you manually create a new resource on the client. It is directly transferred to the relevant configuration field of the (newly created) resource. For the rest of the process, only the value specified for the resource is used.

Consider in evaluations

Reserved

Posting on the terminal

If this option is set, resources of this resource type are displayed in the 3rd list.

Counter/energy resource (EMG 8.1)

Specifies if it is a counter or energy resource (only applies when using HYDRA).

Field description for the tab *Maintenance*

Maintenance monitoring based on the following RPAs

This field includes the information which operation hours of which RPAs are used as reference for the maintenance monitoring according to hours of operation.

Note:

This identifier is only relevant in connection with the additional function WMR-WTK (maintenance calendar).

Field description of the tab *DNC/Documents*

DNC processing (only applies when using HYDRA)

Specifies the behavior of HYDRA for DNC resources of this type:

K: No DNC processing (for resources of this type)

All resources except for DNC resources are configured with this processing option.

L: Local program

Generated by upload to the machine and saved in HYDRA.

E: External programming system

The file is located on an external system and from there it is processed through HYDRA.

O: Optimized program

Generated by upload on the terminal and then transferred to the external programming system through HYDRA.

R: Replacement procedure (**DNC 7.2**)

The upload overwrites the version that is applicable at that time.

V: Version based (**DNC 8.2**)

An upload of an existing resource generates a new version.

File-based

The programs are file-based.

Uploaded version set by default (**DNC 8.2**)

If this option is checked, the uploaded version is automatically set as valid version in version-based DNC processing.

File extension for valid programs:

The files for upload-download can be distinguished by their file extension. Only valid programs are used for downloads to the terminal.

File extension for optimized programs:

The files for upload-download can be distinguished by their file extension. New programs optimized by upload are provided with this extension. These programs must be "released" before being downloaded again by the programming system by changing the file extension.

Path

A path configured in HYDRA for saving the files in the server or programming system.

File extension for program description 1...3 (**DNC 7.2**):

A total of 3 other file extensions are available for saving descriptions, etc.

Field description for the tab "compensation"

Posting record after [hh:mm:ss] hours

Specifies the time when a compensation record is to be written at the latest.

Use cancellation documents for editing

If this option is enabled, cancellation records are created as part of the editing process.